


# Wireless Charging Mouse Pad

Instruction Manual  
CD-1024R



## Instructions:

**Wirelessly charging a wireless enabled smartphone using the mouse pad :**

1. Make sure your smartphone has integrated wireless capability or is equipped with wireless charging adapter
2. Insert the micro USB output of charging cable into the input port (3) of the mouse pad & connect USB output of cable to a certified wall adapter.
3. The RED LED light will illuminate that the mouse pad is ready to wirelessly charge your smartphone. Center your electronic device over the icon. The BLUE LED will be off, and the RED LED will be on when the device is fully charged.

• (NOTE: The RED & BLUE LED will flash when other metal object is touching.)

4. To stop charging, remove your electronic device from the icon on mouse pad and disconnect the charging cable.

### NOTE:

- Only smartphones equipped with wireless charging capabilities are able to use the wireless charging of the mouse pad
- The wireless charging dock of mouse pad will activate **only** when it connected to a certified A/C adapter (not included)

## SAFETY PRECAUTIONS:

WARNING—When using this product, basic precautions should always be followed, including the following:

1. Read all the instructions before using the product.
2. The unit's full performance is achieved only after 2 or 3 completed charge and discharge cycles.
3. To reduce the risk of injury, close supervision is necessary when the product is used near children.
4. Do not expose the device to moisture.
5. Do not use the device in excess of its output rating. Overload outputs above rating may result in a risk of fire or injury.
6. Do not use the device if damaged or modified.
7. Damaged or modified batteries may exhibit unpredictable behavior resulting in fire, explosion or risk of injury.
8. Do not disassemble the device. Take it to a qualified service person when service or repair is required. Incorrect reassembly may result in a risk of fire or injury.
9. Do not expose the device to fire or excessive temperature. Exposure to fire or temperatures above 212°F may cause explosion.
10. Have servicing performed by a qualified repair person using only identical replacement parts.
11. This will ensure that the safety of the product is maintained.

## FCC Statement

This device complies with part 15 and part 18 of the FCC Rules. Operation is Subject To the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Changes or modifications not explicitly approved by the party responsible for compliance could void the user's authority to operate this equipment.

Note: this equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 and part 18 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

• Reorient or relocate the receiving antenna.

• Increase the separation between the equipment and receiver.

• Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

• Consult the dealer or an experienced radio/TV technician for help.

The equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. During the operation of device a distance of 15 cm surrounding the device and 20 cm above the top surface of the device must be respected.

This device complies with Part 18 of the FCC Rules. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

• Increase the separation between the equipment and any other radio device.

• Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

## Features:

1. Wireless Charging Dock
2. LED Lights
3. Micro - USB Input Port

## What's included:

- 1 x Wireless charging mouse pad
- 1 x USB to Micro-USB charging cable
- 1 x Instruction Manual

## Tech Specifications

- Input power: DC 5V/1.2A
- Wireless Output: DC 5V/0.8A

Made in China

170\*90mm