

# APP INSTRUCTIONS – TAKE PHOTOS/VIDEOS


Turn on your quadcopter, then go into your phone settings, select WIFI, and then connect to “HolyStoneFPV\*\*\*”, which is the camera connection. Once you have successfully connected, exit the settings menu on your phone and open the ‘Deerc FPV’ App. To see real time images from the quadcopter, simply press the play button in the app.



- 1. Take Photos:** To take a photo, simply tap the Take Photo button. (Pic. 15)
- 2. Take Videos:** To take video, simply tap the Take Video button. (Pic. 16)



(Pic.15)




(Pic.16)


3. All images and videos will be saved to the camera’s micro SD card, so make sure you have inserted that before flight. Once you have finished flying, simply push the card gently to remove it from the camera (Pic. 17), and insert it into a card reader and connect to your computer to access your files.(Pic. 19) All data is saved to a folder called “Deerc FPV” on the phone.




(Pic. 17)



(Pic 18)



(Pic.19)




(Pic.20)

**Tip:** (1) The red light indicator will be flashing quickly when the Memory card is not inserted or already full.  
 (2) The video player must support AVI format.

## MOBILE PHONE CONTROL

You can control the quadcopter directly from within the app without using the transmitter. Hold the mobile phone horizontally when using the Gravity Sensor Mode. Always ensure that you turn off the transmitter before attempting to control the quadcopter via your phone.




## COMMON PROBLEM AND SOLUTION INSTRUCTION:

THE PROBLEM	REASON	COUNTERMEASURES
The indication light of the quadcopter is flashing and without reaction when operated.	1.Frequency modulation between the quadcopter and remote control is not operated correctly. 2.Insufficient battery power.	1.Refer to the Preparation for taking off, and re-modulate the frequency. 2.Recharge the battery.
The blades turn, but the quadcopter can't take off.	1.Insufficient battery power. 2.The blades distorted.	1.Recharge the battery. 2.Replace the blades.
The quadcopter shakes hardly.	The blades distorted.	Replace the blades
Use the tuning functions, but the quadcopter still couldn't keep balance.	1.The blades distorted. 2.The motor doesn't work properly.	1.Replace the blades. 2.Replace the motor.
The quadcopter is out of control after crashing.	Three-axis acceleration sensor lose it's balance after crashing.	Put the quadcopter on the level ground for 5-10 seconds.


## SPARE PARTS:



Blades



Landing Gear



Propeller Guard



USB Cable



Phone Holder



Card Reader



Screw Driver



Battery



Transmitter



FPV WIFI Camera

### Tips:

Please contact Holy Stone for the purchase of replacement parts if the users would need additional ones.



Made in China

# GENERAL INFORMATION

## FCC Information

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC rules. These limits are designed to provide residential protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on. The user is encouraged to try to correct the interference by one or more of the following measures:

Reorient or relocate the receiving antenna.

Increase the separation between the equipment and receiver.

Connect the equipment into an outlet on the circuit different from that to which the receiver is connected.

Consult the dealer or an experienced radio/TV technician for help.

## CAUTION!

The manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications to this equipment. Such modifications could void the user authority to operate the equipment.

## FCC RADIATION EXPOSURE STATEMENT

This equipment complies with FCC RF radiation exposure limits set for an uncontrolled environment. This transmitters must not be co-located or operating in conjunction with any other antenna or transmitter.

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) This device must accept any interference, including interference that may cause undesired operation.

The distance between user and products should be no less than 20cm.

## HOW TO RECYCLE THIS PRODUCT

This symbol on the product or its documentation indicates that it must not be disposed of with household waste. Uncontrolled waste disposal may harm the environment or human health. Please separate your device from other types of waste to recycle it responsibly. This will help to foster the sustainable re-use of material resources. We invite you to contact your retailer or inquire at your local town hall to find out where and how the drone can be recycled.



## BATTERY

**WARNING:** Failure to follow all the instructions may result in serious injury, irreparable damage to the battery and may cause a fire, smoke or explosion. Always check the battery's condition before charging or using it. Replace the battery if it has been dropped, or in case of odour, overheating, discolouration, deformation or leakage. Never use anything other than the approval LiPo charger the battery. Always use a balancing charger for LiPo cells or a LiPo cell balancer. It is recommended that you do not to use any other charger than the one provided with the product. The battery temperature must never exceed 60°C(140°F) otherwise the battery could be damaged or ignite. Never charger on a flammable surface, near flammable products or inside a vehicle (preferably place the battery in a non-flammable and non-conductive container). Never leave the battery unattended during the charging process. Never disassemble or modify the housing's wiring, or puncture the cells. Always ensure that the charger output voltage corresponds to the voltage of the battery. Do not short circuit the batteries. Never expose the LiPo battery to moisture or direct sunlight, or store it in a place where temperatures could exceed 60°C(car in the sun, for example). Always keep it out of reach of children. Improper battery use may result in a fire, explosion or other hazard.

## MANUFACTURER INFORMATION

Manufactured by Xiamen Huoshiquan Import & Export CO., LTD  
Room 703, No. 813-2 Xiahe Road, Siming District, XIAMEN, China

**IC Notice:**

This device complies with Canada Industry licence-exempt RSS standard(s). Operation is subject to the following two conditions:

- (1) this device may not cause interference; and
- (2) this device must accept any interference. Including interference that may cause undesired operation of the device.

Cet appareil est conforme aux CNR exemptes de licence d'Industrie Canada . Son fonctionnement est soumis aux deux conditions suivantes :

- ( 1 ) Ce dispositif ne peut causer d'interférences ; et
- ( 2 ) Ce dispositif doit accepter toute interférence , y compris les interférences qui peuvent causer un mauvais fonctionnement de l'appareil.

**RF Exposure****Radiation Exposure Statement:**

This equipment complies with IC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.

**Déclaration d'exposition aux radiations:**

Cet équipement est conforme aux limites d'exposition aux rayonnements IC établies pour un environnement non contrôlé. Cet équipement doit être installé et utilisé avec un minimum de 20 cm de distance entre la source de rayonnement et votre corps.