

	 Hand-free function In Bluetooth mode, short press to answer a call, short press again to hang up the call. In Bluetooth/TF/USB/Radio modes, short press button to PLAY/PAUSE the song. In radio mode, long press the button to search for the channels. key In Bluetooth/TF/USB modes, short press — key to change to previous song, long press — key to decrease the volume. In radio mode, short press — key to change to previous channel, long press — key to decrease the volume. key In Bluetooth/TF/USB modes, short press + key to change to next song, long press + key to increase the volume. 	This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1)This device may not cause harmful interference, and (2)This device must accept any interference received, including interference that may cause undesired operation. Warning: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. NOTE: This equipment has been tested and found to comply with the limits
(3) (2) (4)	In radio mode, short press + key to change to next channel, long press + key to increase the volume.	for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.
MP3 files automatically. cted is 32G.	Bluetooth Pairing:	However, there is no guarantee that interference will not occur in a particular
files automatically. ected is 32G.	Long press the Button to turn the speaker on, then search for "535698" in your phone and connect to it. You will hear an audio prompt when the speaker has paired successfully with your device.	installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more
ided)into the AUX port, and connect the vice.	Pairing TWS: Turn the two speakers on and ensure these two speakers did not connected with any Bluetooth device, then long press button on one of the speakers. You will hear an audio	of the following measures: Reorient or relocate the receiving antenna. Increase the separation between the equipment and receiver.
g cable(included) to the charging port,and ıter' s USB port or an AC adaptor(not	prompt when the speakers have paired each other successfully. Only one Bluetooth pairing name "535698" appeared in your device means the TWS speakers are ready to pair.	Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. Consult the dealer or an experienced radio/TV technician for help.
ter full charged, the red indicate light will	Technical Speci⊣cations: Power: DC 5V, 0.5A	
f the speaker in standby mode.	Battery: 1200mAh Battery run time: 2-3 hours Operation temperature: 0-45°C	RF warning statement: The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

Jong press + key to NOTE: This equipment has been tested and found to comply with the limits + key to increase the for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: with your device. and on, the user is encouraged to try to correct the interference by one or more of the following measures: ected with any Reorient or relocate the receiving antenna. , You will hear an audio ne Bluetooth pairing ready to pair. Increase the separation between the equipment and receiver. Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. Consult the dealer or an experienced radio/TV technician for help.

FCC STATEMENT :