



## 14. A Quick Look at Your RC Car's Remote Control



## 15. Inserting Batteries Into Your Remote Control



**Use a screwdriver to open up the battery compartment located on the rear of your remote control.**


**Insert 2 AA 1.5V batteries, making sure that the batteries are inserted with the correct polarity (+,-) as displayed in the battery compartment.**

**Once the batteries are inserted, put the battery compartment cover back on the battery compartment, and use a screwdriver to close it securely.**




- Do not mix rechargeable and non-rechargeable batteries.**
- Do not mix old and new batteries or different types of batteries.**
- Remove exhausted batteries and dispose of them based on the rules of your local municipality.**
- Remove the batteries from your remote control if it will not be in use for an extended period of time.**

## 16. Charging Your RC Car's Battery




Open the drone's rear battery module and then pull the lithium battery out of the car battery compartment.

### USB CHARGER



Connect the battery to the included charger. Then plug the charger into a USB charging adapter (not included). For best results, use a 5V, 1-2A charger to charge the battery.

While charging, an LED light on the charger will illuminate. This light will turn off once charging is complete. Charging typically takes approximately 90 to 120 minutes with a playtime of 15 minutes.



Once fully charged, insert the battery back into the battery compartment, making sure to connect it to the connector on the circuit board. Make sure when connecting not to reverse the positive and negative poles (+,-).


### ⚠ WARNING:

1. Unplug the charger when charging is complete to avoid damaging the battery.
2. Do not leave the battery unattended when charging.
3. Do not use other chargers other than the one supplied.
4. Wait at least 30 minutes after using your drone before charging the battery. The battery's temperature can become elevated during use and charging it immediately could damage the battery.
5. Remove the drone's battery when the drone is not in use. Store it in a cool dry place.
6. Do not leave the battery exposed to excessive heat, flame or fire.
7. Do not short circuit the battery. Do not leave the battery in contact with any metal parts.

## 17. Driving Your RC Car

### Powering On Your RC Car

To use your RC Car, locate the power switch on the car's underside.




Move the power switch left and right to turn your car ON/OFF. Make sure to turn your RC car off when it is no longer used to preserve the battery charge.

### RC Controls

Use the left joystick to move the car forward and backward.

Use the right joystick to turn the car left and right.



**This device complies with part 15 of the FCC Rules. Operation is subject to the condition that this device does not cause harmful interference (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.**

**Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.**

**NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.**

**If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:**

- Reorient or relocate the receiving antenna.**
- Increase the separation between the equipment and receiver.**
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.**
- Consult the dealer or an experienced radio/TV technician for help.**

**To maintain compliance with FCC' s RF Exposure guidelines, The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.**

**FCC ID:2AJGI-C014D6**