



börne BTWS550



The earbuds are pre-paired with each other. Turn on the Bluetooth function on your device.



Open the case beside your unlocked device and search for "BTWS550" and connect.



Note: Music playback, call functions and volume can be also controlled from your device.



Press and hold to activate Siri on your iPhone. Make sure Siri is enabled in your settings.

CHARGING THE CASE & EARBUDS

With the earbuds in the case, charge the unit using the USB cable provided. Connect one end into a USB charging port on your computer or USB wall charger (not included) and the other end into the Charging Port located on the bottom of the case.

The LED Indicator Light will flash red while charging. Charging will be complete in approximately 3-4 hours.

CHARGING THE EARBUDS IN THE CASE

The case has a built-in battery to charge your earbuds while on the go. When the case is fully charged with the earbuds in the case, press the Charging Button located on the back of the case to charge your earbuds.

Need help? Please call us.

1-800-593-6669

Monday to Friday: 9am – 5pm EST

Email: support@borne-lifestyle.com

IMPORTANT SAFEGUARDS

Listening with this product at high volume may affect your hearing. For your safety, do not use this headset while driving a motor vehicle or while cycling. Do not use this product in places where it would be dangerous if you are unable to hear ambient sound, such as at railroad crossings, train station platforms, pedestrian crossings, and construction sites. To avoid impairing your hearing with prolonged operation, keep the volume at a moderate level. Do not leave this product in a hot car or a place with high heat temperatures for a long period of time. Do not expose this product to water or any other liquids. This product is not waterproof.

Do not use this product in humid locations or bad weather, such as in the rain or snow.

PRODUCT AND BATTERY DISPOSAL

This product contains a built-in lithium battery and should not be disposed of in normal household waste. The battery in this device is not intended to be removed by the individual or end user. For disposal and recycling, please contact your local waste management authorities. The recycling and processing of electronic waste will make a significant contribution towards helping protect the environment. Warning: To reduce the risk of fire and burns, do not disassemble, crush, puncture, short external contacts or dispose of in fire or water.

IC Warning

This device complies with Industry Canada license-exempt RSS standard(s). Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

Under Industry Canada regulations, this radio transmitter may only operate using an antenna of a type and maximum (or lesser) gain approved for the transmitter by Industry Canada. To reduce potential radio interference to other users, the antenna type and its gain should be so chosen that the equivalent isotropically radiated power (e.i.r.p.) is not more than that necessary for successful communication. This device complies with Canadian ICES-003 and RSS-247

FCC Warning

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE 1: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

NOTE 2: Any changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

WARNING

FCC/ISED Radiation Exposure Statement:

This equipment complies with FCC/ISED radiation exposure limits set forth for an uncontrolled environment. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.