



a-Six Wireless

Getting started, safety and warranty

Important safety instructions

1. Read, follow and keep these instructions.
2. For the best possible experience, always use the product as described by the manufacturer.
3. Always handle your earphones with care and protect them from external damage.
4. Clean your earphones using a soft dry cloth. Never use water, cleaning detergent, leather polish or other substances as they may damage your earphones permanently.
5. Avoid exposure to extreme conditions such as very cold or hot temperatures, magnetic fields or damp environments.
6. Listening to music at high volume for prolonged periods of time can cause permanent damage to your hearing.
7. Contains small parts and are not suitable for children age three (3) and below.
8. The earphones contain magnetic material.
9. The earphones contain a Lithium battery. If misused or damaged it can become a hazard and is at risk of explosion.
10. Should a battery cell leak, do not allow the liquid to come in contact with skin or eyes.
11. The earphones must be switched off before boarding an aircraft.
12. The earphones must not be disposed of with regular household waste. Please dispose of in accordance with local regulations.
13. Do not use your earphones in the immediate proximity (10 cm) of a pacemaker.
14. Do not subject the product and included accessories to abnormal wear and tear.
15. Do not expose the earphones to temperatures below -20°C or above +45°C.
16. Do not attempt to burn the earphones. The battery could explode causing injury and death.
17. Do not attempt to open, modify, disassemble, repair or in other way access the internal structure of the earphones. They are not user serviceable.
18. Do not use or store the earphones near to a vehicle airbag due to risk of injury.
19. Do not use earphones while driving, jogging or walking through traffic areas. Earphones effectively isolate external sound and noise, which means that when in use, you might not be able to hear your surroundings.
20. Do not drop, sit on or cause other unusual impact to the earphones.
21. Do not expose to fire, water or high voltage equipment.
22. Do not expose the product to rain or moisture.
23. Do not use the earphones near water, bathtubs, sinks, saunas, pools, other liquids or moist areas.

Statements

US FCC interference statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

MODIFICATION: Any changes or modifications not expressly approved by the grantee of this device could void the user's authority to operate the device. This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

US FCC radiation exposure statement

FCC ID: XXXXXXXXXX. The product comply with the US portable RF exposure limit set forth for an uncontrolled environment and are safe for intended operation as described in this manual. The further RF exposure reduction can be achieved if the product can be kept as far as possible from the user body or set the device to lower output power if such function is available. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

EU Declaration of conformity

Hereby Jays AB declares that this product is in compliance with the essential requirements and other relevant provisions of Directive R&TTE 1999/5/EC and all other EU directive requirements. The complete declaration of conformity can be found at www.jaysheadphones.com.

Caution

Risk of explosions if battery box is damaged or opened. Dispose of used battery according to your local waste disposal authority.

KO KC statement

헤드 무선설비는 운용중 전파혼신 가능성이 있으므로 인명안전과 관련된 서비스는 할수 없습니다.

MSIP-XXX-XXX-A6W01

Model: A6W01



Complies with
IMDA Standards
N0122-17

Getting started

Power on/off and pairing

To power on, press and hold the center button for 3s. A voice assistant will tell you the current battery status. Pairing mode will automatically be initiated, indicated by the LED blinking slowly. Go to Bluetooth® settings on your device and select "JAYS a-Six Wireless". The blinking LED will turn off upon a successful connection followed by a short audio beep.

To power off, press and hold the center button for 3s.

Reconnecting and additional pairing

Next time you power on, the earphones will automatically try to reconnect to the most recently used device. If not found, or if you manually disconnect through your device, pairing mode will automatically be initiated again. To force pairing mode, press center button for 5s from off state.

Battery status and charging

When on, press and hold the down-button 2s for voice assistant battery status.

Battery high: 70-100% remaining

Battery medium: 30-70% remaining

Battery low: 0-30% remaining

When battery is below 3%, "Battery low" will be announced automatically.

Charge using a USB cable and connect it to any certified USB power output. Charging is indicated by a solid red light, and a full charge is indicated by a solid white light.

Troubleshooting

Problem pairing and connecting

- Make sure the earphones are not connected to another device.
- Disable and enable Bluetooth on your device.
- Move the earphones closer to the device or alter their positions to avoid Bluetooth interference.
- Verify no other wireless equipment interfere with your earphone Bluetooth signal.

Problem with sound transmission

Move the streaming device to another position. Your body, distance, different materials and other wireless equipment can interfere with the wireless signal between your device and earphone.

Legal & Warranty

Environmental information

This product complies with international directives, including but not limited to WEEE Directive (2012/19/EU). Do not dispose with normal household waste. Please consult your local waste disposal authority for guidance on how to properly recycle or dispose of this product.

Manufacturer's limited warranty

Your original Jays AB product is covered by a warranty of twelve (12) months from the date of purchase of a brand new, unused Jays AB product by the original purchaser. Jays AB guarantees that the product is free from faults in the materials, design and workmanship when it was sold to the purchaser. If you are not able to submit the receipt when making a warranty claim you may be obliged to pay for any repairs carried out. Proof of purchase must clearly state the date of purchase, name of the product and authorized resellers' details. For Australian customers, please visit www.jaysheadphones.com for full warranty terms.

Limited warranty period

The product may include different parts and they may have different Warranty Periods. The different Warranty Periods for this product are:

- Twelve (12) months warranty on the product and included accessories

The Warranty Period cannot be extended or renewed due to subsequent resale or replacement of the product. This Limited Warranty does not affect your legal rights under your applicable national laws relating to the sale of consumer electronic products. Defective parts replaced within the Limited Warranty Claim shall become the property of Jays AB.

What is not covered by the limited warranty?

- Faults caused by wear and tear, accident, dropping, mechanical damage, moisture, chemical products, abnormal impact damage or force majeure.
- Modification or repair by yourself or third party without Jays AB approval.

How to get warranty service

If you wish to make a Warranty Claim within the Limited Warranty Period, please contact the reseller of your product for further help. You will need to provide the proof of purchase and the affected part. Any defective parts covered by the Limited Warranty will be repaired or replaced free of charge. Replaced or repaired parts provided during the Warranty Period will be warranted for the remainder of the original Warranty Period or for sixty (60) days from the date of repair or replacement, whichever is longer. For FAQ please visit www.jaysheadphones.com.



Getting started

Power on/off and pairing

To power on, press and hold the center button for 3s. A voice assistant will tell you the current battery status. Pairing mode will automatically be initiated, indicated by the LED blinking slowly. Go to Bluetooth® settings on your device and select "JAYS a-Six Wireless". The blinking LED will turn off upon a successful connection followed by a short audio beep.

To power off, press and hold the center button for 3s.

Reconnecting and additional pairing

Next time you power on, the earphones will automatically try to reconnect to the most recently used device. If not found, or if you manually disconnect through your device, pairing mode will automatically be initiated again. To force pairing mode, press center button for 5s from off state.

Battery status and charging

When on, press and hold the down-button 2s for voice assistant battery status.

Battery high: 70-100% remaining

Battery medium: 30-70% remaining

Battery low: 0-30% remaining

When battery is below 3%, "Battery low" will be announced automatically.

Charge using a USB cable and connect it to any certified USB power output. Charging is indicated by a solid red light, and a full charge is indicated by a solid white light.

Troubleshooting

Problem pairing and connecting

- Make sure the earphones are not connected to another device.
- Disable and enable Bluetooth on your device.
- Move the earphones closer to the device or alter their positions to avoid Bluetooth interference.
- Verify no other wireless equipment interfere with your earphone Bluetooth signal.

Problem with sound transmission

Move the streaming device to another position. Your body, distance, different materials and other wireless equipment can interfere with the wireless signal between your device and earphone.

Legal & Warranty

Environmental information

This product complies with international directives, including but not limited to WEEE Directive (2012/19/EU). Do not dispose with normal household waste. Please consult your local waste disposal authority for guidance on how to properly recycle or dispose of this product.

Manufacturer's limited warranty

Your original Jays AB product is covered by a warranty of twelve (12) months from the date of purchase of a brand new, unused Jays AB product by the original purchaser. Jays AB guarantees that the product is free from faults in the materials, design and workmanship when it was sold to the purchaser. If you are not able to submit the receipt when making a warranty claim you may be obliged to pay for any repairs carried out. Proof of purchase must clearly state the date of purchase, name of the product and authorized resellers' details. For Australian customers, please visit www.jaysheadphones.com for full warranty terms.

Limited warranty period

The product may include different parts and they may have different Warranty Periods. The different Warranty Periods for this product are:

- Twelve (12) months warranty on the product and included accessories

The Warranty Period cannot be extended or renewed due to subsequent resale or replacement of the product. This Limited Warranty does not affect your legal rights under your applicable national laws relating to the sale of consumer electronic products. Defective parts replaced within the Limited Warranty Claim shall become the property of Jays AB.

What is not covered by the limited warranty?

- Faults caused by wear and tear, accident, dropping, mechanical damage, moisture, chemical products, abnormal impact damage or force majeure.
- Modification or repair by yourself or third party without Jays AB approval.

How to get warranty service

If you wish to make a Warranty Claim within the Limited Warranty Period, please contact the reseller of your product for further help. You will need to provide the proof of purchase and the affected part. Any defective parts covered by the Limited Warranty will be repaired or replaced free of charge. Replaced or repaired parts provided during the Warranty Period will be warranted for the remainder of the original Warranty Period or for sixty (60) days from the date of repair or replacement, whichever is longer. For FAQ please visit www.jaysheadphones.com.

Getting started

Power on/off and pairing

To power on, press and hold the center button for 3s. A voice assistant will tell you the current battery status. Pairing mode will automatically be initiated, indicated by the LED blinking slowly. Go to Bluetooth® settings on your device and select "JAYS a-Six Wireless". The blinking LED will turn off upon a successful connection followed by a short audio beep.

To power off, press and hold the center button for 3s.

Reconnecting and additional pairing

Next time you power on, the earphones will automatically try to reconnect to the most recently used device. If not found, or if you manually disconnect through your device, pairing mode will automatically be initiated again. To force pairing mode, press center button for 5s from off state.

Battery status and charging

When on, press and hold the down-button 2s for voice assistant battery status.

Battery high: 70-100% remaining

Battery medium: 30-70% remaining

Battery low: 0-30% remaining

When battery is below 3%, "Battery low" will be announced automatically.

Charge using a USB cable and connect it to any certified USB power output. Charging is indicated by a solid red light, and a full charge is indicated by a solid white light.

Troubleshooting

Problem pairing and connecting

- Make sure the earphones are not connected to another device.
- Disable and enable Bluetooth on your device.
- Move the earphones closer to the device or alter their positions to avoid Bluetooth interference.
- Verify no other wireless equipment interfere with your earphone Bluetooth signal.

Problem with sound transmission

Move the streaming device to another position. Your body, distance, different materials and other wireless equipment can interfere with the wireless signal between your device and earphone.

Legal & Warranty

Environmental information

This product complies with international directives, including but not limited to WEEE Directive (2012/19/EU). Do not dispose with normal household waste. Please consult your local waste disposal authority for guidance on how to properly recycle or dispose of this product.

Manufacturer's limited warranty

Your original Jays AB product is covered by a warranty of twelve (12) months from the date of purchase of a brand new, unused Jays AB product by the original purchaser. Jays AB guarantees that the product is free from faults in the materials, design and workmanship when it was sold to the purchaser. If you are not able to submit the receipt when making a warranty claim you may be obliged to pay for any repairs carried out. Proof of purchase must clearly state the date of purchase, name of the product and authorized resellers' details. For Australian customers, please visit www.jaysheadphones.com for full warranty terms.

Limited warranty period

The product may include different parts and they may have different Warranty Periods. The different Warranty Periods for this product are:

- Twelve (12) months warranty on the product and included accessories

The Warranty Period cannot be extended or renewed due to subsequent resale or replacement of the product. This Limited Warranty does not affect your legal rights under your applicable national laws relating to the sale of consumer electronic products. Defective parts replaced within the Limited Warranty Claim shall become the property of Jays AB.

What is not covered by the limited warranty?

- Faults caused by wear and tear, accident, dropping, mechanical damage, moisture, chemical products, abnormal impact damage or force majeure.
- Modification or repair by yourself or third party without Jays AB approval.

How to get warranty service

If you wish to make a Warranty Claim within the Limited Warranty Period, please contact the reseller of your product for further help. You will need to provide the proof of purchase and the affected part. Any defective parts covered by the Limited Warranty will be repaired or replaced free of charge. Replaced or repaired parts provided during the Warranty Period will be warranted for the remainder of the original Warranty Period or for sixty (60) days from the date of repair or replacement, whichever is longer. For FAQ please visit www.jaysheadphones.com.



Getting started

Power on/off and pairing

To power on, press and hold the center button for 3s. A voice assistant will tell you the current battery status. Pairing mode will automatically be initiated, indicated by the LED blinking slowly. Go to Bluetooth® settings on your device and select "JAYS a-Six Wireless". The blinking LED will turn off upon a successful connection followed by a short audio beep.

To power off, press and hold the center button for 3s.

Reconnecting and additional pairing

Next time you power on, the earphones will automatically try to reconnect to the most recently used device. If not found, or if you manually disconnect through your device, pairing mode will automatically be initiated again. To force pairing mode, press center button for 5s from off state.

Battery status and charging

When on, press and hold the down-button 2s for voice assistant battery status.

Battery high: 70-100% remaining

Battery medium: 30-70% remaining

Battery low: 0-30% remaining

When battery is below 3%, "Battery low" will be announced automatically.

Charge using a USB cable and connect it to any certified USB power output. Charging is indicated by a solid red light, and a full charge is indicated by a solid white light.

Troubleshooting

Problem pairing and connecting

- Make sure the earphones are not connected to another device.
- Disable and enable Bluetooth on your device.
- Move the earphones closer to the device or alter their positions to avoid Bluetooth interference.
- Verify no other wireless equipment interfere with your earphone Bluetooth signal.

Problem with sound transmission

Move the streaming device to another position. Your body, distance, different materials and other wireless equipment can interfere with the wireless signal between your device and earphone.

Legal & Warranty

Environmental information

This product complies with international directives, including but not limited to WEEE Directive (2012/19/EU). Do not dispose with normal household waste. Please consult your local waste disposal authority for guidance on how to properly recycle or dispose of this product.

Manufacturer's limited warranty

Your original Jays AB product is covered by a warranty of twelve (12) months from the date of purchase of a brand new, unused Jays AB product by the original purchaser. Jays AB guarantees that the product is free from faults in the materials, design and workmanship when it was sold to the purchaser. If you are not able to submit the receipt when making a warranty claim you may be obliged to pay for any repairs carried out. Proof of purchase must clearly state the date of purchase, name of the product and authorized resellers' details. For Australian customers, please visit www.jaysheadphones.com for full warranty terms.

Limited warranty period

The product may include different parts and they may have different Warranty Periods. The different Warranty Periods for this product are:

- Twelve (12) months warranty on the product and included accessories

The Warranty Period cannot be extended or renewed due to subsequent resale or replacement of the product. This Limited Warranty does not affect your legal rights under your applicable national laws relating to the sale of consumer electronic products. Defective parts replaced within the Limited Warranty Claim shall become the property of Jays AB.

What is not covered by the limited warranty?

- Faults caused by wear and tear, accident, dropping, mechanical damage, moisture, chemical products, abnormal impact damage or force majeure.
- Modification or repair by yourself or third party without Jays AB approval.

How to get warranty service

If you wish to make a Warranty Claim within the Limited Warranty Period, please contact the reseller of your product for further help. You will need to provide the proof of purchase and the affected part. Any defective parts covered by the Limited Warranty will be repaired or replaced free of charge. Replaced or repaired parts provided during the Warranty Period will be warranted for the remainder of the original Warranty Period or for sixty (60) days from the date of repair or replacement, whichever is longer. For FAQ please visit www.jaysheadphones.com.

Getting started

Power on/off and pairing

To power on, press and hold the center button for 3s. A voice assistant will tell you the current battery status. Pairing mode will automatically be initiated, indicated by the LED blinking slowly. Go to Bluetooth® settings on your device and select "JAYS a-Six Wireless". The blinking LED will turn off upon a successful connection followed by a short audio beep.

To power off, press and hold the center button for 3s.

Reconnecting and additional pairing

Next time you power on, the earphones will automatically try to reconnect to the most recently used device. If not found, or if you manually disconnect through your device, pairing mode will automatically be initiated again. To force pairing mode, press center button for 5s from off state.

Battery status and charging

When on, press and hold the down-button 2s for voice assistant battery status.

Battery high: 70-100% remaining

Battery medium: 30-70% remaining

Battery low: 0-30% remaining

When battery is below 3%, "Battery low" will be announced automatically.

Charge using a USB cable and connect it to any certified USB power output. Charging is indicated by a solid red light, and a full charge is indicated by a solid white light.

Troubleshooting

Problem pairing and connecting

- Make sure the earphones are not connected to another device.
- Disable and enable Bluetooth on your device.
- Move the earphones closer to the device or alter their positions to avoid Bluetooth interference.
- Verify no other wireless equipment interfere with your earphone Bluetooth signal.

Problem with sound transmission

Move the streaming device to another position. Your body, distance, different materials and other wireless equipment can interfere with the wireless signal between your device and earphone.

Legal & Warranty

Environmental information

This product complies with international directives, including but not limited to WEEE Directive (2012/19/EU). Do not dispose with normal household waste. Please consult your local waste disposal authority for guidance on how to properly recycle or dispose of this product.

Manufacturer's limited warranty

Your original Jays AB product is covered by a warranty of twelve (12) months from the date of purchase of a brand new, unused Jays AB product by the original purchaser. Jays AB guarantees that the product is free from faults in the materials, design and workmanship when it was sold to the purchaser. If you are not able to submit the receipt when making a warranty claim you may be obliged to pay for any repairs carried out. Proof of purchase must clearly state the date of purchase, name of the product and authorized resellers' details. For Australian customers, please visit www.jaysheadphones.com for full warranty terms.

Limited warranty period

The product may include different parts and they may have different Warranty Periods. The different Warranty Periods for this product are:

- Twelve (12) months warranty on the product and included accessories

The Warranty Period cannot be extended or renewed due to subsequent resale or replacement of the product. This Limited Warranty does not affect your legal rights under your applicable national laws relating to the sale of consumer electronic products. Defective parts replaced within the Limited Warranty Claim shall become the property of Jays AB.

What is not covered by the limited warranty?

- Faults caused by wear and tear, accident, dropping, mechanical damage, moisture, chemical products, abnormal impact damage or force majeure.
- Modification or repair by yourself or third party without Jays AB approval.

How to get warranty service

If you wish to make a Warranty Claim within the Limited Warranty Period, please contact the reseller of your product for further help. You will need to provide the proof of purchase and the affected part. Any defective parts covered by the Limited Warranty will be repaired or replaced free of charge. Replaced or repaired parts provided during the Warranty Period will be warranted for the remainder of the original Warranty Period or for sixty (60) days from the date of repair or replacement, whichever is longer. For FAQ please visit www.jaysheadphones.com.



Getting started

Power on/off and pairing

To power on, press and hold the center button for 3s. A voice assistant will tell you the current battery status. Pairing mode will automatically be initiated, indicated by the LED blinking slowly. Go to Bluetooth® settings on your device and select "JAYS a-Six Wireless". The blinking LED will turn off upon a successful connection followed by a short audio beep.

To power off, press and hold the center button for 3s.

Reconnecting and additional pairing

Next time you power on, the earphones will automatically try to reconnect to the most recently used device. If not found, or if you manually disconnect through your device, pairing mode will automatically be initiated again. To force pairing mode, press center button for 5s from off state.

Battery status and charging

When on, press and hold the down-button 2s for voice assistant battery status.

Battery high: 70-100% remaining

Battery medium: 30-70% remaining

Battery low: 0-30% remaining

When battery is below 3%, "Battery low" will be announced automatically.

Charge using a USB cable and connect it to any certified USB power output. Charging is indicated by a solid red light, and a full charge is indicated by a solid white light.

Troubleshooting

Problem pairing and connecting

- Make sure the earphones are not connected to another device.
- Disable and enable Bluetooth on your device.
- Move the earphones closer to the device or alter their positions to avoid Bluetooth interference.
- Verify no other wireless equipment interfere with your earphone Bluetooth signal.

Problem with sound transmission

Move the streaming device to another position. Your body, distance, different materials and other wireless equipment can interfere with the wireless signal between your device and earphone.

Legal & Warranty

Environmental information

This product complies with international directives, including but not limited to WEEE Directive (2012/19/EU). Do not dispose with normal household waste. Please consult your local waste disposal authority for guidance on how to properly recycle or dispose of this product.

Manufacturer's limited warranty

Your original Jays AB product is covered by a warranty of twelve (12) months from the date of purchase of a brand new, unused Jays AB product by the original purchaser. Jays AB guarantees that the product is free from faults in the materials, design and workmanship when it was sold to the purchaser. If you are not able to submit the receipt when making a warranty claim you may be obliged to pay for any repairs carried out. Proof of purchase must clearly state the date of purchase, name of the product and authorized resellers' details. For Australian customers, please visit www.jaysheadphones.com for full warranty terms.

Limited warranty period

The product may include different parts and they may have different Warranty Periods. The different Warranty Periods for this product are:

- Twelve (12) months warranty on the product and included accessories

The Warranty Period cannot be extended or renewed due to subsequent resale or replacement of the product. This Limited Warranty does not affect your legal rights under your applicable national laws relating to the sale of consumer electronic products. Defective parts replaced within the Limited Warranty Claim shall become the property of Jays AB.

What is not covered by the limited warranty?

- Faults caused by wear and tear, accident, dropping, mechanical damage, moisture, chemical products, abnormal impact damage or force majeure.
- Modification or repair by yourself or third party without Jays AB approval.

How to get warranty service

If you wish to make a Warranty Claim within the Limited Warranty Period, please contact the reseller of your product for further help. You will need to provide the proof of purchase and the affected part. Any defective parts covered by the Limited Warranty will be repaired or replaced free of charge. Replaced or repaired parts provided during the Warranty Period will be warranted for the remainder of the original Warranty Period or for sixty (60) days from the date of repair or replacement, whichever is longer. For FAQ please visit www.jaysheadphones.com.

Getting started

Power on/off and pairing

To power on, press and hold the center button for 3s. A voice assistant will tell you the current battery status. Pairing mode will automatically be initiated, indicated by the LED blinking slowly. Go to Bluetooth® settings on your device and select "JAYS a-Six Wireless". The blinking LED will turn off upon a successful connection followed by a short audio beep.

To power off, press and hold the center button for 3s.

Reconnecting and additional pairing

Next time you power on, the earphones will automatically try to reconnect to the most recently used device. If not found, or if you manually disconnect through your device, pairing mode will automatically be initiated again. To force pairing mode, press center button for 5s from off state.

Battery status and charging

When on, press and hold the down-button 2s for voice assistant battery status.

Battery high: 70-100% remaining

Battery medium: 30-70% remaining

Battery low: 0-30% remaining

When battery is below 3%, "Battery low" will be announced automatically.

Charge using a USB cable and connect it to any certified USB power output. Charging is indicated by a solid red light, and a full charge is indicated by a solid white light.

Troubleshooting

Problem pairing and connecting

- Make sure the earphones are not connected to another device.
- Disable and enable Bluetooth on your device.
- Move the earphones closer to the device or alter their positions to avoid Bluetooth interference.
- Verify no other wireless equipment interfere with your earphone Bluetooth signal.

Problem with sound transmission

Move the streaming device to another position. Your body, distance, different materials and other wireless equipment can interfere with the wireless signal between your device and earphone.

Legal & Warranty

Environmental information

This product complies with international directives, including but not limited to WEEE Directive (2012/19/EU). Do not dispose with normal household waste. Please consult your local waste disposal authority for guidance on how to properly recycle or dispose of this product.

Manufacturer's limited warranty

Your original Jays AB product is covered by a warranty of twelve (12) months from the date of purchase of a brand new, unused Jays AB product by the original purchaser. Jays AB guarantees that the product is free from faults in the materials, design and workmanship when it was sold to the purchaser. If you are not able to submit the receipt when making a warranty claim you may be obliged to pay for any repairs carried out. Proof of purchase must clearly state the date of purchase, name of the product and authorized resellers' details. For Australian customers, please visit www.jaysheadphones.com for full warranty terms.

Limited warranty period

The product may include different parts and they may have different Warranty Periods. The different Warranty Periods for this product are:

- Twelve (12) months warranty on the product and included accessories

The Warranty Period cannot be extended or renewed due to subsequent resale or replacement of the product. This Limited Warranty does not affect your legal rights under your applicable national laws relating to the sale of consumer electronic products. Defective parts replaced within the Limited Warranty Claim shall become the property of Jays AB.

What is not covered by the limited warranty?

- Faults caused by wear and tear, accident, dropping, mechanical damage, moisture, chemical products, abnormal impact damage or force majeure.
- Modification or repair by yourself or third party without Jays AB approval.

How to get warranty service

If you wish to make a Warranty Claim within the Limited Warranty Period, please contact the reseller of your product for further help. You will need to provide the proof of purchase and the affected part. Any defective parts covered by the Limited Warranty will be repaired or replaced free of charge. Replaced or repaired parts provided during the Warranty Period will be warranted for the remainder of the original Warranty Period or for sixty (60) days from the date of repair or replacement, whichever is longer. For FAQ please visit www.jaysheadphones.com.



Getting started

Power on/off and pairing

To power on, press and hold the center button for 3s. A voice assistant will tell you the current battery status. Pairing mode will automatically be initiated, indicated by the LED blinking slowly. Go to Bluetooth® settings on your device and select "JAYS a-Six Wireless". The blinking LED will turn off upon a successful connection followed by a short audio beep.

To power off, press and hold the center button for 3s.

Reconnecting and additional pairing

Next time you power on, the earphones will automatically try to reconnect to the most recently used device. If not found, or if you manually disconnect through your device, pairing mode will automatically be initiated again. To force pairing mode, press center button for 5s from off state.

Battery status and charging

When on, press and hold the down-button 2s for voice assistant battery status.

Battery high: 70-100% remaining

Battery medium: 30-70% remaining

Battery low: 0-30% remaining

When battery is below 3%, "Battery low" will be announced automatically.

Charge using a USB cable and connect it to any certified USB power output. Charging is indicated by a solid red light, and a full charge is indicated by a solid white light.

Troubleshooting

Problem pairing and connecting

- Make sure the earphones are not connected to another device.
- Disable and enable Bluetooth on your device.
- Move the earphones closer to the device or alter their positions to avoid Bluetooth interference.
- Verify no other wireless equipment interfere with your earphone Bluetooth signal.

Problem with sound transmission

Move the streaming device to another position. Your body, distance, different materials and other wireless equipment can interfere with the wireless signal between your device and earphone.

Legal & Warranty

Environmental information

This product complies with international directives, including but not limited to WEEE Directive (2012/19/EU). Do not dispose with normal household waste. Please consult your local waste disposal authority for guidance on how to properly recycle or dispose of this product.

Manufacturer's limited warranty

Your original Jays AB product is covered by a warranty of twelve (12) months from the date of purchase of a brand new, unused Jays AB product by the original purchaser. Jays AB guarantees that the product is free from faults in the materials, design and workmanship when it was sold to the purchaser. If you are not able to submit the receipt when making a warranty claim you may be obliged to pay for any repairs carried out. Proof of purchase must clearly state the date of purchase, name of the product and authorized resellers' details. For Australian customers, please visit www.jaysheadphones.com for full warranty terms.

Limited warranty period

The product may include different parts and they may have different Warranty Periods. The different Warranty Periods for this product are:

- Twelve (12) months warranty on the product and included accessories

The Warranty Period cannot be extended or renewed due to subsequent resale or replacement of the product. This Limited Warranty does not affect your legal rights under your applicable national laws relating to the sale of consumer electronic products. Defective parts replaced within the Limited Warranty Claim shall become the property of Jays AB.

What is not covered by the limited warranty?

- Faults caused by wear and tear, accident, dropping, mechanical damage, moisture, chemical products, abnormal impact damage or force majeure.
- Modification or repair by yourself or third party without Jays AB approval.

How to get warranty service

If you wish to make a Warranty Claim within the Limited Warranty Period, please contact the reseller of your product for further help. You will need to provide the proof of purchase and the affected part. Any defective parts covered by the Limited Warranty will be repaired or replaced free of charge. Replaced or repaired parts provided during the Warranty Period will be warranted for the remainder of the original Warranty Period or for sixty (60) days from the date of repair or replacement, whichever is longer. For FAQ please visit www.jaysheadphones.com.

Getting started

Power on/off and pairing

To power on, press and hold the center button for 3s. A voice assistant will tell you the current battery status. Pairing mode will automatically be initiated, indicated by the LED blinking slowly. Go to Bluetooth® settings on your device and select "JAYS a-Six Wireless". The blinking LED will turn off upon a successful connection followed by a short audio beep.

To power off, press and hold the center button for 3s.

Reconnecting and additional pairing

Next time you power on, the earphones will automatically try to reconnect to the most recently used device. If not found, or if you manually disconnect through your device, pairing mode will automatically be initiated again. To force pairing mode, press center button for 5s from off state.

Battery status and charging

When on, press and hold the down-button 2s for voice assistant battery status.

Battery high: 70-100% remaining

Battery medium: 30-70% remaining

Battery low: 0-30% remaining

When battery is below 3%, "Battery low" will be announced automatically.

Charge using a USB cable and connect it to any certified USB power output. Charging is indicated by a solid red light, and a full charge is indicated by a solid white light.

Troubleshooting

Problem pairing and connecting

- Make sure the earphones are not connected to another device.
- Disable and enable Bluetooth on your device.
- Move the earphones closer to the device or alter their positions to avoid Bluetooth interference.
- Verify no other wireless equipment interfere with your earphone Bluetooth signal.

Problem with sound transmission

Move the streaming device to another position. Your body, distance, different materials and other wireless equipment can interfere with the wireless signal between your device and earphone.

Legal & Warranty

Environmental information

This product complies with international directives, including but not limited to WEEE Directive (2012/19/EU). Do not dispose with normal household waste. Please consult your local waste disposal authority for guidance on how to properly recycle or dispose of this product.

Manufacturer's limited warranty

Your original Jays AB product is covered by a warranty of twelve (12) months from the date of purchase of a brand new, unused Jays AB product by the original purchaser. Jays AB guarantees that the product is free from faults in the materials, design and workmanship when it was sold to the purchaser. If you are not able to submit the receipt when making a warranty claim you may be obliged to pay for any repairs carried out. Proof of purchase must clearly state the date of purchase, name of the product and authorized resellers' details. For Australian customers, please visit www.jaysheadphones.com for full warranty terms.

Limited warranty period

The product may include different parts and they may have different Warranty Periods. The different Warranty Periods for this product are:

- Twelve (12) months warranty on the product and included accessories

The Warranty Period cannot be extended or renewed due to subsequent resale or replacement of the product. This Limited Warranty does not affect your legal rights under your applicable national laws relating to the sale of consumer electronic products. Defective parts replaced within the Limited Warranty Claim shall become the property of Jays AB.

What is not covered by the limited warranty?

- Faults caused by wear and tear, accident, dropping, mechanical damage, moisture, chemical products, abnormal impact damage or force majeure.
- Modification or repair by yourself or third party without Jays AB approval.

How to get warranty service

If you wish to make a Warranty Claim within the Limited Warranty Period, please contact the reseller of your product for further help. You will need to provide the proof of purchase and the affected part. Any defective parts covered by the Limited Warranty will be repaired or replaced free of charge. Replaced or repaired parts provided during the Warranty Period will be warranted for the remainder of the original Warranty Period or for sixty (60) days from the date of repair or replacement, whichever is longer. For FAQ please visit www.jaysheadphones.com.



JAYS AB
Äsögatan 121, 116 24 Stockholm, Sweden

www.jaysheadphones.com

 [@jaysheadphones](https://www.instagram.com/jaysheadphones)  facebook.com/jays  [@jaysheadphones](https://www.twitter.com/jaysheadphones)

Version 1.0 | Please visit www.jaysheadphones.com/A6-manual for latest manual version.