
dodocool Instruction Manual

DA151

Overview



ΕN

- 1 LED
- 2 Multifunction button
- 3 DCIN
- 4 LINE
- MIC
- 6 VOL+
- VOL-
- 8 Previous track
- 9 Next track

How to use

Turn on	Press and hold the multifunction button until the blue light is on.	
Turn off	Press and hold the multifunction button until the red light is on.	
Pair the earphone	When the power is off, press and hold the multifunction button for about 6 seconds until the red and blue lights flash alternatively.	
Adjust the volume	Press the volume up button to increase the volume. Press the volume down button to decrease the volume.	
Adjust the track	Press the next track button to next track. Press the previous track button to previous track.	
Play/Pause	Press the multifunction button once to play/pause the track.	
Answer/End a call	Press the multifunction button once to answer/end a call.	
Reject a call	Long press the multifunction button for 2 seconds to reject a call.	
Mute the microphone	Press the volume up and volume down button simultaneously to mute or recover the microphone.	
Redial the last number	Double press the multifunction button to redial the last number.	
Battery status	Press the volume up/down button to check the battery status when the earphone is standby.	

3

LED indicator

Charging	The red light will be on when the earphone is charging. The blue light will be on when the charging is completed.	
Connected	The blue light will flash slowly when the earphone is connected.	
Unconnected	The blue light will flash quickly when the earphone is unconnected.	
Pairing	The red and blue lights will flash alternatively when pairing.	
Low-battery warning	The red light will flash when the battery is low.	


To enjoy more functions of this earphone, please download "EQPlus" app from App Store or Google Play.

Download on the

App Store


Connect to the earphone via Bluetooth

 Press down the power button for about 6 seconds. When the LED light flashes in blue and red alternatively, the earphone is ready for pairing.



 On your phone, go to "Settings", then "Bluetooth" (make sure the Bluetooth function is on) to find "dodocool-DA151" and press it to connect the earphone.

Google Play



Specifications			
Wireless chip	CSR8670		
Wireless version	V5.0		
Wireless profile	HFP, HSP, A2DP, AVRCP, ATPX-LL, PBAP, SPP, MAP, BLE		
Frequency response	20 Hz - 40 kHz		
Output S.P.L	98 ± 3dB (IEC-318,1000Hz/1mW)		
Normal impedance	32Ω ± 15%		
Rated power	20mW		
Maximum power	30mW		
Working hours	Approx. 20h		
Operating ambient temperature	-5 ~ 40°C		
Nonoperating temperature	-20 ~ 70°C		
Transmission distance	Approx. 10m		

FCC Notice

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- —Increase the separation between the equipment and receiver.
- —Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- —Consult the dealer or an experienced radio/TV technician for help.

WARNING: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC rules. Operation is subject to the following two conditions: 1) this device may not cause harmful interference, and 2) this device must accept any interference received, including interference that may cause undesired operation.