User manual Model:SK1



Use of the HomeKit logo means that an electronic accessory has been designed to connect specifically to iPod, Phone, or iPad, respectively, and has been certified by the developer to meet Apple performance standards. Apple is not responsible for the operation of this device or its compliance with safety and regulatory standards. Please note that the use of this accessory with iPod, iPhone, or iPad may affect wireless performance.

Controlling HomeKit-enabled accessories away from home requires an Apple TV (3rd generation or later) with Apple TV software 7.0 or later and an iPhone, iPad or iPod touch with iOS 8.1 or later.

Operation is Subject to the Following Two Conditions:

This device complies with Industry Canada license-exempt RSS standard(s). Operation is subject to the following two conditions: (1) This device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

Cet appareil est conforme avec Industrie Canada exempts de licence standard RSS(s). Son fonctionnement est soumis aux deux conditions suivantes: (1) Cet appareil ne doit pas provoquer d'interférences et (2) cet appareil doit accepter toute interférence, y compris celles pouvant causer un mauvais fonctionnement de l'appareil.






QUICK START GUIDE

- 1. Twist a light bulb into the Smart Socket and ensure the socket is connected correctly. The LED will flash in green light when it is ready for network setup.
- 2. Make sure your iPhone or iPad (iOS 8.1 or later) is connected to your Wi-Fi network.
- 3. Download and launch the free Koogeek Home app from the App Store. (Apple: iOS 8.1 or later)
- 4. Log in or sign up for a Koogeek account.
- 5. Tap "Add Device" and follow the on-screen directions to complete network setup. Note: To add more sockets (or repeat the socket setup process), tap the "Device" icon and then tap "Add Device".
- When prompted, scan the Setup Code or manually enter the Setup Code, and then follow the step to add the device to the Home and Room.



- 7. You can assign a name to your device and use this name when speaking to Siri. For example, you can name your device "Printer", then launch Siri and speak "Turn on the Printer".
- 8. Set up customized Scenes to control multiple devices with a single command. For example, if you assign the "I'm going to bed" command to the Scene of turning off bedroom light and turning on the night light. When you speak "I'm going to bed" to Siri, everything will be done.

Socket OVERVIEW





Butto

Press once to manually control the switch (Turning socket "On" or "Off")

Restore factory settings: Press and hold the button for about 10 seconds until the LED turns red. When the LED blinks green, it indicates that you have restored the device to factory settings.



Power / Wi-Fi Status Indicator (after setting up)

- · Flashing green: Smart Socket is waiting for a Wi-Fi network configuration
- · Flashing red: Smart Socket is disconnected from a Wi-Fi network
- · Solid green: Smart Socket is "On"
- · Light off: Smart Socket is "Off"

Electrical Ratings

90-250V AC, 50 / 60Hz 25W

E26 / E27 LED / CFL General use

Safety Warnings

Screw directly into a light fixture
For indoor use only

·Turn off power before inspection, installation and removal

Keep children away from Smart Socket
DO NOT clean with liquid

DO NOT remove ground pin (middle pin)

· DO NOT use in wet or damp areas

DO NOT exceed the recommended electrical ratings
DO NOT use in precision timing applications where inaccurate timing could be dangerous (sunlamps, saunas, etc.)

· DO NOT use with devices that should not be operated unattended

· DO NOT touch inside the socket

CE Maintenance

1.EUT Operating temperature range: -10° C to 40° C.

Declaration of Conformity

MEI HUA ELECTRONICS (HUIZHOU) LIMITED hereby declares that this Koogeek Socket is in compliance with the essential requirements and other relevant provisions of Directive 1999/5/EC

C€0700

FCC Caution

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- -Reorient or relocate the receiving antenna.
- -Increase the separation between the equipment and receiver.
- -Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- -Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.