
无线蓝牙耳机



使用说明书

产品示意图



·DS 20262 蓝牙耳机主机 ·DS 20262 耳机充电盒 •Micro 5pin 充电线 •备用大、小耳帽 •使用说明书

产品规格

- •产品型号: Ds 20 26 2 •
- 蓝牙版本: V5.3 •电池规格: 耳机3.7V 30mAh; 充电仓3.7V 200mAh
- •支持模式: HFP/HSP/ A2DP/AVRCP •灵敏度: 105dB±3dBS.P.Lat1KHz • 信号距离· 10米 (无任何较大障碍物的理想环境中)
- ·播放时间。 约2.5 小时
- 诵话时间 . 约3 小时
- · 在由企会互机在由次数· 约2.5次

功能操作说明

将耳机从充电仓拿出自动开机或长按左右耳机多功能键3秒开机。

将耳机放入充电仓自动关机/长按左右耳机多功能键5秒关机。

当配对成功后,第二次开机时蓝牙耳机优先进入回连状态自动回 连已连接过的手机。

在待机状态下,单击左右耳机多功能键均可直接播放音乐,播放 时单击左右耳机多功能键均可暂停播放。

5、切换歌曲

權於音乐时长按左耳机多功能鍵2秒同时响"嘀"一声切换到上一曲。 长桉右耳机名功能键2秒同时响"嘀"一声切换到下一曲。

双击左耳机多功能键逐级加大音量,双击右耳机多功能键逐级减

7、来电接听

手机来电时,单击左右耳机多功能键均可接听电话。

手机通话时, 单击左右耳机多功能键均可挂断电话。

9、来电拒接 手机来电时,长按左右耳机多功能键2秒均可拒接来电。

10、末号重拨 在待机或者播放音乐时,三击左耳机多功能键即可拨打您通话记 录中最后一个拨打讨的电话。

11、启动语音助手

三击右耳机多功能鍵即可启动语音助手进行语音控制手机操作。

当蓝牙耳机电池电量不足时,间隔30秒播放一次电量不足提示音 直至耳机低电关机。

配对方式

普通配对方式

- 1.从充电仓取出或者同时长按左、右耳机多功能键3秒开机。 直至红蓝灯交替闪烁。进入对耳搜索配对状态。进入对耳自动 配对, 配对成功后丰耳(右耳)持续红蓝灯交替闪烁, 副耳为 **芷灯慢闪**。同时播放对耳配对成功提示音。
- 2.启动手机或者其它设备的蓝牙功能,如果是安卓系统手机或 者设备请点击手机"搜寻蓝牙设备"选项,如果是IOS系统的 手机或者设备则会自动搜索设备; 当搜寻到该蓝牙耳机的型号 后,点击进入配对;当配对成功后,主(右)耳机会发出连接 成功的提示音。左右耳机指示灯变为蓝灯慢闪。进入连接待机 状态,配对成功后主耳为右声道,副耳为左声道。

3.两只耳机也可单独与手机进行配对使用,操作方法可按上步 骤 2 操作手法进行操作。

充电操作

1.将Micro USB充电线一头插上充电盒的USB口一头插上充电器 即可给充电盒充电、当充电盒电量在对应指示灯的指示范围时。 该位置的白色指示灯间隔2秒闪一次,直至该指示灯的电量范围 充满后则长亮进入下一电量范围的指示灯闪烁。全部充满电后所 有指示灯长亮。

2.给耳机充电: 将耳机放入充电仓即可自动充电, 充电时耳机 指示灯为红色,充满电后熄灭;充电仓白色指示灯长亮(充电 仓满电时,4个电量指示灯全亮,当充电仓电量下降达到相应电 量时,对应的指示灯则熄灭),当耳机充满电后充电仓白色指 示灯全部熄灭。

注意事项

- 1.请在安全的环境下充电。在给充电仓充电时当充电指 示灯指示满电后请尽快将充电分与USB充电线分开。以 免在长时间插着充电对充电仓造成损伤。
- 2.在音乐播放时, 请将音乐调至合适音量大小, 以免长 期在大音量状态下对听力造成损伤。
- 3.尽量避免在有干扰源的地方使用本耳机,否则有可能 对耳机信号产生影响。
- 4.尽量避免在有腐蚀的环境中使用本耳机,以免对耳机 的功能产生影响。


温馨提示:在您使用本蓝牙耳机听音乐或者通话时, 请注意 适当调节音量大小,以免过大的音量对您的听力造成影响!

Disney TWS



User's manual

Product schematic diagram



Package list

- Wireless earphone
- Endurance charging box
- · Micro 5pin charging cable
- User's manual
- Earplug silicone cap

Product specifications

- •Product number: Ds 20 26 2 Wireless version: V5.3
- •B attery specification: Headset 3.7V/30mAh; Charging box 3.7V/200mAh
- · Supportmode: HFP/HSP/ A2DP/AVRCP
- Sensitivity: 105dB ± 3dB S.P.L at 1KHz •Transmission distance: 10 meters (in an ideal environment withoutany
- major obstacles) •Play time: About 2.5 hours
- •Call time: About 3 hours
- •Standby time: About 80 hours •Charging time: Chargethe charging compartment for about 1.5 hours,
- and chargethe headset forabout 1 hour Charging boxto chargethe headset; About 2.5 times

Functional operation instructions

Take the headset out of the charging compartment and automatically turn it on or press and hold the leftand right headset multifunction button for 3

2. Shutdown

Putthe headset into the charging compartment and turn it off automatically. Press and hold the leftand right headset multifunction button for 5 seconds

3. Bootback

When the pairing is successful, the Wireless headset preferentially enters the connected state when the second time is turned on, and automatically connects back to the connected mobile phone

In the standby mode, click the leftand right earphones multi-function

keys to play music directly. When play ing, click the leftand right earphones multi-function keysto pause play back

5. Switch songs

When playing music, press and hold the left earphone multi-function button for 2 secondswhile ringing "di" to switch to the previous song. Press and hold the right earphone multi-function button for 2 seconds while ringing "di" to switch to the nextsong

6. Volume addition and subtraction

Double-click the leftearphone multi-function key to increase the volume step by step, double-click the rightearphone multi-function key to gradually decrease the volume

7. Call answering

When the mobile phone calls, click the left and rightearphones multi– function button to answerthe call

8, Call hang up

When the phone is talking, click the leftand right earphones multifunction button to hang up the phone

9. Call rejection

When the mobile phone calls, long press the leftand right headphones multi-function button for 2 seconds to reject the call

While on standby orplaying music, you can dial the lastcall you made in yourcall history by tapping the left headset multifunction butto

11. Startvoice assistant

Three-click the right headset multi-function button to start Voice Assistant forvoice control mobile phoneoperation

12. Low battery prompt

When the battery of the Wireless headset is low, the low battery tone will beplay ed every 30 seconds until the headset is powered off

Pairing method

- 1. Take out from the charging bin or press and hold the left and right earphones multi-function button for 3 seconds to turn on until the red and blue lightsflash alternately, enterthe earsearch pairing state, enterthe ear pair automatic matching, and match the main ear (right ear) The red and blue lights are alternately flashing, the secondary ear is flashing slowly, and the paired ear is successfully play ed.
- 2.Startthe Wireless function of the mobile phone or other devices. If it is an Android mobile phone or device, please click the "Search for Wireless device" option. If it is the IOS system mobile phone or device, it will automatically search for the device; when searching for the model of the Bluetooth headset Afterthat, click to enterthe pairing; when the pairing is successful, the main (right) earphone will make a prompt to connect successfully, and the left and right earphones will turn blue and flash slowly, and enter the connection standby state. Afterthe pairing is successful, the main ear is the right channel. The secondary ear is the left channel.
- 3. The two earphones can also be paired with the mobile phone separately. The operation method can be operated according to the above step 2 operation method

Charging operation

1. Plug the Micro USB charging cable into the USB portof the charging compartmentand plug in the charger to charge the charging compartment When the charging power is within the indication range of the corresponding indicator light, thewhite indicator light of the position flashes once every 2 seconds until When the indicator's power range isfull, the indicatorlight

that is on forthe next power rangewill flash. When all the lights arefully charged, all the indicators will be on

2. Charging the headset: Putthe headset into the charging compartment to automatically charge. When charging the headset indicatoris red When the battery is fully charged, it will be off; the charging compartment white Indicator will be on. When the charging compartment is fully charged, the four battery indicator lights are all on. When the charging capacity drops to the corresponding power, the corresponding indicator light goes out. When the earphone is fully charged, the white light of the charging compartment is completely extinguished

- 1. Please charge in a safe environment. When charging the charging compartment, please chargethechargingcompartmentseparately from the USBcharging cable as soon asthe charging indicator indicates full power, so as to avoid damage to the charging compartment after a long
- 2. When playing music, please adjust the music to the appropriate volume to avoid hearing damage at high volume for a long time
- 3. Try to avoid using the headset in a placewith interference sources. otherwise it may affect the headphone signal
- 4. Try to avoid using this headset in a corrosive environment to avoid affecting the function of the headset.

Tips: When you usethis Wireless headset to listen to music or talk, please pay attention to adjust the volume properly, so as not to affect the hearing of excessive volume!

FCC STATEMENT:

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

Warning: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

Reorient or relocate the receiving antenna.

Increase the separation between the equipment and receiver.

Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

Consult the dealer or an experienced radio/TV technician for help.

RF warning statement:

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.