# USER GUIDE

CARFIT

Instructions overview

www.car.fit

## Connect

### Enable battery power

Pull the plastic tab out of the sensor.

### Activate Bluetooth

Turn your phone's Bluetooth ON.

### Reset connection

Press & hold the center for 10s to reset the CARFIT PULS sensor. Tap the button to turn it on.

### Bluetooth pairing

Ensure the CARFIT PULS sensor is in pairing mode with the center LED flashing.
Choose available sensor in the connection list and connect.

## Install

### Activate adhesive

Remove the protective tape from the bottom of the CARFIT PULS sensor.

### Position the CARFIT PULS sensor

Place the CARFIT PULS sensor on the top of the steering wheel hub with the lights facing the driver.
Ensure that the sensor is flat when the steering wheel is horizontal.

## Register & configure car

### Enter license plate or VIN

Enter your license plate if you are in the EU area.
Enter your VIN if you are in the US area.
Verify & add your car's details.

### Possible VIN locations

Drivers side door

Drivers side windshield

Car documents

## Support

### Need help or have questions?

support@car.fit

## App info

**CARFIT PULS sensor**
tracks your cars health

**Usage**
displays your recent drives

**Service**
displays alerts, schedule and history

**Car details**
view or edit your car's details

**Settings**
my cars (car details), sensors, my account, demo & more

**Date**
date of your most recent drive

**Time**
time of your most recent drive

**Distance**
distance of your most recent drive

**Smoothness**
how smooth your drive was relative to the average

**Highway**
time driven at highway speeds

**City**
time driven at city speeds

**Stop & Go**
time driven in stop and go conditions

**Graph**
drive profile graph

## Change battery

### Open the top of the sensor

To change the batteries you don't need to remove the sensor from the steering wheel.
Put your finger into the groove above the LED's and pull the lid up.

### Replace the CR2032 batteries

Use your finger from the side to lift the batteries out of their location.
When adding new batteries make sure they all have the positive side facing up before closing the lid.

### Closing the top of the sensor

To close the lid align it to the back first. Make sure the pin on the under-side of the lid fits into the groove in the bottom. Then push down on the lid and close it. It will snap shut.

## Battery info

### 3 pcs CR2032 coin cell battery

The sensor is optimized for using three CR2032 battery. Always place the batteries with the positive side up. Do not use other batteries to prevent damage to the sensor.

# USER GUIDE

Information

www.car.fit

## CARFIT APP

**iOS & Android**

iPhone: iOS 9 or later is required

Android: Galaxy S4 or later

## CARFIT PULS SENSOR

**SENSOR**

- Vibration sensor
- 3x CR2032 batteries
- 2 year battery life
- completely automated
- turns on when the car is started
- hibernation mode when inactive




STEERING WHEEL | SHOCK ABSORBERS | BRAKES | WHEELS | TIRES | OVERALL STATE

**Groove to open the sensor**

pulling here opens the sensor to change the batteries

**Button**

requests an autoservice call

**LED indicator**

5 LED's to show the status

**3M adhesive tape**

adhesive tape at the bottom of the sensor to secure it on the steering wheel

## Sensor usage

The CARFIT PULS sensor is easy to install. Simply stick it with the included double sided tape onto your steering wheel.

The CARFIT APP seamlessly connects with your sensor which analyzes your drives completely automatically. There is no direct interaction necessary. Battery life lasts up to 1 years. As soon as you start your car the sensor wakes up and starts recording.

If an issue occurs the sensor will identify it and the CARFIT APP companion will send you a notification.