

90mm



Audio Chatpad




For use with
Xbox One™ X / S & Elite

USER MANUAL

EN

Package Contents:

- Wireless Chatpad x 1
- Wireless Dongle x 1
- User Manual x 1



Wireless Dongle


Specification:

- 2.4G wireless keyboard easily connects to the Xbox One Console
- Enables most wired stereo headsets to work with your Xbox One Controller.
- Easily adjust audio without taking your hands off the controller.
- Controls include volume up/down, microphone mute, and speaker mute.
- Connects to the bottom of the Xbox One Wireless Controller and features a 3.5mm audio jack for your wired headset to plug into.
- Microphone mute, and speaker mute LED indication.
- Powered by the controller.


Setting up the Chatpad:

1. Following this illustration, line up the connector of the chatpad with the rectangular expansion port at the bottom of the Xbox One Controller.

If connecting the Chatpad to the original Xbox One Controller (without 3.5mm audio port), Fold the 3.5mm Audio connector into the Chatpad before installing.






If connecting to the updated Xbox One Controllers (with 3.5mm audio port), take the 3.5mm audio connector out of the Chatpad before installing, as shown below.



2. Carefully insert the expansion port and 3.5mm audio connector (if required) to the expansion port and audio port of Xbox One Controller.

Removal from the Xbox One Controller:


1. Please following this illustration carefully: Gently lift the bottom of the Chatpad in the direction shown (up).
2. While lifting up, gently pull the chatpad out from the Xbox One controller at the same time.




Pairing the Chatpad to the Console:

1. Insert the wireless dongle in to the USB port of the Xbox One console.
2. Switch the ON/OFF switch to the ON position. The LED on the Chatpad will start flashing quickly and begin automatically searching for the wireless dongle. Once successfully connected, the LED will stop flashing.

Keyboard Function:


1. After successfully connecting to the console, the Chatpad will input as a standard keyboard.
2. Simply press each button to input the lowercase letters.
3. Holding the Shift button, and then pressing a letter will input capital letters.
4. Press the Function button  once, the function button LED will turn ON, the Chatpad will then input the numbers and symbols (shown at the top left of each button). Press the Function button again to turn it OFF.



Audio Function:

PLEASE NOTE: Audio functions only compatible with Official Xbox One controllers with the 3.5mm audio port.

1. Connect your headset (4pin 3.5mm connector) to the audio port of the Chatpad. (The microphone function will be not work If the headset only has a 3pin connector).
2. Make sure the Chatpad is switched ON.
3. Use the Volume UP/DOWN buttons to adjust the output volume.



Precaution and maintenance:

- Store in a cool, dry & dust free area.
- Do not store in areas of extreme low temperatures (0°C) or high (40°C).
- Avoid direct sunlight and heat sources.
- Do not allow the product to get wet or dirty; doing so may cause damage.
- Do not clean with benzene, paint thinner, acetone, alcohol or other solvents.
- Do not take the product apart; doing so will void your warranty and may cause electrical shock or damage to internal components.
- Please help to conserve the enviroment by recycling the cardboard packaging of this product.
- This product should NOT be disposed of in normal household waste it should be disposed of separately. Please take it to an electrical waste collection point.



This device complies with part 15 of the FCC Rules.

Operation is subject to the following two conditions:
(1) This device may not cause harmful interference, and
(2) this device must accept any interference received, including interference that may cause undesired operation.

Warning: Changes or modifications to this unit not expressly approved by the part responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/ TV technician for help.

FCC Radiation Exposure Statement
The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.