

Wireless voice multifunctional Air Mouse




VER: 1.0
Part No: 06718207101




VER: 1.0

◆ Product Diagram




◆ Quick Guide


1. Open the battery cover




2. Install the battery(AAA*2)



3. Take out the receiver, and then plug it in the USB interface of the device



4. Ready to work



◆ Special key instruction



Infrared key could learn from other infrared remote control button

- Steps:
1. Press and hold down one of the five infrared keys for 3 seconds, the LED will be on to indicate that it has entered in learning state.



2. Let the learnt remote controller's infrared focus on the original receiving infrared, keep the distance as close as 1 to 3cm and then pressing down the learnt button.



3. If the learning is completed with success, the LED will flash for 2 seconds and quit learning state.
4. The learning state will be ended if it has not detected any infrared signal within 10 seconds.

◆ Product Features

1. Air mouse+Infrared+Microphone.
2. USB2.0 receiver, plug and play.
3. Auto connect through 2.4g wireless.
4. 360° all-round use.
5. The receiver can be stored in the battery compartment to avoid missing if you don't use it for a long time.

◆ System Requirements

HID compatible device
Terminal with USB port
Window 2000 + Window XP
Windows Vista, Windows CE, Windows 7, Window 8
Linux(Debian-3.1, Redhat-9.0,Ubuntu-8.10, Fedora-7.0 tested)
Android OS (With standard USB interface)

◆ Specifications

- Receiver(dongle): Nano style
- Connection port : With USB2.0 above
- Transmission mode: GFSK 2.4GHz, up to 10 meters
- Transmission Power: Less than +4db
- Power supply: AAA * 2 battery
- Sleeping current class1: 53uA
- Operation voltage: 3V
- Operating current: <26mA
- Product Weight: 160g (Not Contains battery)
- Product Size: 162*20.5*21mm

	System Hibernation
	Last Track
	Play/Pause
	Next Track
	Open the player
	Voice input key: press down the voice input key when you want to use Mic and release it when you want to close the Mic function.
	Mute
	The cursor speed, It has slow, medium and fast 3 speed, the default is mid-speed.
	Cursor on/off key, the air mouse is on by default. It is a toggle key, one pressing will stop the air mouse and the other pressing will stop using the air mouse.

	Home
	Menu
	Email
	Volume +/-
	Page UP&Page Dn
	Backspace
	Scroll wheel

◆ Scroll key Operation

The key scrolls up and down for the mouse wheel function,when pressing it, it is the OK button.

◆ LED Indicator

There is a blue light indicator on the remote controller. It will be always on if the connection is normal.

1. The light will flashes once when any key pressed.
2. When the remote control is not connected to the receiver, this light will flash at a lower rate.
3. The remote light will flashes at a higher rate when the remote control is at battery low.Please replace the battery in time.

Scroll wheel

This new design can help you scroll through long documents or web pages faster and easier, same as using your mouse.

Sleep

The Remote controller will enter into sleep (low power consumption) mode if there is no operation in 3 minutes. It will wake up and operate again once there is any operation with any key on the remote controller.

Note

It can work on Amazon Fire TV with an App-app2 file on android. You can install any App to fire TV .

◆ FAQ

Q1: The cursor is out of control or randomly moving around.

A: Put the remote control on the desktop, and wait for 5 seconds before use.

Q2: The indicator light is flashing, but the remote control works well.

A: This state is the battery low state, please replace the battery with new battery.

Q3: The indicator light is flashing, but the remote control can not control anything on the device.

A1: Check if the receiver is plugged in firmly, you can replug in the receiver again to see if it can recover to work again. If no, please do step A2.

A2: Place the remote control very close to the receiver, then press the <Scroll key> and <OK> key at the same time to see if it can recover to work again.

Q4: The <OK> key does not work.

A: The <OK> key is an infrared function key. You need to let it learn before using it.

Please refer to the "Special key instruction" section.

◆ Maintenance:

- Do not attempt to disassemble the device or replace the rechargeable battery yourself.
- The battery will discharge when it is stored for a long time without operation.
- Use the specified charger. Disconnect the device when the battery is fully charged.
- Overcharging will shorten the battery life.

◆ Disposal:

Always dispose the used appliance at a recycling center. Do not dispose the used appliance together with the household waste.

Note:

Due to 2.4G wave technology adoption, the connection can be subject to interference from obstacles, like walls, metals, or other electronic devices.

Please keep the space between the keyboard and USB receiver free of obstacle.In line with the policy of continued development, the manufacturer reserves the right to amend The specifications without prior notification. The illustrations in the user manual are for reference only. Please operate according to the real design.

◆ FCC Notice

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE 1: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

NOTE 2: Any changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

FCC ID: 2AJU3RT718



THANKS FOR READING

FCC Warning

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE 1: Any changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.