


USER MANUAL



from your watch.





4 5 6 ×

1 2 3

. 0

SMART WATCH

Thank you for choosing the smart watch as your fitness transformation companion.

Allow this manual to guide you through the functioning of your smartwatch.

Please read it thoroughly before using your smart watch. Keep this manual for later use as well.



PACKAGE CONTAINS:

- · User Manual x1 · Warranty Card x1



CHARGING THE WATCH

The smart watch must be charged before initial use. It takes 2 hours to be fully

Connect and charge the watch according to the image at left, using a 5V/2A adapt er. Please note that the positive & negative

magnets on the charger need to be aligned correctly with the watch for the charger to connect correctly.




TURNING THE WATCH ON/OFF

To turn the watch on/off, press and hold side button for 3-5 seconds.

You can wake up the screen by lifting





To ensure connectivity throughout your journey, make sure the app is allowed to run in the background of your phone at all times.

iPhones will not prompt any information unless you complete Bluetooth



SYNCING YOUR SMARTWATCH TO THE APP

Data Synchronization:

- Open the app on your phone.
- Make sure your smart watch is connected; refer to "CONNECTING TO THE APP" section of this manual.
- Svnchronization will start automatically once you enter the app interface.

void data loss in the watch.

NAVIGATING THROUGH THE FUNCTIONS

Changing the dial interface

watch face for your smartwatch.

4 6 0

LOVE SPORTS

Pair your device

Changing the watch face using app Select Cloud Watch Faces on the app and select your preferred

Make sure your watch and phone are connected via Bluetooth. Do not exit the downloading interface until it displays 100% downloaded. It may take up to 60 secs to sync the watch face with the app.

Changing the watch face directly on the watch Swipe left on the main interface of your watch screen to enter the main menu -> Scroll down -> Select "watch faces" -> Tap on your preferred display.

Cycling, Climbing, Yoga, Basketball, Football, Badminton, Rope Skipping, and Swimming

to water. When your watch does get wet, wipe the surface with a soft cloth before using it. Make sure maximum depth of water is not more than 59" (1.5 m) and maximum time for exposure



Camera Control Mode

Click on the Remote Camera icon on your smart watch to shoot a photo with your

Note: turn the camera on from your app to use this feature.

Blood Oxygen Level Monitor

Wear the watch on your wrist, then click on the icon to start measurements. You can also view the data on the app.

not for medical purposes.



Tap on the icon to start the stopwatch



PRODUCT PARAMETERS:

Model	Love & Sports Smartwatch
Screen Type	1.4" HD Display
Battery Capacity	220 mAh
Net weight	32.6 g
Bluetooth version	Bluetooth® 5.1
Working temperature	32°F to 140°F (0°C to 60°C)
Charging time	about 2 hours
Working time	about 7 days
Maximum transmission power	7.5 dBm
Frequency band	2402-2480 MHz

Maintenance:

Regularly clean your wrist and the strap of the smartwatch, especially after sweating during exercise or being exposed to substances such as soap or detergent, which may get stuck on the other end of the product.

Do not wash the strap with a household deanser. Please use soapless detergent, rinse thoroughly and wipe with a piece of soft towel or napkin.

and then follow the above procedure.

Charging norms & Precautionary Guidelines: -1) Charger/Brick/Adapter 5V, 2A

Any other accessory can be paired up with the product as long as the specifications are as per above norms.

FCC Warning

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE 1: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- -Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- -Consult the dealer or an experienced radio/TV technician for help.

NOTE 2: Any changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Tap on this to reset watch data. Note: All data will be erased if watch is reset.



LOVE SPORTS

Power off



Tap on this to begin countdown.

Tap on this to switch your watch off.



TURNING THE WATCH ON/OFF

Swipe down for shortcut menu

phone, Music control, QR code, the About section and settings from the shortcut menu.

Swipe up to access all data

Swipe right to access all notifications

Call and Text Notifications

