
USER MANUAL

32166 Bluetooth Speaker and Earbud adapter with Clip



1 – LED indicator

2 - Vol +

3 - Mode

4 - Vol -

5 – Micro USB Input Port

6 – AUX Input Port

Product Specifications:

Bluetooth version: 4.2

Bluetooth profiles: HSP,HFP,ADP AND

AVRCP

Battery: lithium battery 110 MAH

Music playing time: 4 hours(earphone)/2.5

hours(speaker)

Talk time:3 hours(earphone)/1.5

hours(speaker)

Charging time: 2 hours

Input Voltage: 5V

Input Current: 25mA

(earphone)/50mA(speaker)

Skip and Voice prompt: Support

First Time Use:

(Fully charged before first time use)

Connect the provided charging cable to a power source and to the micro USB port on

the headphones.

The LED indicator light shows red when

charging and turns off when fully charged.

ON/OFF

Switch on - Press and hold Mode key until

Blue LED light will be blinking

Switch off – Press and hold Mode key until

Blue LED light disappeared

Wireless Set Up:

Press the Mode button, hold until the Blue

LED light is blinking

Using a Bluetooth enabled device, search the possible connections for "GC-20".

After selecting "GC-20" it will connect the device and the Bluetooth Receiver.

Audio Functions:

Once connected to a Bluetooth enabled device press the Mode button to play the selected audio.

Press Mode again to pause the audio.

If receiving a call via the Bluetooth connection, the audio will immediately pause, and will continue when the call is ended.

Long Press "Vol + " key – To play next song

Long Press "Vol – " key – To play previous song

Short Press "Vol + " key – To volume up

Short Press "Vol – " key – To volume down

Short Press "Mode" key – To pause/stop

Phone Functions:

Under connected mode when phone call comes in:

Long press the Mode key to reject

Short press the Mode key to answer

Short press the Mode key to end the call

Double press the Mode key to redial the

last number

SAFETY PRECAUTIONS:

WARNING-When using this product, basic precautions should always be followed, including the following:

- Read all the instructions before using the product.
- Never store or use this product in temperatures below 32°F(0°C) or above 115°F(45°C).
- The unit's full performance is achieved only after 2 or 3 completed charge and discharge cycles.
- To reduce the risk of injury, close supervision is necessary when the product is used near children.
- 5. Do not expose the device to moisture.
- Do not use the device in excess of its output rating. Overload outputs above rating may result in a risk of fire or injury.
- 7. Do not use the device if damaged or modified.
- Damaged or modified batteries may exhibit unpredictable behavior resulting in fire, explosion or risk of injury.
- Do not disassemble the device. Take it to a qualified service person when service or repair is required. Incorrect reassembly may result in a risk of fire or injury.

- 10. Do not expose the device to fire or excessive temperature. Exposure to fire or temperatures above 104°F may cause explosion.
- 11. Have servicing performed by a qualified repair person using only identical replacement pairs.
- 12. This will ensure that the safety of the product is maintained.

FCC Statement:

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment general uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular

installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

Reorient or relocate the receiving antenna.

Increase the separation between the equipment and receiver.

Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions (1) this device may not cause harmful interference, and (2)this device must accept any interference received, including interference that may cause undesired operation.