	Issue Department: Bedding Division	Date:	2022-03-25
	User manual	Author:	
		Edition:	1.0
		Page 1 of 7	

User manual of RF396E





Figure 1 button of remote

	Issue Department: Bedding Division	Date:	2022-03-25
	User manual	Author:	
		Edition:	1.0
		Page 2 of 7	

Item

1.1 Child Lock 1

Click the Child Lock button for 3 second to lock or unlock the remote.

1.2 Bed lamp 2

Click the bed lamp button to open or shut the light under the bed.

1.3 Antisnore 3

Click the Antisnore button, the bed moves to Antisnore position, press and hold Antisnore button for 5s, until backlight flashes, the control set the current position as Antisnore position

1.4 TV 4


Click the TV button, the bed moves to TV position, press and hold TV button for 5s, until backlight flashes, the control set the current position as TV position.

1.5 LUMBAR UP 5

Press and hold LUMBAR UP button, Lumbar actuator moves out, stop when released.

1.6 LUMBAR DOWN 6

Press and hold LUMBAR DOWN button, Lumbar actuator moves in, stop when released.

	Issue Department: Bedding Division	Date:	2022-03-25
	User manual	Author:	
		Edition:	1.0
		Page 3 of 7	

1.7 M1 7

Click the M1 button, the bed moves to M1 position, press and hold M1 button for 5s until backlight flashes, the control set the current position as M1 position

1.8 M2 8

Click the M2 button, the bed moves to M2 position, press and hold M2 button for 5s until backlight flashes, the control set the current position as M2 position

1.9 HEAD UP 9

Press and hold HEAD UP button, head actuator moves out, stop when released.

1.10 HEAD DOWN 10

Press and hold HEAD DOWN button, head actuator moves in, stop when released.

1.11 FOOT UP 11


Press and hold FOOT UP button, foot actuator moves out, stop when released.

1.12 FOOT DOWN 12

Press and hold FOOT DOWN button, foot actuator moves in, stop when released.

1.13 ZG 13

Click the ZG button, the bed moves to zeroG position, press and hold zeroG button for 5s,

	Issue Department: Bedding Division	Date:	2022-03-25
	User manual	Author:	
		Edition:	1.0
		Page 4 of 7	

until backlight flashes, the control set the current position as zeroG position

1.14 HEAD MASSAGE 14

Click the HEAD MASSAGE button, head message motor switches message intensity, message intensityswitches among 0-1-2-3;

1.15 MESSAGE model 15

Click the MESSAGE MODEL button to change the message model.

1.16 FOOT MASSAGE 16

Click the FOOT MASSAGE button, foot message motor switches message intensity, message intensityswitches among 0-1-2-3

1.17 FLAT 17


Click the FLAT button, the bed goes flat.


1.18 MESSAGE FREQUENT 28Hz

Click the 28Hz button to set the message frequent 28Hz.

1.19 MESSAGE FREQUENT 40Hz

Click the 28Hz button to set the message frequent 40Hz.

	Issue Department: Bedding Division	Date:	2022-03-25
	User manual	Author:	
		Edition:	1.0
Page 5 of 7			




1.20 S20

The two remote controls are synchronized wirelessly.

1.21 S21

Click the S21 button, the remote control will be paired with the control box.

	Issue Department: Bedding Division	Date:	2022-03-25
	User manual	Author:	
		Edition:	1.0
		Page 6 of 7	

Federal Communications Commission (FCC) Statement

You are cautioned that changes or modifications not expressly approved by the part responsible for compliance could void the user’s authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:


- 1) this device may not cause harmful interference, and
- 2) this device must accept any interference received, including interference that may cause undesired operation of the device.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

RF warning for Portable device:

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

	Issue Department: Bedding Division	Date:	2022-03-25
	User manual	Author:	
		Edition:	1.0
		Page 7 of 7	

Canada, Industry Canada (IC) Statement

This device complies with Industry Canada licence-exempt RSS standard(s).

Operation is subject to the following two conditions:

- (1) this device may not cause interference, and
- (2) this device must accept any interference, including interference that may cause undesired operation of the device.

Le present appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes:

- (1) l'appareil ne doit pas produire de brouillage, et
- (2) l'utilisateur de l'appareil doit accepter tout brouillage adioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

ISED RF exposure statement:

This equipment complies with ISED radiation exposure limits set forth for an uncontrolled environment. The device has been evaluated to meet general RF exposure requirement.

Le matériel est conforme aux limites de dose d'exposition aux rayonnements énoncés pour un autre environnement. ce dispositif a été évalué à satisfaire l'exigence générale de l'exposition aux rf.