



Mini self-timer anti-lost
Bluetooth speakers

- Thank you for purchasing our mini-self-timer anti-lost Bluetooth speakers.
- in order to make your product more in-depth understanding, please read this manual.

Specifications:

Model: EC101

Bluetooth name: EC101

Talking time: about 2H

Music playing time: about 2H

Self-timer: Support

Playback: Supported

Pause: Support

Anti-lost: support

Effective distance: 10 meters

Power charger: DC5V

Instructions

1. long press the power button, hear the boot sound, Bluetooth search the device, you can enjoy music after the success of connection.
2. Click the button to pause playback.
- 3.calls Click the button to answer, long press reject.
- 4.Turn on the camera and double-click the self-timer.
- 5.anti-lost function, when the Bluetooth distance beyond the effective distance, the device will issue a continuous prompt sound.

Frequently Asked Questions:

Indicator does not light:
Charge the device

Unable to search for devices:
Check if you have connected to other
devices, delete connected devices,
retry

Sound Cardon:
Make sure that your device is within
range of your phone

Package list: mini self-timer anti-lost
Bluetooth stereo * 1
Specifications * 1

FCC Caution:

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.