





	<b>Wireless Adapter Quick installation</b>	<b>Step 2 Driver Installation</b>	<b>Step 3 Wireless Connection</b>
	<p style="text-align: center;"><b>Step 1 Hardware connection</b></p> <p>Please insert the usb adapter directly into the computer's USB port.</p>  <p style="text-align: center;">802.11ax WiFiAdapter</p> <p>Note: When using the desktop PC, it is recommended to connect the rear interface of the computer chassis, the effect is better! (Most of the desktop computer's front USB interface is underpowered or unavailable)</p>	<p>Applicable system: Windows 7, 10, 11</p> <p>Installation Guide</p> <ol style="list-style-type: none"> <li>1. Please use the U disk to install the driver before use, the driver name is "Setup.exe" and follow the direction to finish the installation</li> <li>2. After the installation is completed, click to restart the computer</li> <li>3. After restarting the computer, connect to WiFi.</li> </ol> <p>Notice:</p> <ol style="list-style-type: none"> <li>1. The U disk cannot be recognized, or the file is damaged. Please log in to the website to get the installation package, URL: <a href="https://www.dropbox.com/s/k6n1ehtjmqiz6ea/X.rar?dl=0">https://www.dropbox.com/s/k6n1ehtjmqiz6ea/X.rar?dl=0</a></li> <li>2. If there is a computer firewall, or a virus is displayed, the anti-virus software does not recognize the driver software. Please turn off the antivirus software first and then start the installer</li> <li>3. If it cannot be used after installation: 1) Replace the USB port, or use the USB port on the back of the main computer; 2) After deleting all network card drivers, reinstall the drivers</li> </ol>	 <ol style="list-style-type: none"> <li>1. Click on the Wi-Fi icon on the taskbar;</li> <li>2. Select SSID connection.</li> </ol>

	<b>Adaptateur sans fil installation rapide</b>	<b>Etape 2 Installation du pilote</b>	<b>Etape 3 Connexion sans fil</b>
	<p style="text-align: center;"><b>Etape 1 Connexion matérielle</b></p> <p>Veillez insérer l'adaptateur USB directement dans le port USB de l'ordinateur</p>  <p style="text-align: center;">Adaptateur WiFi 802.11ax</p> <p>Remarque: Lorsque vous utilisez le PC de bureau, il est recommandé de connecter l'interface arrière du boîtier de l'ordinateur, l'effet est meilleur. (La plupart des interfaces USB en façade des ordinateurs de bureau sont sous-alimentées ou indisponibles).</p>	<p>Systeme applicable: Windows 7, 10, 11</p> <p>Guide d'installation</p> <ol style="list-style-type: none"> <li>1. Veillez utiliser le disque U pour installer le pilote avant utilisation, le nom du pilote est "Setup.exe" et suivez les instructions pour terminer l'installation.</li> <li>2. Une fois l'installation terminée, cliquez pour redémarrer l'ordinateur.</li> <li>3. Après avoir redémarré l'ordinateur, connectez-vous au WiFi.</li> </ol> <p>Remarques:</p> <ol style="list-style-type: none"> <li>1. Si le disque U ne peut pas être reconnu ou si le fichier est endommagé, veuillez vous connecter au site Web pour obtenir le package d'installation, URL: <a href="https://www.dropbox.com/s/k6n1ehtjmqiz6ea/X.rar?dl=0">https://www.dropbox.com/s/k6n1ehtjmqiz6ea/X.rar?dl=0</a></li> <li>2. Si l'ordinateur dispose d'un pare-feu ou affiche un virus et que le logiciel antivirus ne reconnaît pas le logiciel du pilote, veuillez d'abord désactiver le logiciel antivirus, puis lancer le programme d'installation.</li> <li>3. S'il ne peut pas être utilisé après l'installation: 1) Remplacez le port USB, ou utilisez le port USB à l'arrière de l'ordinateur principal; 2) Réinstallez le pilote après avoir supprimé tous les pilotes de la carte réseau.</li> </ol>	 <ol style="list-style-type: none"> <li>1. Cliquez sur l'icône Wi-Fi dans la barre des tâches.</li> <li>2. Sélectionnez la connexion SSID.</li> </ol>

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

The frequency stability of all transmission frequencies of U-NII-1 and U-NII -3 meets the 47 CFR FCC Part15.407(g) requirements, and the manufacturer states that their transmissions remain within the U-NII-1 and U-NII -3 bands.