

**Just
Wireless®**



08082

**BLUETOOTH® HEADSET
USERS MANUAL**



**BEFORE YOU BEGIN TO USE YOUR JUST WIRELESS®
BLUETOOTH® HEADSET, YOU MUST FULLY CHARGE AND PAIR
IT WITH YOUR MOBILE PHONE. PLEASE READ THE ENCLOSED
USERS MANUAL FOR EASY PAIRING INSTRUCTIONS.
SHOULD YOU NEED ASSISTANCE, PLEASE CALL 888-753-6957.**

INTRODUCTION

Thank you for purchasing the Just Wireless Bluetooth® Headset. We hope you enjoy it. This manual will get you started and help you to get familiar with the features of your headset. For those individuals with the Bluetooth® Headset, in addition to all the other features, the unit supports a multipoint function to allow simultaneous connection of the Bluetooth® Headset with 2 mobile phones. Music play function headset allows the user to play / hear / listen to music and control the music player.

ABOUT YOUR JUST WIRELESS BLUETOOTH® HEADSET

Your Just Wireless® Bluetooth® Headset lets you do the following functions, provided your mobile phone can support it:

- Making a call
- Ending a call
- Answering calls
- Adjusting Volume
- Pause / play music
- Next track / previous track control
- Call Waiting
- Rejecting a call



FEATURE DIAGRAM

1 LED Indicator Light

- a) Blue mode indicates active/standby.
- 1 Consecutive Flash: Your Bluetooth® Headset is connected to your mobile phone.
- b) Red mode indicates battery level.
- Flashing Red - Indicates low battery level.
 - Solid Red - Indicates your Bluetooth® Headset is being charged.
 - Light Off - The battery is fully charged.
- c) Blue/Red Flashing Mode
- Your Bluetooth® Headset is in pairing mode

2 Volume Higher +

3 Volume Lower -

4 Charging Port

5 Microphone

6 Adjustable Ear Hook


7 Earphone

GETTING STARTED

CHARGING YOUR HEADSET

Your Just Wireless® Bluetooth® Headset comes with a built in rechargeable battery, and must be fully charged before using. Use the supplied USB Cable to charge your headset by plugging it into the charging jack shown below.

- The red LED light will flash when you have a low battery level. It is suggested to charge the headset at this time.
- The red light will illuminate solid red during charging and will turn off when fully charged. It will take approximately 1-2 hours to charge.
- Your headset cannot be used while charging.



TURNING THE HEADSET ON AND OFF

ON Mode: Press and hold down the Main Button for 3 seconds. Your headset voice prompt will say "Power On" and the blue LED light will flash 1 time. Now your headset is on. Red / blue flashing means your Bluetooth is now in pairing mode.

OFF Mode: Press and hold down the Main Button for 3 seconds. Your headset will sound a tone and the solid red LED light will turn on. Now your headset is off.

Reset: In power off status, press and hold the power button for 10 seconds until your headphone powers off again.

Reconnect: In power off status, press and hold the power button for 3 seconds until LED flashes red / blue alternately. Your headphone will be connected with the last paired device automatically. If reconnect fails, 5 seconds later will enter pairing mode again automatically.

PAIRING AND CONNECTING YOUR HEADSET TO YOUR MOBILE PHONE

Pairing is a process of linking the Bluetooth® Headset with your mobile phone. Before using your Bluetooth® Headset, you must successfully pair it to your mobile phone. Your mobile phone must be Bluetooth® compatible. If it is not, you will not be able to pair the headset to your mobile phone. Check the users manual of your mobile phone to see if it is Bluetooth® compatible. Your mobile phone and headset should not be more than 3 feet in distance when pairing.

Step 1 - Setting the headset into pairing mode: In the OFF mode, press and hold down the Main Button for 3 seconds, until you see the LED light consecutively flashing blue and red. Your Bluetooth® Headset is now in pairing mode.

Step 2 - Setting the mobile phone into pairing or “discover” mode: Follow your mobile phone’s instruction manual. Although it is different on all types of mobile phone brands and models, it usually involves going to the “set up”, “connect” or “Bluetooth®” menu on your mobile phone, and selecting the option “discover” or “add” a Bluetooth® device.

Step 3 - Completing the pairing: Your mobile phone will search for your Bluetooth® Headset. The LED indicator light must continue to consecutively flash blue and red while your mobile phone is searching for your Bluetooth® Headset. If it isn't flashing blue/red repeat step 1 above. When your mobile phone finds Bluetooth® Headset, you will need to accept your Bluetooth® Headset by pressing "Pair", "Yes" or "OK" on your mobile phone and then confirm using the **passkey or PIN number 0000**. The headset and mobile phone are now paired and the LED light on the headset will now flash blue 2 times consecutively and beep twice. You will only have to pair your Bluetooth® Headset to your mobile phone once. After this process has been completed you can use the Bluetooth® Headset only with its paired mobile phone. Repeat steps 1-3 if pairing was unsuccessful.

Step 4 - Connecting: Most phones require an additional step to “connect” to a Bluetooth® Headset. Follow the instructions in your mobile phone users manual. Once connected, your Bluetooth® Headset blue LED light will flash.

If either the Bluetooth® Headset unit or your mobile phone is turned off, most mobile phones will allow you to automatically connect back to your Bluetooth® Headset once your headset or mobile phone is turned back on. However with some mobile phones, you will need to manually reconnect. Your mobile phone’s users manual will guide you through these set up instructions.

Step 5 - Pairing and Connecting to a Second Phone: For those individuals with the Bluetooth® Headset, it supports a multipoint function to allow simultaneous connection of the headset with 2 mobile phones. Once you have paired and connected your Bluetooth® Headset to the 1st mobile phone, as per the instructions above in steps 1-4, then close Bluetooth® on 1st mobile phone, open Bluetooth® on 2nd mobile phone and repeat instructions in steps 1-4. After paired, reopen 1st mobile phone. The headset will then be connected to 2 mobile phones.

Please note that if the Bluetooth® Headset is connected with 2 mobile phones and there is an incoming or outgoing phone call on either phone, the audio play (music) will temporarily pause with the headset. Once the call is finished, music play can be resumed using phone functions.

HOW TO USE THE FEATURES

ANSWERING CALLS

- Tap the Main Button of your headset to answer an incoming call.

MAKING CALLS


- When you make a call from your mobile phone, the call will automatically transfer to your headset.

ADJUSTING VOLUME

- Pressing the Volume Higher (+) button increases the speaker volume of the headset.
- Pressing the Volume Lower (–) button decreases the speaker volume of the headset.

MUSIC CONTROLS

- Click main button to play / pause
- Click volume up / down to adjust volume levels
- Press and hold volume down to go back to previous track
- Press and hold volume up to go to next track



CALL WAITING

- Your headset will indicate that there is an incoming call by beeping. To reject the incoming call, press and hold main button for 1 second.
- Utilize your phone function to accept / reject second call and switch back and forth between two calls

REJECTING A CALL

- Press and hold down the main button of your Bluetooth® headset for approximately 1 second and then release the main button. Depending on your mobile phone settings, the call will either go to voice mail or the person calling will hear a busy signal.

ENDING A CALL

- Tap the main button to your headset to end an active call.

RIGHT OR LEFT EAR FITTING

- The Just Wireless® Bluetooth® Headset is ready to wear on your right ear.
If you prefer to use it on your left ear, rotate the ear hook to the other side of the headset.

TROUBLESHOOTING

■ I cannot turn on my ear buds

- Ensure earbuds are fully charged before turning it on.

■ My mobile device is unable to find the Bluetooth earbuds

- Make sure that the earbuds are in pairing mode (blue/red indicator light flashing).
- Remove "Just Wireless BT" from Bluetooth setting list and set up again.
- If still no search found, please restart the headset and phone, and try again.

■ After successfully pairing, earbuds disconnect

- Check the battery level and recharge if low.
- Ensure earbuds are within 30ft of mobile device and free of disruptions.
- The connection may be affected by obstructions such as walls or other electronic devices. Try to move closer to the device you are connected to.

■ **When answering a call, I cannot hear anything**

- Ensure the mobile device is connected to earbuds and not on speakerphone mode.
- Increase the volume on your mobile device.

■ **There is no sound when listening to music**

- Increase the volume on your mobile device.
- Reconnect the earbuds to your mobile device.
- Check if the app has paused or stopped playback.

■ **Earbuds will not charge**

- Check whether the charging cable is functional.
- Ensure the micro-USB charging cable is properly inserted in the earbuds and wall charger ports.
- Ensure the charging cable and wall charger are functional.

IF YOU NEED ADDITIONAL HELP

Call us toll free at 888-753-6957 and ask to speak to our technical assistance department.

Be sure to have the users manual for your mobile phone before calling.

STORING YOUR BLUETOOTH® HEADSET

- Always store your Just Wireless® Bluetooth® Headset with the power OFF and make sure it is safely protected.
- Avoid storage at high temperatures (above 40°C/104°F) such as in a hot vehicle or in direct sunlight. (Storage at high temperatures can reduce performance and battery life)
- Keep the headset or any of its supplied parts from getting wet.

LIFETIME WARRANTY

Just Wireless will repair or replace this product if, due to defective parts or workmanship, it does not perform as specified. This warranty covers only repair or replacement of the product itself. This warranty is extended to the original consumer purchaser only. Specifically exempt from this warranty are limited-life consumable components subject to normal wear and tear, such as microphone windscreens, ear cushions, ear tips, decorative finishes, batteries, and other accessories. In no event does this warranty extend to instances where the product is damaged through uses for which it was not intended, misuse, mishandling, removal and/or reinstallation, neglect, accident or tampering. In no event shall **Just Wireless** be liable for any indirect, incidental or consequential damages, or lost profits arising out of or related to this product, or the performance or breach thereof, even if **Just Wireless** has been advised of the possibility thereof. **Just Wireless** liability to customer, if any, shall in no event exceed the total of the purchase price. Some states do not permit the exclusion or limitation of incidental or consequential damages, therefore, sections of the above limitation or exclusion may not apply to you. This warranty is in lieu of any other warranty, expressed or implied, including, but not limited to, any warranty of merchantability or fitness for any particular purpose. Any representations or promises inconsistent, or in addition to this warranty are unauthorized and shall not be binding upon **Just Wireless**. Please contact **Just Wireless** by phone at 888-753-6957 or by email info@justwirelessintl.com for return instructions.

Bluetooth® is a trademark owned by Bluetooth SIG, Inc.



Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy, and if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

SKU 08082 REV072020

©2020 Just Wireless. Bluetooth® and associated marks are each trademarks of independently owned and operated companies.