



**Pro True Wireless Earbuds  
User Manual**



**Earbud Use Mode - Automatic Pairing**

1. Tear off the charging insulation sticker behind the dual earbuds and put them back into the charging case to activate earbuds.

**Note:** If the headset is not in charging state, please use USB cable to charge the charging case.

2. Take out the two earbuds. Red and Blue LEDs will automatically be flashing. Earbuds will pair successfully after 3-5 seconds. You will then hear prompt tone "Connected." With the main ear flashing Red and Blue, open the phone's Bluetooth® search to find the pairing name: **Just Wireless**, then tap. When prompt tone "Connected" is heard, you can use your earbuds.

3. Every time you take out the earbuds from the charging case, the earbuds will reconnect automatically to your Bluetooth® devices.

**Earbud Use Mode - Manual Pairing**

1. Hold "Power On" button for 3 seconds (the two sides of the earbuds flash Blue and Red lights slowly). Earbuds will pair successfully after 3-5 seconds.

2. The prompt "Connected" will sound, and then main earbuds will flash Red and Blue. Open your phone Bluetooth® search on your device, find the pairing name: **Just Wireless**, and tap pairing. When prompt tone "Connected" is heard, you can use your earbuds.



**Operation**

**Power off / on**

Press & hold either side for 3 seconds, earbuds will state "Power off," or "Power on."

**Play/Pause**

Press either side to play or pause music.

**Answer/ End a call**

Press either side to answer/end a call.

**Reject a call**

Double click either side to reject a call.

**Music search - Play Mode Only**



**Double Click-Previous track**



**Double Click-Next track**

**Note** - some applications change these settings.



**Using Only One Earbud**

1. If either side of the earbuds is taken out of the charging case alone, it will automatically enter the pairing state. You can search directly in Bluetooth® interface of the mobile phone and tap to connect the device and enter the use. At this time, please put the other one back into the charging case.

2. When separately using one earbud, take it out of the charging case and press the "Power On" button for 3 seconds putting the earbud into pairing mode. You then can search **Just Wireless** in your phone Bluetooth® screen and tap to connect the device.



**How to charge the earbuds**

1. The earbuds are placed into the charging box and the indicator light will go on. Charging case light will go out when earbuds fully charged.

**2. Indicator lights state:**

Charge case battery up to 0-25%, Blue light flashes 1 bar

Charge case battery up to 25%- 50%, Blue light flashes 2 bars

Charge case battery up to 50%-75%, Blue light flashes 3 bars

Charge case battery up to 75%-100%, Blue light flashes 4 bars

**How to charge the charging case**

Use 5V charger to charge the Charging case. When fully charged, Blue light stays on.



**Please pay attention to signals when using earbuds:**

1. Your wearing method is important to avoid reception interruption. Please wear appropriately

2. Covering any earbud with your hand while wearing can lead to poor audio reception between earbuds.

3. Avoid obstacles between the earbuds. The right earbud needs to communicate with the left (main earbud) to work in binaural mode.

4. The R earbud may disconnect from the L earbud occasionally. Please wait a moment or change the position of the earbuds.

**Tips**

1. Please read the instructions carefully before using the product and keep them safe.

2. For the first time use, please charge this product.

3. If the product is not used for more than three months, please charge it.

4. If the phone cannot search Bluetooth, please make sure that the earbuds are in "pairing mode." If the earbuds are not paired or connected for a long time, the earbuds pairing function will be turned off. To solve, restart the phone. If earbuds have a program error, restart them.

5. When the main and secondary earbuds cannot be automatically connect, they can be in the shutdown state. Hold down the multi-function key on the earbud until the white light stays on. Keep them close to each other and wait for the connection to restore.

Bluetooth and associated product marks are the trademarks of an independently owned and operated company. This product has not been licensed by this company.

For Warranty information, please visit our website.

[www.justwireless.com](http://www.justwireless.com)

info@justwireless.com  
140 58th St, Brooklyn, NY 11220

© 2021 Just Wireless. Made In China.

SKU 20526  
REV062021-1

## FCC Warning

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

**Note:** This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- ▶ -Reorient or relocate the receiving antenna.
- ▶ -Increase the separation between the equipment and receiver.
- ▶ -Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- ▶ -Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.