




**USER MANUAL**  
MODEL : GC-T006

### Package Content:


- 1 x Wireless headphone
- 1 x USB charge cable
- 1 x User manual
- 1 x Audio cable



### Product Description:

1. Wireless version: 4.1
2. Model No: GC-T006
3. Battery: Rechargeable lithium 250mAh battery
4. Charge method: USB charge DC ~5v
5. Talk time: 11-12 hours
6. Play time: 11-12 hours
7. Stand by time: Up to 110 hours
8. Operating distance: Up to 33ft

### Product Schematic:



### Operating Instructions:

**Power on:** Hold the power button for 2 seconds to turn on; the LED indicator light will flash blue. A voice prompt will confirm you have "power on."

**Power off:** When the headphones are powered on, hold the power button for 3 seconds. The indicator light will flash blue before turning off. A voice prompt will state "power off" before powering off. When the headphones are left idle without being paired or connected, they will turn off automatically after 5 minutes.

**Pairing:** For the best pairing results, make sure your headphones and device are within 33ft of each other. When the headphones are on, hold the power button until the indicator light flashes red and blue to indicate it is in pairing mode. When the headphones are off, hold the power on button for 3 seconds until the indicator light flashes red and blue. A voice prompt will confirm the headphones are "pairing." Turn on the wireless feature on the device you would like to pair. Search for "GC-T006" on your wireless device to connect. A voice prompt will confirm you are "connected." If unsuccessful, repeat the steps. If issue persists, read through the "troubleshooting" section of this manual.

### Test Your Connection:

Put the headphones on and call a number on your connected device. If you hear a ring, you have successfully paired your device.

### Reconnect:

After initially pairing your headphones to your device, the device used will automatically connect when the headphones are turned on.

### Call Function:

**Answer a call:** Click the power button

**Ending a call:** Click the power button

**Rejecting a call:** Press and hold the power button for 2 seconds

**Redialing the last call number:** From standby state, double click the power button

### Music Functions:


**Play/pause:** Click the power button to play and pause music.

**Volume +/next track:** Click the + button to increase the volume. When you reach the maximum volume, a voice prompt will state you have reached the "maximum volume" and the indicator light will briefly flash blue. Press and hold the + button for about 1 second to go to the next track.

**Volume -/previous track:** Click the - button to decrease the volume. When you have reached the minimum volume, a voice prompt will confirm and the blue indicator light will briefly flash. Press and hold the - button for about 1 second to go to the previous track.

### Battery Life:

The indicator light will flash red to indicate the battery is low. A voice prompt will confirm "battery low." When the battery power is too low or less than 3.0v, the headphones will shut down automatically. When charging, the red indicator will be lit until the headphones are fully charged. The indicator light will turn blue once the headphones are fully charged.



### Troubleshooting:

1. Headphones won't power on: The battery is drained, charge the headphones for 30 minutes before attempting to power on again.
2. Phone can't find the headphones: Make sure any previously paired devices are turned off or are out of range. If the indicator light is not flashing red and blue, restart both the headphones and the device before attempting to pair again.
3. Headphones disconnect automatically when pairing: The battery is very low or the headphones are out of range.
4. No sound when a call is answered:
  - a. Make sure the phone is connected to your headphones but not another device.
  - b. Try to increase the volume on your headphones or on your phone.
  - c. Check to see if the wireless mode has been activated on your device.
  - d. Check to see if you have chosen the headphones mode on your phone
5. No sound when playing music: Try to increase the volume on your headphones or your device.
6. Will not charge: Make sure the charging cable is well connected. Charging cable may be damaged.
7. No sound when audio cable is plugged in: Try to increase the volume on the headphones or on the phone. Make sure the audio cable is connected. The audio cable may be damaged.

### FCC Warning:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.