CAMERA PLACEMENT

Install the camera in a location with strong, reliable Wi-Fi reception to ensure best streaming performance. You can easily check the Wi-Fi signal strength of the camera using the app. As a general rule, the nearer your camera is to your Wi-Fi router, the better the wireless connection quality.

Motion detection

The camera's PIR motion sensor detects heat signatures of moving objects. You'll generally get good detection results by pointing the camera downwards at an angle where people will be moving across the coverage area before heading directly towards the camera.

Mounting the camera

The camera can be mounted to a flat surface using screws. The surface must have sufficient strength to hold the camera. Materials such as hardwood, brick or masonry are good options. To mount the camera, simply follow the instructions in the supplied mounting template.

Adjusting the camera angle

Using the supplied L-wrench, loosen the appropriate hex screws on the stand of the camera to pan, tilt or rotate the camera. Remember to tighten the screws back securely to lock the camera's position in place after adjusting the angle.

HELP AND RESOURCES

Camera LED Indicator Guide

Slow Blinking Blue (& Blinking Infrared LEDs)	Wi-Fi Pairing mode
Solid Red	Live streaming / Motion recording
Blinking Purple	Out of Wi-Fi range

NEED HELP?

There's more information and support online for your product. Find latest guides, FAQs, customer support, and more, by visiting support.swann.com.

- **Product Registration**
- **Customer Support**
- **Product Guides**
- **Support Community**
- tech@swann.com

QSGWHDOUTCAMVER1E

Swann®

ENGLISH

SWWHD-OUTCAM

QUICK START GUIDE

CAMERA OVERVIEW



1. Wi-Fi Antenna
2. Camera Lens
3. Infrared LEDs (for night vision)
4. Microphone
5. Night Detection Sensor
6. Passive Infrared Motion Sensor
7. LED Indicator
8. Reset Button
9. Power Connector
10. Ethernet Connector (optional wired connection to your router; camera must be paired via Wi-Fi first)

ASSEMBLE ANTENNA & POWER UP

1. Bend the antenna 90° at the antenna joint, then using the ferruled nut, screw the antenna onto the gold antenna socket on the back of the camera until it is hand tight, as shown in Figure 1.
2. Connect the camera to the power adapter using the power & Ethernet cable, then plug the power adapter to a power outlet, as shown in Figure 2. Make sure the camera is within range of the Wi-Fi network to which you want to connect.



Figure 1: Attaching the antenna



Figure 2: Connecting to power

GET THE APP

Download and install the latest version of the SAFE by Swann app from the Apple App Store® or Google Play™ Store on your iOS or Android device. Simply search for "SAFE by Swann".

Download on the App Store

GET IT ON Google Play

FIRST TIME SETUP

Launch the SAFE by Swann app. Create an account or log in if you already have an account. Once logged in, tap the "+" Pair Camera icon on the screen and follow the prompts to pair your new camera.