






5. Push the left joystick up and the right joystick down at the same time, the Stunt Car is begins to rotate in a clockwise direction .



6. Push the left joystick down and the right joystick up at the same time, the Stunt Car is begins to rotate in a counter clockwise direction .



7. Push the left joystick down, the Stunt Car is turn left.Keep pushing the left joystick down, the Stunt Car is spin to left .



8. Push the right joystick down, the Stunt Car is turn right.Keep pushing the right joystick down, the Stunt Car is spin to right .

### AUTO DEMO

Press the "Demo" Button, the Stunt Car start to playing automatically.



USED FOR H835 & H837



**STORM  
BRAVE**

### WELCOME

Thanks for purchasing a Stunt Car, get ready to have the time of your life!  
Please take the time to read the following safety warnings and operating instructions carefully.

### CAUTION


- Please remove the battery from the Stunt Car and controller if you are not going to use it.
- Keep the toy away from direct heat.
- Do not pick up the Stunt Car in motion.
- Keep hands, hair and loose clothing away from tires when the Stunt Car is switched on.

### BATTERY SAFETY

- Keep batteries away from Children.
- Battery must be replaced by an adult.
- The battery is only to be charged under adult supervision, do not leave charging batteries unattended.
- Do not cover the batteries when charging. Do not leave batteries in direct sunlight.
- Do not leave a fully charged battery connected to charger; overcharging may shorten its lifetime.
- Do not dispose of battery in a fire as they may explode, battery may also exploded if damaged.
- Do not short-circuit the battery. Accidental short-circuiting can occur when a metallic object such as a coin, clip, or pen causes direct connection of the positive (+) and negative (-) terminals of the battery.

### OPERATION AND CONTROL

1. Push both joysticks up, the Stunt Car is go forward.
2. Push both joysticks down, the Stunt Car is go backward.
3. Push the left joystick up, the Stunt Car is turn right.Keep pushing the left joystick up, the Stunt Car is spin to right.
4. Push the right joystick up, the Stunt Car is turn left.Keep pushing the right joystick up, the Stunt Car is spin to left.




### CONTROLLER OVERVIEW

Insert one side of the USB connector into the battery and the other side into any computer USB port or compatible adapter.




### BATTERY CHARGING(Li-ion battery version)

Battery installation should be done under adult supervision only!  
Do not mix old and new batteries.  
Do not mix different types of batteries.



**• STUNT CAR**  
To install batteries: Open the cover of battery case, insert 2x1.5V AAA batteries, according to indicated polarity (Batteries not included).



**• CONTROLLER**  
Battery cover

### BATTERY INSTALLATION

- Clean the Stunt Car with clean, dry soft cloth only.
- To avoid irreparable damage, keep the Stunt Car dry and away from water.
- Check the Stunt Car and accessories for damage. If damage is found, do not use the Stunt Car until it is repaired.

### MAINTENANCE

- \*Always dispose of old batteries responsibly
- Note:
- 3.HELICUTE encourages you to participate in electronics recycling program.
- 2.Follow the local regulations and laws for proper disposal of discarded electronic products.
- 1.Do not place the product as household waste.

How to treat Waste Electrical Products

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.