文件名称: Plug Mini-SMS-EN-2110	⊠⊠:ZBH	完成⊠∷2021/11/04
版本号: Plug Mini-SMS-EN-2110	成品尺寸:42*70mm	
材⊠和工図: 図琴折 128G図版図		
更改内容:		
│ │ │ │ │ │ │ │ │ │ │ │ │ │ │ │ │ │ │		

# SwitchBot Plug Mini User Manual



# Package Contents

Plug Mini

User Manual

The graphics used in this manual

are for reference only. Due to the

future updates and improvements

of the product, the actual product

images may differ.

Status of LED

Indicator Lamp

White light on

White light off

flashes rapidly

flashes slowly

Blue light

Blue light


turned off

Blue light

turns off

lights up then

for more details.



Power Socket



# Specifications

Model No.: W1901400 Size: 70 x 39 x 59 mm (2.8 x 1.6 x 2.4 in) Weight: 70 g (2.5 oz) per plug Input Voltage: 100 - 125 V AC Input Frequency: 50/60 Hz Output Power: 1875 W Output Current: 15 A maximum Operating Temperature: -15 to 40 (5 to 104 ) Wireless Standard: IEEE 802.11 b/g/n, 2.4 GHz Wi-Fi, Bluetooth Low Energy

# Preparation

- A smartphone or tablet with Bluetooth 4.2 or above.
- Download the SwitchBot app on App Store or Google Play Store.
- Open SwitchBot app and register for a SwitchBot account or log in directly if you already have an account.
- (Optional) If you need to control SwitchBot Lock remotely, receive notifications or use third-party services, you must first set up SwitchBot Hub Mini.





# Safety Information

- Only for indoor use.
- Please keep this device dry and away from hot, humid, and/or other extreme environments as this may cause accidents such as fire, burn, injury, electric shock and so on. Never use when you are in contact
- with any kinds of liquid, as this may cause electric current damages and
- Do not attempt to disassemble,
- repair or modify the device. Do not drop, step or throw the
- device purposefully as this may cause accidents such as fire, burn, injury, electrical shock and other
- Do not insert foreign objects

into the device (e.g. metal pieces, pencil lead etc.) or let dust in this

• Remove from the power socket to clean or if not used for a long

### Precautions

- Do not connect electric appliances such as electric stoves and electric heaters that may cause fire, electric shock or injury when left unattended.
- Do not connect appliances that may cause life danger in sudden operation, such as ventilator and other life-support devices.
- Do not connect devices which have rated power bigger than the device.

www.switch-bot.com V1.0-2111

• Do not connect to any devices that may cause harm to objects or persons under remote control.

### Power Button Functions

- 1) Short press: switches between on/off
- 2 Press and hold for 2s: enters adding mode
- ③ Press and hold for 15s: resets to factory settings

Please visit support.switch-bot.com for more details.

## LED Indicator Light

Device Status

In adding mode

Connecting to

Connected to

Reset to factory

the internet

successfully

settings

Please visit support.switch-bot.com

the internet

Power on

Power off


Please visit support.switch-bot.com for more details.

Troubleshooting



## Disclaimer

The company assumes no responsibility or liability for any loss or damage suffered by any person as a result of using the product in



caused by third-party actions. • Faulty operation and unusual conditions.

the following situations:

- This product is intended to be used in your own country but not for abroad.
- Tries to trigger actions in products of other brands but unsuccessful.

## Return and Refund Policy

This product has a one-year warranty which begins from date of purchase.

The following situations are not eligible for a return or refund:

- Any loss or damage caused by intentional damage, abuse or misuse of the device.
- Inappropriate storage (damages caused by dropping or soaking in
- Modifying or repairing of product. Natural wear and/or cosmetic
- damage. Natural disasters.

# Setup and Troubleshooting: support.switch-bot.com Support Email: support@wondertechlabs.com

Contact & Support

Feedback: If you have any concern or problem when using our product, please kindly send feedback from the Profile > Feedback page in the SwitchBot app.

## FCC Warning

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and

can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: Reorient or relocate the receiving

antenna. Increase the separation between the

connected.

- equipment and receiver. • Connect the equipment into an outlet on a circuit different from that to which the receiver is
- Consult the dealer or an experienced radio/ TV technician for

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: 1) This device may not cause harmful

interference. 2) This device must accept any interference received, including interference that may cause undesired

operation

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. Note: The manufacturer is not responsible

for any radio or TV interference caused by unauthorized modifications to this equipment. Such modifications could void the user's authority to operate the

This device has been evaluated to meet general RF exposure requirement. This device should be operated with a minimum separation distance of 20 cm between the equipment and a persons