


Kinetic Door Contact
INSTRUCTIONS

Product Description

This kinetic door contact could be paired with controller and installed on the door or window to turn on /o fffthe light once open or close it.



Product Parameters


Power Supply: Self-powered(No battery)
Working Frequency: 433MHz
Working Temperature: -20°C~+55°C
Control Distance: 80m (outdoor) 30m (indoor)
Life time: >100,000 times
Dimension: 109*27*17 mm

Installation

1.Remove the double-sided tap on the back



2.Fix the door contact on selected door.
Do not attach to metal security doors as this may affect signal transmission.




Paring with controller

1.Press pairing button on receiver for around 3 seconds until the indicator light blinks slowly



2.Open/close the door quickly. Pairing will be successful if the indicator light stops blinking.

Optional fixing kit



You can mount the door contact with the fixing kit,which can be screwed on the door. Note: it's optional.

FCC Warning

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) This device may not cause harmful interference, and
(2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following

Measures

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and

- receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Note: The Grantee is not responsible for any changes or modifications not expressly approved by the party responsible for compliance. such modifications could void the user's authority to operate the equipment

The device has been evaluated to meet general RF exposure requirement.
To maintain compliance with FCC's RF exposure guidelines, the distance must be at least 20 cm between the radiator and your body, and fully supported by the operating and installation

**CERTIFICATE
INSPECTED**