

# Android TV Box

## User Manual

NOTE : This device is for indoor use only

A



A

Amlogic  
S922X

# Standard Accessories


IR Remote(TV Box)

Adaptor

HDMI cable




# Peripheral device for TV BOX





# Installation instructions





1. Turn on TV or Display screen, turn video output mode to HDMI .
2. Connect TV to TV BOX with a HDMI cable.
3. Connect the adaptor to power and TV BOX.
4. the TV BOX will start with LED light on in TV BOX.
5. Then, the TV will show the home UI of TV BOX.
6. If need to connect to many devices, please use USB HUB.



# 5 IR Remote instruction



# 6 Amlogic Android 9 Series









# 8 Troubleshooting

Problem	Solution
No power	<ul style="list-style-type: none"><li>-Check if the power adaptor is properly connected to the power and the TV Box.</li><li>-Press the power on the remote controller to turn on the power.</li></ul>
No picture	<ul style="list-style-type: none"><li>-Reconnect with HDMI cable or AV cable.</li><li>-Check if the TV is switched on.</li></ul>
No sound or distorted sound	<ul style="list-style-type: none"><li>-Adjust the volume.</li><li>-Check that the speakers are connected correctly.</li></ul>
No audio or digital output	<ul style="list-style-type: none"><li>-Check the digital connections.</li><li>-Check if your amplifier is set correctly.</li></ul>
The box does not respond to the Remote Control	<ul style="list-style-type: none"><li>-Aim the remote control directly at the sensor on the front of the TV Box.</li><li>-Reduce the distance to the TV Box.</li><li>-Replace the batteries in the remote control.</li></ul>
Player does not respond to some operating commands during playback	<ul style="list-style-type: none"><li>-Operations may not be permitted. Refer to the user manual.</li><li>-Possibility of system halted, re-insert with power adaptor to restart.</li></ul>
No sound during movies playback	<ul style="list-style-type: none"><li>-The audio codec may not be supported by the TV Box. You can change to the supported audio on playing menu.</li><li>-Check the volume.</li></ul>
The contents of the USB flash drive cannot be read	<ul style="list-style-type: none"><li>-The USB flash drive format is not compatible with the box.</li><li>-If one of the USB can not be read, Please turn off the TV Box for 30seconds and restart TV Box.</li></ul>
Slow operation of the USB flash drive	<ul style="list-style-type: none"><li>-Big file size or high resolutions USB flash drive takes longer time to read and display on the TV screen.</li></ul>
No sound with HDMI connection	<ul style="list-style-type: none"><li>-Check the connection between the TV and the HDMI jack of box.</li><li>-Check your TV system setup.</li><li>-Check the volume.</li></ul>
The TV screen is blank and the player LED is blinking	<ul style="list-style-type: none"><li>-Turn off your TV Box, wait 30 seconds, turn it on again.</li><li>-IF under HDMI status, check if HDMI connection is correct or change HDMI cable set the output resolution of this TV Box into 720p.</li></ul>

**Warning:**

Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

**Note:** Please keep at least 20cm away from the human body during normal use.

**NOTE:**

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

**NOTE:**

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

RF exposure compliance statement:

This device has been evaluated to meet the general RF exposure requirement