Wireless Headphone



User Manual

Features

- Headphone - Charging port
- LED indicator

Contents

- Headphone
- USB charging cable
- User Manual

A Quick Look



- 1.Previous Tarck/Volume
- 2.Power On/Off/Play/Pause Accept/End Call 3.Next Track/Volume +
- 4.Mic 5.Auxiliary Port
- 6.LED Indicator
- 7.Charging Port
- 8.MicroSD Card Reader

Charging the Headphone

- To charge the headphone, attached the small end of the usb cable to the charging port located on the headphone.
- Attached the other end to the USB port on a computer, USB charging adapter.
- A RED light will turn ON while the speaker is charging and turn BLUE once charging is complete.

Pairing the Headphone

- . When you turn your headphone on, it will starts to flash Red and Blue alternately
- Open your smartphone's Bluetooth menu to enable Bluetooth and search for Bluetooth devices. Select "Al9006 Headphone" from the list of devices.
- · After sucessfully pairing, you will hear a voice prompt from the headphone.

On an IOS or Android Device

Go to SETTING>BLUETOOTH

(Make sure Bluetooth is turned ON)





Controls Power On/Off

To turn on the product, hold down the power button for approximately 3 seconds until the LED indicator flashes Red and Blue alternately. Press and hold the same button again to turn off the product.

Play/Pause music

When playing music, press the Play/Pause button to pause the music, press again the same button to resume playing the music.

Volume + / Next track

Press the Volume + / Next track button to advance to the next track. Hold down the same button if you want to increase the music volume.

Volume - / Previous track

Press the Volume - / Previous track button to return to the previous track. Hold down the same button if you want to reduce the music volume.

Call controls

When receiving an incoming call, press the Call button once to accept call, press again to decline call. If you press and hold the Call button, it will reject the incoming call instead of picking it up. Press the Call button twice to redial the last called number.

MicroSD Card Mode

Insert the MicroSD Card into the card slot and the will automatically enter card reader mode. Remove the MicroSD card and the headphone will switch back to Bluetooth mode.

This equipment complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

FCCID: 2AL9B-AI9006

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

Warning

FCC Statement

To assure continued compliance, any changes or modifications not expressly approved by the party. Responsible for compliance could void the user's authority to operate this equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can realidate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- -Reorient or relocate the receiving antenna.
- -Increase the separation between the equipment and receiver.
- -Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- -Consult the dealer or an experienced radio/TV technician for help.

FCC Radiation Exposure Statement:

The device has been evaluated to meet general RF exposure requirement.

The device can be used in the portable exposure condition without restriction.