

# Do Not Return Card



**IMPORTANT**



**PLEASE DO NOT RETURN TO STORE**

If You're Having Trouble, We're Here to Help!




Call us 24/7 at 1-855-292-4087

E-mail us at [alsupport@sakar.com](mailto:alsupport@sakar.com) or visit us at [alteclansing.com](http://alteclansing.com)



# WELCOME 😊

Thank you for purchasing an Altec Lansing product. Download our App to unlock all the features our products have to offer!



**ALTEC**  
LANSING



**JUST LISTEN.**



**MZX4515T**

**Active Noise Cancelling  
'Kid Safe' \*1 Headphones  
with Built-in Locator**


**QUICK START GUIDE**

**FCCID: 2AL9B-MZX4515T**


**In the Box**



**ANC 'Kid Safe'\* Volume  
Limiting Headphones  
With Built-in Locator**




**AUX Cable**



**USB-C Cable**

\* 'Kid Safe' is a marketing term which refers to the volume limiting capability of these headphones only.


## A Closer Look



1. Next Track / Volume +
2. Multi-Function Button  
(Power/Play/Pause/Answer)
3. Previous Track / Volume -
4. ANC On/off
5. LED Indicator Light

6. Auxiliary Port
7. Microphone
8. Charging Port
9. Locator On/Off

## Charging




- **Charging (solid red light)**
- **Fully charged (light off)**

Connect the USB-C cable into the charging port, and connect the other end to a suitable USB charger or USB output to charge the headphone. The headphone's indicator will turn red while charging and turn off when it is fully charged.

Please charge the headphone when you hear a low battery alert or if it turns off automatically due to low battery. The headphone and the locator share the same battery. Continuing to use the headphone without charging will deplete the reserved power for the locator, thus significantly reducing its working time.

**Powering On**



**Pairing Mode**  
**Blue flashing LED**



To turn on the headphone, press and hold the power button for 2-3s. The LED will flash Blue when the headphone is in pairing mode and go solid blue when connected.

## **Bluetooth Pairing**



Once the headphone is on, look up your Bluetooth pairing list on your smart device and select **"AL Kids Locator ANC"** . The headphone LED light will turn into solid Blue, indicating that the headphone is now connected successfully.





# Controls



Function	Required action
<b>Power ON/OFF</b>	Press and hold the Power button for 2-3s
<b>Play/Pause Music</b>	When playing music, press the multi-function button to pause the music. Press again to resume playing the music.
<b>Accept/End/Reject Call</b>	When receive an incoming call, press the multi-function button to accept call, press again to end call. Press and hold the button for 2s to reject the incoming call.
<b>Siri/Voice Assistant</b>	Press and hold the multi-function button to activate Siri or other voice assistant on your connected device.
<b>Volume control</b>	Tap the '+' button to increase the volume. Tap the '-' button to decrease the volume.
<b>Next / Previous track</b>	Press and hold the '+' button to advance to the next track. Press and hold the '-' button to return to the previous track.



*est.*  
**FIRST**

**FCCID: 2AL9B-MZX4515T**

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

**FCC Radiation Exposure Statement:**


The device has been evaluated to meet general RF exposure requirement.  
The device can be used in the portable exposure condition without restriction.

FOLLOW US ON



#myalteclansing  
alteclansing.com


**ANC mode**



- **ANC On**
- **ANC Off**

Press the ANC button to activate the headphone's active noise cancellation function. The headphone's indicator will turn solid green. Press again the same button to turn off the ANC function.

# Locator



1. Turn on the locator: Press and hold the locator button, you will hear a beep, and the orange light will stay lit for 3 seconds.
2. When you are finding the headphone through Find My, the headphone will chime, press the locator button once to stop the chime.
3. Connection test: Press the locator button twice and the headphone will chime. This indicates that the locator is working normally.
4. Turn off the locator: Press the locator button 5 times, and you will hear a long beep sound, with no light indication.

 Locate with  
Apple Find My

## **Powering on and entering pairing mode**

Before using the headphone's locator, please ensure it is powered on. You can double press the locator button and see if it make a 'beep' sound with the orange light flashing three times. If there is no sound or light, press and hold the locator button for 5 seconds to turn it on. Upon powering on, you will hear a beep, and the orange light will stay lit for 3 seconds, indicating that the locator is on.

## **Add the headphone locator to Find My**

Please make sure that you have an iPhone, iPad, or iPod touch with iOS 14.5 or iPadOS 14.5 or later and two-factor authentication enabled.

1. Turn on Bluetooth on your Apple product, and go to Settings > Privacy & Security. Turn on Location Services, then scroll down and tap Find My and choose a level of access. Turn on Precise Location to have the most accurate location.
2. Go back to main screen of the your Apple product, open the Find My app, and tap Items.
3. Tap Add Item, and tap Other Supported Item.
4. Look for the item "MZX4515T", select Connect, name the item, and tap Continue. Then choose an emoji, tap Continue and it will show a message stating that this item is linked to your Apple ID, please check to make sure the email address and mobile phone number are correct, then tap Agree, and Finish.

## **Mark the headphone as lost in Find My**

1. Tap Items at the bottom of the screen, then select the name of the lost device. Scroll down the screen, and below Lost Mode, tap Enable.
2. Follow the on-screen instructions and enter a phone number where you can be contacted, or if you want to enter an email address instead, select 'Use an email address.' Then press Activate.

Note: Make sure the Notify When Found is on.

## **See the location of your headphone on a map**

You can see your headphone's current or last known location in Find My app.

1. Tap Items at the bottom of the screen, then tap the headphone's name you want to locate in.
  - a) If the headphone can be located: it will appear on the map. The updated location time will be displayed below its name.
  - b) If the headphone cannot be located: You will either see its last detected location and time, or 'No location found' displayed below the headphone's name. Turn on Notify When Found and you will receive a notification when it is located.

## **Play a sound**

1. Open the Find My app, select Items tab, then choose the headphone you want to play a sound on. Tap Play Sound, and then you will hear a piece of music, indicating that the product is functioning normally.

※ If the headphone's locator is offline or out of range, it will not play sound.

## **Unwanted tracking alert**

1. If any of the locators or other Find My network accessory products, separated from its owner, is seen moving with you over time, you will be notified. Find My will display a map showing the locations and sequence of where the item was detected with you. If you feel your safety is at risk, contact your local law enforcement officer.

2. This product includes features to guard against unwanted tracking. It should not be used to track people or property that does not belong to you. In many countries and regions around the world, using these products to track someone without their consent is a crime.

## **Product reset**

If you are unable to use the headphone's locator properly, you can unpair and reset it by following the steps below:

To reset the locator in the headphone, you first need to ensure that the device is unpaired and removed from your Apple ID.

1. Open the Apple Find My app, then tap the Items tab.

2. Tap the item that you want to remove, then swipe down to the bottom of the page.

3. Tap Remove Item, then tap Remove again to confirm.

After removing the product from Find My, you can now perform a manual reset to the locator in the headphone.

1. Press twice the locator button on the headphone until you hear a chime. Please note that you should only proceed to the next step after you hear the headphone chime. If it does not chime, please repeat this step a few more times.

2. Then, press and hold the same button again. Do not release it until you hear a short chime followed by a long chime. The LED indicator will blink orange three times, indicating that the locator has been successfully reset.

You can also place the locator close to the device you need to connect before performing a product reset, and then try connecting the locator again.

※ If you manually reset the product before unbinding it from your Apple device, it will take longer time for the Apple device to remove the product.

## Notes



\*To use voice assistant, you must have a phone that is equipped with a voice assistant.

\*You must be within Bluetooth range to use voice assistant via your headphone.

Your headphone's voice assistant feature will not work if a voice assistant is not first enabled with in the settings on the phone. For more information, see your phone's user manual.

Use of the Works with Apple badge means that a product has been designed to work specifically with the technology identified in the badge and has been certified by the product manufacturer to meet Apple Find My™ network product specifications and requirements. Apple® is not responsible for the operation of this device or use of this product or its compliance with safety and regulatory standards.

The Apple Find My™ network provides an easy, secure way to locate compatible personal items using the Find My™ app on your iPhone®, iPad®, Mac®, iPod touch®, or the Find Items app on Apple Watch®. To use the Find My app to locate this item, the latest version of iOS®, iPadOS®, or macOS® is recommended. The find Items app on Apple Watch® requires the latest version of watchOS®. Apple Find My, Apple Watch, Find My, iPhone, iPad, iPadOS, iPod touch, Mac, macOS and watchOS are trademarks of Apple Inc. IOS is a trademark of Cisco and is Used under license. One year manufacturer warranty.

\*\*'Kid Safe' is a marketing term which refers to the volume limiting capability of these headphones. In normal use the sound level will be below 85dBA SPL which is the recommended limit for an 8 hours maximum period per day.

For additional user materials and  
warranty information, please  
visit [alteclansing.com](http://alteclansing.com)

## Notes



### Care and maintenance

To ensure the longevity and optimal performance of your headphone, please follow these care instructions:

#### 1. Charging and battery care

- Always use the charging cable that came with your headphone. If a replacement is necessary, ensure the charger and cable used matches the product input voltage and amperage.
- Do not leave your headphone charging overnight. Disconnect it once it is fully charged to preserve battery life.

#### 2. Cleaning

- Clean the parts of the headphone only with a soft, dry cloth.
- Do not use any solvents or cleansing agents.
- Keep all liquids far away from the headphone.

#### 3. Storage and usage

- Do not expose the headphone to direct sunlight or high temperatures for extended periods of time.
- Do not subject the headphone to excessive shock as it is a precision device.
- Do not apply weight or pressure to the headphone for long periods, including when it is stored, as it may cause deformation.



# **REGISTER YOUR PRODUCT**

**To receive news, exclusive deals, OTA or  
firmware updates, warranty information and  
more please register your product at**

**[alteclansingsupport.com](http://alteclansingsupport.com)**





FOLLOW US ON



#myalteclansing  
alteclansing.com

## 12 Month Limited Warranty

All Altec Lansing products come with  
12 month limited warranty  
from the date of its original purchase

## 24 Hour Customer Support

We love our customers, and we care  
about your experience with Altec  
Lansing. If you need  
assistance, please call us at  
1.855.292.4087

or e-mail [alsupport@sakar.com](mailto:alsupport@sakar.com)  
[www.alteclansing.com](http://www.alteclansing.com)

Altec Lansing Edison, NJ 08817