ϑ Jiuzh⊕u



USE MANUAL

Modelo: DTS3443

нэті

"HDMI, the HDMI Logo, and High-Definition Multimedia Interface are trademarks or registered trademarks of HDMI Licensing LLC in theUnited States and other countries."

DOLBY AUDIO

Manufactured under license from Dolby Laboratories. Dolby, Dolby Audio and the double-D symbol are trademarks of Dolby Laboratories.

Key Features

Our set-top box ensures you access to the TV service with satellite signal

Claro TV digital and allows you to enjoy better sharpness in image and sound. In addition,

the service brings you benefits as a fast program switching feature,

automatic frequency search, lock password, all on one interface

user friendly and easy to use. With advanced demodulation 8PSK and QPSK and

decoding technologies, the team is able to receive and decode all

digital satellite television programmes compatible with DVB video standards, with

MPEG2 and MPEG4 modulation. DVB-S/S2.

- Compatible with DVB-S/S2 video standard
- Nagra Silicon Secret CAS Certificate
- User-friendly interface
- HI-FI digital stereo output
- USB port for personal digital recorder
- Programming Guide (EPG)
- OTA support

Packing List

You Set-Top-Box and the following items:

- 1 STB Digital Satellite (Set-Top-Box)
- 1 Audio/video cable
- 1 Remote control unit (RCU)
- 2 Battery
- 1 User Manual
- 1 HDMI cable

Content

1. Safety Instructions	3
2. TV receiver	4
1) Front Panel	4
2) Rear Panel	4
3) Remote Control Unit	5
3. Connections	6
4. Introducing features7	

Safety Instructions

Do not allow the receiver to be exposed to extreme heat, cold or moisture.

Do not remove the cover to prevent electric shock or damage.

Do not place heavy objects on the receiver.


If the receiver is not in use for a long time, disconnect the power cord to prevent fire or electric shock (do not use a damaged power cord).

When the receiver moves to another place with a lot of temperature difference, please do not turn it on immediately until 1-2 hours later.

Never allow liquids or other materials to enter the receiver.

2. TV Receiver

1) Front Panel




1.Power button

Switch between power mode and standby mode.

2.CH- / CH+ button

Changes the current channel to the previous or next channel in the menuless state. 2) Rear Panel



1. RF IN

Digital signal input door coming in from the antenna.

2. USB

Use connector to connect the receiver to your external hard drive, for recording and repring

3. HDMI

HDMI digital audio and video output.

4. VIDEO

This connector has a constant video signal for additional VCR connections.

5. Smartcard slot Slot to insert the service card

6. AUDIO Right and Left

These connectors give you the ability to connect the audio signal to the external amplifier or AUDIO input from the TV.

7. S/PDIF

Uses electrical output to connect the receiver to the audio amplifier input. opposition

8. Power Input

Connection to the power adapter.


3) Remote Control Unit



All decoder features can be controlled with the remote control. じ: Turns on or off. : Turns off the sound. AUDIO: Displays the audio selection window. INFO: Displays the current channel information. TV/R: Switches between TV and Radio modes. MENU: Displays the main menu. EXIT: Return to the previous menu or exit. OK: Confirm operation. Move the cursor up /down /left/ right, page up/down, Volume + / -. V +/V-: Volume up or down. P+/P-: Page up or down in the menu list. RCL: Switches to the last channel seen. SUB: Displays the list of languages for subtitles. TEXT: Display of current teletext service on the screen. FAV : Displays the favorites list window. EPG: Displays the programming guide. Color buttons: Useful depends on information displayed in the menu or Remote Control. II Starts the Time Shift operation or pauses the recording operation. Starts the recording operation manually. Enter the file list menu or start displaying Time Shift files in the Non-menu state. Executes the forward or backward operation for recording files. : For the recording or Time Shift operation Manually.

3. Connector

- 1. Connect the LNB satellite signal to the LNB IN connector..
- 2. Connect the TV using an AV cable.
- 3. Connect the TV using a HDMI cable.



4. Introducing features

1) Main menu

The main menu consists of five parts:

System Settings: This part allows the user to run satellite settings, automatic scanning of a given satellite, manual scan of a specified TP, OTA update and reset all factory settings.

Channels: This part allows the user to check the menu of the Programming Guide and channel information, editing and sorting of the program, and editing of Favorite Channels List. Utilities: This part allows the user to check disc information and default settings of Digital Recording, and list of scan recording files.

Information: This part allows the user to confirm information from CA, mail and basic system. User Settings: This part allows the user to configure various user screen settings, Time Scheduler settings, and parental control.

\diamond	Claro
🔍 Instalación	
📰 Editar	
📄 Ajustes	Configuración Antena Búsqueda manual
📋 Herramientas	
CAS	
\otimes	

2) Time Scheduler setting

The user can select different options to start different time scheduler that can support playback, recording and rest timer. Take the recording timer as an example.

	\Diamond	Claro-
🔍 Instalación 📼 Editar	Selección de Idioma Ajustes de OSD	
Ajustes	Ajustes de salida Fecha y Hora Temporizador	
	Control parental	

The user can press the yellow key to add a recording time and press the red to cancel it

clarهٔ emporizador de eventos 15:15 09/12/2019			
Canal	Modo	Frecuencia	Fecha y Hora
No activado			
Agregar MENU Volve	r (Exit) Salir		

The user can select recording parameters from this list, such as the following: Time Scheduler Cycle, Start Date, Start Time, Channel Time duration

ïmer Event	Clarb-
Modo	Cambiar Canal >
Canal Fecha de inicio Duración Frecuencia Dom Lun Mar Mié Jue	TBN Enlace 09/12/2015 15:20 00:00 Una vez Vie Sáb
Cancelar (MENU) Volver (Exit) Guardar	

Record from the Guide When the focus is on the right side, the user can set a new recording timer or cancel it for the current event by pressing the yellow button.

Guía	Claro TV Cano 15:16 09/12/2015					
TBN Enlace 15:00-15:30 Pala Desde Colombia,			acional, Eduard	o Cañas, nos tra	e temas	
09 Dec	15:00	15:30	16:00	16:30	17:00	
600 TBN Enlace	Pelabra y mile	Verdades que	Fe expecta	Casa de Dios	Generación vic	
601 Sembrador	Diseñados par	Herramientas	Santa Misa desde España		Dimensión de	
650 History HD	El precio de la	El precio de la	El precio de la	El precio de la	Rutas mortales	
651 FOX HD	Yo, Robot				Futurama / Lee	
652 ESPN HD	UEFA Champio	ns Leag UEFA C	hampions Leag	ue / AS Roma (Ita	a) vs. BATE Boris	
Día Anterior (Día Siguiente	Reserva (INFO	Información			

Record directly The user can start a recording just by pressing the REC button when the set-top box is connected to any storage device, for example, usb.



NOTE:

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

-Reorient or relocate the receiving antenna.

-Increase the separation between the equipment and receiver.

-Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

-Consult the dealer or an experienced radio/TV technician for help.