


Take Off Guide


1. Notus Remote Control



NOTUS
remote control

2. Turn On Notus


Notus remote control arrives with a 2XAAA (2PCS) batteries blister inside a polybag. To turn on your Maestro remote control, please follow the instructions below.




1. Turn ON your TV and your Set Top Box.



2. Remove your Notus remote control and its batteries from the plastic bag.



3. Remove the remote's battery lid.




4. Place the batteries on the Notus remote control as indicated in the image above and replace the battery lid.



5. After inserting the batteries, wait a few seconds and the Notus remote will be ready to operate.

3. Notus - Control Your TV

The Notus remote control can control your TV. By default, it is configured to control a Samsung TV, but via the STB User Interface the remote can be setup to control other brands and models.



1. Once you have selected to configure your remote to control your TV in the STB user interface, the STB will guide you through the necessary steps to configure the Notus remote to control your TV.



FCC Compliance Statements

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) this device may not cause harmful interference, and
(2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE: This equipment has been tested and found to comply with the limits for Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC Radiation Exposure Statement:

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

Warning: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.