
FSC 100% Wood MagClick™ 5000 mAh Fast Wireless Power Bank

Instruction Manual Item: 7122-06 Model: XY-PR016



Functions:

- 1. Wireless Charging Surface 2. Magnetic Surface
- 3. ON/OFF Button
- 4. LED Display
- 5. Type-C Input/Output
- 6. LED Indicator
- 7. USB-A Output

What's included:

- 1 x Instruction Manual 1 x USB-A to Type-C Charging Cable
- 1 x Wireless Charging Pad
- - play(4) will show the remaining power, LED Indicator(6) turn RED when in standby mode.

Tech Specifications

- Battery Capacity: 5000mAh/18.5Wh
- Type-C input: 5V/2.4A:9V/2A: 12V/1.5A
- Type-C output: 5V/2.4A:9V/2A: 12V/1.5A
- USB-A output: 5V/2.4A:9V/2A: 12V/1.5A Wireless output: 10W/7.5W/5W

Instructions:

- 1. Charging the Powerbank:
- . Be sure the power bank is fully charged
- Using the included Type-C to USB charging cable, insert the USB A port of the cable into a certified USB AC adapter or USB port of a computer and Type-C into Type-C Input/ Output port (5).
- . Once connected, the LED display(4) will show the percentage of remaining power and when fully charged the LED display will show "100%"
- 2. Charging Mobile Phones and Other Flectronic Devices:
- . Connect the charging cable to your mobile phone/device using the appropriate connector. Connect the LISB tip of the cable. into USB A Output(7) or Type-C tip into Type-C input(5).
- . Phone will begin to charge automatically. the LED display will show the percentage of remaining power in the power bank.
- . Remove the charging cable from your mobile device when it is fully charged.
- 3. Wireless Charging Mobile phones and other electronic devices:
- Press the ON/OFF button(3) once to turn on the wireless charger function, the LED dis-
- Place the wireless charging supported

mobile device on the wireless charging surface, it will begin to charge automatically and the LED Indicator will glow RED when device is charging.

- Once fully charged remove the device.
- . Double press the button to turn off the wireless charger.
- ** Note: When wireless charging, if the LED indicator flashes BLUE the device is either NOT a wireless charging device or there is an object between the the device and charging surface interfering with the charging process
- 4. Wireless Charging with Magnetic Surface:
- If your device supports MagSafe, the magnets in your iPhone will connect to the magnetic surface(2) of the pad for a more secure charging.
- . This item is also compatible with other items, the magnetic function just won't

SAFETY PRECAUTIONS:

- WARNING-When using this product. basic precautions should always be followed, including the following:
- 1. Read all the instructions before using the product
- 2. Charge the power bank fully before initial use. The unit's full performance is achieved only after 2 or 3 completed charge and discharge cycles.
- 3. To reduce the risk of injury, close supervision is necessary when the product is used near children.
- Do not expose the device to moisture.
- Do not use the device in excess of its output rating. Overload outputs above rating may result in a risk of fire or injury.

- 6. Do not use the device if damaged or
- 7. Damaged or modified batteries may exhibit unpredictable behavior resulting in fire, explosion or risk of injury.
- 8. Do not disassemble the device Take it to a qualified service person when service or repair is required. Incorrect reassembly may result in a risk of fire or injury.
- Do not expose the device to fire or excessive temperature. Exposure to fire or temperatures above 212Fmay cause
- 10. Have servicing performed by a qualified repair person using only identical replacement parts
- 11. This will ensure that the safety of the product is maintained.
- 12. Do not overcharge Phone. Unit may get hot with excessive use.Remove Phone when it is fully charged Never charge for more than7 hours at a time.
- 13. Attachments on the back of your phone can impede the effectiveness of the wireless charger, and lead to overheating. Please remove attachments from the phone before charging on this device

FCC Statement:

- This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.
- * Warning: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B. digital device pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna. - Increase the separation between the
- equipment and receiver - Connect the equipment into an outlet on a circuit different from that to whitch the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

IC Statement

This device contains licence-exempt transmitter (s)/receiver(s) that comply with Innovation, Science and Economic Development Canada's licence-exempt RSS(s). Operation is subject to the following two conditions:

- (1) This device may not cause interference. (2) This device must accept any interference. including interference that may cause undesired operation of the device
- L'émetteur/récepteur exempt de licence contenu dans le présent appareil est conforme aux CNR d'Innovation. Sciences et Développement économique Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes:

Radio Frequency Exposure Statement for IC This equipment complies with IC exposure limits set forth for an uncontrolled environment. This equipment shall be installed and operated with minimum distance 10cm between the radiator & body.

Cet équipement est conforme aux limites

d'exposition IC définies pour un environnement non contrôlé. Cet équipement doit être installé et utilisé avec une distance minimale de 10cm entre le radiateur et la carrosserie. CAN ICES-3 (B) / NMB-3 (B) This Class B digital apparatus complies with Canadian ICES-003

(Cet appareil numérique de la Classe B conforme à la norme NMB-003 du Canada).

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction

Name of the Distributor: Leedsworld Inc. Address of the Distributor: 400 Hunt Valley Road. New Kensington PA 15068 USA.

2ALCEXY-PR016 IC ID: 27880-XYPR016 Made in China

FSC

Paper from responsible sources FSC® C170910 $20.0 \, \text{mm}$ **FSC** MIX

Paper from responsible sources FSC® C170910