



User Guide

Frontrow Unity

Part #2000-00062

1. Power ON Unity, Power LED and volume LEDs turn ON (volume LEDs yellow for some seconds, then green)



2. Region switches must match between microphones and Unity. Flip region switch to US for all US/CAN and to EU for any other country (see below).

Microphone

Region
Switch



Region: US/CAN



Region: EU



Unity



Region: US/CAN





Region: EU



3. Press and hold microphone mute button (see image below) until microphone beeps **two** times, then release. On Unity, press microphone button once. Then both wireless and battery LEDs on

microphone flash green. Registration is complete, microphones are ready for testing.

Microphone	Unity
 <p>A close-up photograph of a grey microphone control panel. At the top is a black microphone grille. Below it are several buttons: a black triangular button, a black button with a microphone icon (highlighted by a red box), another black triangular button, a cyan square button, and a yellow circular button. A white label with the text "DO NOT MODIFY" is positioned vertically on the right side. A red arrow points to the microphone icon button.</p>	 <p>A close-up photograph of a grey Unity control panel. From left to right, it features a white volume knob with a green LED ring, a black button with a padlock icon, a black button with a microphone icon (highlighted by a red box), a blue button with a telephone handset icon, and a red button with a warning triangle icon. A red arrow points to the microphone icon button. A green LED indicator is visible near the volume knob.</p>

FCC Warning

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.

IC Warning

This device complies with Industry Canada licence-exempt RSS standard(s). Operation is subject to the following two conditions:

(1) This device may not cause interference, and

(2) This device must accept any interference, including interference that may cause undesired operation of the device.

This equipment complies with IC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes: (1) l'appareil ne doit pas produire de brouillage, et (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement

Ce matériel est complété par une exposition de rayonnements IC pour un environnement nature I. Ce matériel doit être installé et se faire avec une distance minimale de 20cm entre les radiateurs et les autres.