

INSTRUCTION MANUAL

PLEASE READ ALL INSTRUCTIONS CAREFULLY & RETAIN FOR FUTURE USE

Getting Started

Remove the unit from the box.

Remove any packaging from the product.

Please retain all packaging until you have checked and counted all the parts and the contents against the parts list.

Package Contents

FBT280 Portable Wireless Speaker

USB rechargeable cable : The USB port can only be used for charging, cannot transmit data.

Instruction manual

Warranty Card

Features

1. Wireless Bluetooth connectivity to iPad, iPod Touch, Android, Windows Phone, Blackberry, smartphones, tablets, computers and more.
2. Play music through Bluetooth.
3. Rechargeable built-in battery

IMPORTANT SAFETY INFORMATION


1. Read all instructions before using this product.
2. Do not leave this product unattended while connected to the power supply.
3. Do not immerse in water or any other liquids.
4. Do not use if unit has been dropped or damaged in any way.
5. Improper repairs may place user at serious risk.
6. Repairs to electrical equipment should only be performed by qualified personnel.

Place unit on sound, even surface, free of vibrations and away from sources of heat.

7. Do not put objects into openings.
8. Do not use this unit for anything other than its intended use.
9. Keep this product out of reach of children.
10. This product is not a toy.

Do not play music at excessive levels especially near children, as damage to hearing may occur.

Description of Parts:



Item	Function	Operation
①	Power ON/OFF switch	Turn ON/OFF the speaker.

Bluetooth Connection.

Press POWER SWITCH to turn on the speaker until there is notice voice.

Then it's ready to repair.

Turn on the Bluetooth on your devices to add, search or scan for devices, select "2Boom-BT280".

Enter passcode "0000" if it asks. Voice notice appear when connected successfully.

Specification

Bluetooth version : 4.2 Support A2DP V1.2, AVRCPV1.4 PROFILES.

Maximum Output : 3W

Channel: Dual channel

S/N ratio: ≥ 80 db

Frequency range: 100Hz-20kHz

Battery voltage: 3.7V DC

Nominal voltage: 3.7V DC

Battery: Built -in lithium battery, 3.7V DC/300mAh

Charge Voltage/Current : 5V ± 0.25 V/1A

Working time : 3-4hours (vary with volume)

Product size: 95*26mm

Troubleshooting

My mobile phone can't find any new Bluetooth device?

Make sure the Bluetooth speaker has entered pairing mode.

Ensure the speaker is within the effective working range.

Bluetooth devices can't pair up

Make sure your mobile phone allows new connection, did not reach the maximum allowed connection number, please refer to your mobile's user manual.

Make sure the pairing password entered is "0000". If you are using a Bluetooth transmitter device, please ensure the responding password of your Bluetooth transmitter supports "0000" code.

Turn off the speaker and your device, then power on and reconnect.

FCC STATEMENT

This device complies with Part 15 of the FCC Rules.

Operation is subject to the following two conditions:

This device may not cause harmful interference, and

This device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

FCC Radiation Exposure Statement:

The device has been evaluated to meet general RF exposure requirement.

The device can be used in portable exposure condition without RF striction.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If the equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/ TV technician for help.