


TAGRY



S64 USER MANUAL
Open Wearable Stereo


Contents

- Customer Service & Packing List.....01
- Product Overview.....02
- Product Parameters & First -Use.....03
- How to Wear.....04
- How to Charge.....04-05
- Power on / Power Off.....06-07
- How to Pair/Reset?.....08-09
- Touch Control Music/Call/Voice Assistant....10-11
- Battery Warning & Storage and Maintanance.....12
- FCC Caution.....13
- FAQ.....14-16

01. Customer Service

www.tagry.studio

If you have any problems with your earbuds, please do not hesitate to contact us to solve your problem.




www.tagry.studio

02. Packing List

- Charging Case *1
- Earbuds (L&R) *1
- Type-C Charging Cable *1
- User Manual *1

Note: Before using earbuds, please remove the protective films from the charging contacts.

03. Product Overview




Charging Contact, Microphone, LED Indicator of Earbud, Touch Control Area, Charging Pin, Type-C Charging Port, Charging Status of Earbuds(L/R), Power Display of Charging Case

04. Product Parameters

- Model No.: S64
- Bluetooth Version: V5.4
- Support Profile:A2DP/AVRCP/HSP/HFP
- Transmission Range: 33feet (Without Obstacles)
- FCC ID: 2AMBA-S64 IC: 27838-S64
- Charging Cord Type: USB-C Charging Cable
- Input: 5V 1A
- Capacity for Charging Case: 500mAh, 3.7V, 1.85Wh
- Capacity for Earbuds: 60mAh, 3.7V, 0.222Wh
- Weight: 0.18 lb
- Size: 4.3*1.2*2.1 in

05. First -Use

- Please remove the protective film before use, otherwise the headphone will not be able to charge.
- Please use put both earbuds into charging case and use usb-c cable to charge for earbuds about 2.5Hrs.



Remove Me, Input: DC 5V

06. How to Wear

Step 1: Take out the earbuds


Step 2: Place the earhook over your ear

Step 3: Rotate it backward, and adjust to the optimal position for a secure and comfortable fit.

07. How to Charge?

Charging the Earbuds

Place both earbuds in the charging case. Then close the lid, while charging, the LED indicator of earbuds will be red. (When the earbuds are fully charged, the red light will turn off)



Input: DC 5V

08. Power On and Power Off

Power on
Auto power on

Once open the charging case, it will automatically power on and enter pairing mode, the LED indicator of earbuds will be on blue light for 1s.

Manual power on

When earbuds are out of charging case. Long press the touch area for 2s, then the LED indicator of earbud will be on blue light for 1s.

Please note: in this situation, each earbud need to be manual power on separately.


Power off
Auto power off

Put both earbuds into charging case and close the case, earbuds will auto power off.

Manual Power Off

Long press the touch control area of either earbud for 5s, earbuds will power off, the LED indicator of earbuds will be on red light for 1s.

Please note: this way is just for earbuds are disconnected with your device.



1s, 2s, L/R Earbuds, Touch Control Area for 5s, Power Off

09. Pair and reset

How to pair
Stereo Mode


- Open the charging case, earbud will power on automatically and they will connect with each other, then enter pairing mode.
- Turn on your device bluetooth to search and select "S64" to connect.

Note: If in the disconnected statement, the earbuds will enter pairing mode automatically, the led indicator for main earbud flash red and blue alternately, the sub earbud flash blue slowly. Once paired successfully, the led indicator for main earbud flash blue for 2s and off.

Single Earbud Mode

- Take one earbud out from charging case and close the case.

- Turn on your device bluetooth and select "S64", earbud will pair with your device successfully.




Note:

- If both earbuds do not connect with your device for 5 mins, earbuds will auto power off.
- These earbuds will auto pair with your last successfully connected device, so if you need to pair with new device, please forget "S64" at your previous bluetooth list first.

How to reset

- When earbuds are out of charging case and not connect with any device, 5 clicks both earbuds at same time, then the led indicator of both earbuds will flash red and blue light for three times, and hear a promote "power off".



5x

10. Touch Control

Music Assistant

Play/Pause: Double clicks L/R earbud.

Previous Track: Triple clicks L earbud

Next Track: Triple clicks R earbud.

Volume -: Long press L earbud

Volume +: Long press R earbud

Call Assistant

Answer/End Call: Double clicks L/R earbud

Reject Call: Long press L/R earbud 2s

Voice Assistant

Activate voice assistants: Triple clicks L/R earbuds.

End voice assistants: Triple clicks L/R earbuds.

Note: In single earbud, triple clicks L/R earbud, the music will enter next track)


11. Battery Warning

Using the wrong battery can cause fire and other hazards (for example, in the case of some lithium battery types).

- Disposal of a battery into fire or a hot oven, or mechanically crushing or cutting of a battery, that can result in an explosion.
- Do not leaving a battery in an extremely high temperature surrounding environment that can result in an explosion or the leakage of flammable liquid or gas.
- A battery subjected to extremely low air pressure that may result in an explosion or the leakage of flammable liquid or gas.

12. Storage and Maintenance

- If the earbuds have been unused for more than 3 months, we recommend that you charge them.
- Please use chargers that are FCC (Federal Communications).
- Do not disassemble earbuds.
- Adult supervision is required for children aged 6 and under.
- Do not expose earbuds to high or low temperature, do not use the earbuds in thunderstorm storm. Avoid falling or violent impact of the device. Keep the device away from fire, do not put.



Keep Away

13. FCC Caution

Changes or modifications not expressly approved by the party responsible for compliance may void the user's authority to operate the equipment. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference with radio communications. However, there is a guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference with radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to attempt to correct the interference by one or more of the following measures:

- Increase separation between equipment and receiver.
- Connect the equipment to an outlet on a circuit different from that to the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

This device contains licence-exempt transmitter(s)/receiver(s) that comply with Innovation, Science and Economic Development Canada's licence-exempt RSS(s). Operation is subject to the following two conditions:

- (1) This device may not cause interference.
- (2) This device must accept any interference, including interference that may cause undesired operation of the device.

L'émetteur/récepteur exempt de licence contenu dans le présent appareil est conforme aux CNR d'Innovation, Sciences et Développement économique Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes :

- (1) L'appareil ne doit pas produire de brouillage;
- (2) L'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.


14. FAQ

Q: How can i do when the earbuds can't be charged?

A: Please check if the charging case are out of battery. If yes, please use USB-C cable to charge it. It will take about 2.5Hrs for fully charging.

If not about the battery, please check the earbuds as below details:

- Put both earbuds into charging case to check if the LED indicator for earbuds are on. If not, please check whether there are dirty in the charging pins of earbuds and the charging case. Use a fine cotton swab dipped in a small amount of alcohol, wipe the charging pins of the earbuds and case.
- Whether the earbuds can be turned on normally.
- Ensure that you are using a standard adapter and the provided Type-C data cable for charging.




Q: Why these earbuds can not pair with my phone?

A: 1. Please make sure the earbuds are fully charged and power on.

2. Please make sure the bluetooth of your phone is turn on.
3. If above 2 points have no problem, please take out earbuds and click both earbuds for 5 times to reset earbuds, hold on for 1 min, then open the charging case to turn on earbuds and search "S64" at your phone to reconnect.

Please note, the earbuds will connect with your last device automatically. If you need to pair with new device, please forget the earbuds from your previous device bluetooth list.



Please kindly scan the QR code to activate lifetime warranty of your earbuds within 15 days.

www.tagry.studio

S64说明书
尺寸:72.5*111.3mm
材质:108g铜板纸
对折方式:凤琴折