













 <p><b>All-in-One Karaoke Microphone</b> <b>M1</b> <b>User Manual</b></p>		<p><b>Tips</b></p> <ol style="list-style-type: none"> <li>The button is always facing in your direction, holding the microphone perpendicular to the face, and the top is facing the lips. At this time, the left and right ears have the best sense of hearing and pickup (because the speaker has directivity, the microphone is a heart-shaped anti-interference pointing).</li> <li>The microphone volume can be adjusted by adjusting the distance between the lips and the karaoke. When using the product, you can adjust freely for the best results.</li> <li>Do not hold the sponge part in your hand. Do not place the microphone on the sundries. The sponge part has a built-in speaker, which is easy to cause whistling.</li> </ol>  		<p><b>Product Instruction</b></p>  <p><b>Notiz:</b> 1. The long-term pressing of the sponge may cause temporary deformation, and the karaoke microphone may need a moment to recover. 2. Do not pull the sponge cover with your fingernails or sharp objects.</p>	<p><b>Operation Instruction</b></p> <ol style="list-style-type: none"> <li><b>Boot</b> Press and hold the multi-function button for 3 seconds to turn it on. When the blue light is on, there accompanied the startup ringtone.</li> <li><b>Shutdown</b> Press and hold the multi-function button for 2 seconds to turn off the light, the indicator light is off.</li> <li><b>Charging</b> Connect the mobile phone with a quality USB charger (requires the user to self-provide it) through the USB type-c charging cable, and plug the charger into the socket to automatically charge.</li> </ol>	<p><b>Wireless Mode (Bluetooth mode)</b></p> <p>In the power-on state, if there is no connection to the USB Type-C, the microphone will automatically enter the Bluetooth mode with the corresponding prompt "Bluetooth Mode".</p> <p><b>Bluetooth connection</b></p> <ol style="list-style-type: none"> <li>In Bluetooth mode, if there is no Bluetooth connection, it will automatically enter pairing mode.</li> <li>Search and connect to the Bluetooth "Cozime" via the Bluetooth list of the mobile phone, and you can connect successfully. When the connection is finished, the microphone will send a "buzz" tone. At this point, you can open the Karaoke app and also play music.</li> </ol>	 <p><b>Notiz:</b> 1. The connected mobile phone will automatically connect back after entering the Bluetooth mode. 2. When the Bluetooth connection is disconnected, the microphone will issue a "beeping bell" tone and enter pairing mode again.</p>	<p><b>Music Playback Operation</b></p> <p>It can be operated on the phone or while the player is running:</p>  <p>Click the multi-function button to play and pause the music. Double-click the multi-function button to the previous song. Triple-click multi-function button to the next song.</p> <p><b>Wired recording (AUX mode)</b></p> <ol style="list-style-type: none"> <li>Power on state, insert the recording line, it will automatically switch to recording mode, accompanied by the corresponding prompt "AUX Mode".</li> <li>Connect the other end of the recording cable to the mobile phone, open the Karaoke app, and you can use the app to sing and record songs.</li> </ol>	<p><b>Notiz:</b> For iPhone 7 or above, you need to connect your own Lightning to 3.5mm AUX cable on your phone.)</p> <p><b>Music playback operation</b> Please operate on your phone.</p>																																								
<p><b>Sing in USB mode</b></p> <p>In the power-on state, the U disk inserted into the USB Type-C interface is converted to the U disk mode, accompanied by the corresponding prompt "Play By USB Drive", and then the music in the U disk is automatically played, and you can sing accompanied by the music.</p>  <p><b>Music Playback Operation</b></p> <p>It can be operated on the phone or while the player is running:</p>  <p>Click the multi-function button to play and pause the music. Double-click the multi-function button to the previous song. Triple-click multi-function button to the next song.</p>	<p><b>Volume Adjustment</b></p>  <p>Rotate in the "-" direction to adjust the volume of the music. Rotate in the "+" direction to increase the volume of the music.</p> <p><b>Notiz:</b> The volume of the sound pickup input is not adjusted with the knob. To adjust the input volume of the microphone, you can adjust the distance between the mouth and the karaoke.</p>	<p><b>Indicator Status Description</b></p> <table border="1"> <tr> <td>Start up</td> <td>blue light is always on</td> </tr> <tr> <td>Shutdown</td> <td>indicator is off</td> </tr> <tr> <td>Low battery</td> <td>red light is flashing</td> </tr> <tr> <td>When the microphone is in shutdown charging</td> <td>red light is always on</td> </tr> <tr> <td>When the microphone is in shutdown charging</td> <td>red light and blue light are always on at the same time</td> </tr> <tr> <td>When the microphone is power off and full charged</td> <td>green light is always on</td> </tr> <tr> <td>When the microphone is power on and full charged</td> <td>green and blue lights are always on</td> </tr> </table>	Start up	blue light is always on	Shutdown	indicator is off	Low battery	red light is flashing	When the microphone is in shutdown charging	red light is always on	When the microphone is in shutdown charging	red light and blue light are always on at the same time	When the microphone is power off and full charged	green light is always on	When the microphone is power on and full charged	green and blue lights are always on	<p><b>Parametro</b></p> <table border="1"> <tr> <td>Model</td> <td>M1</td> </tr> <tr> <td>Microphone directivity</td> <td>single directivity</td> </tr> <tr> <td>Speaker</td> <td>5W/ Φ45mm</td> </tr> <tr> <td>Frequency response range</td> <td>60Hz-20KHz</td> </tr> <tr> <td>Bluetooth version</td> <td>4.2</td> </tr> <tr> <td>Connection distance</td> <td>7 meters (accessibility and strong interference)</td> </tr> <tr> <td>Battery</td> <td>3.7V/890mAh</td> </tr> <tr> <td>Charging input</td> <td>DC5V/0.8A</td> </tr> <tr> <td>Charging time</td> <td>about 1.5 hours</td> </tr> <tr> <td>Use time</td> <td>about 4 hours</td> </tr> <tr> <td>Interface</td> <td>USB Type-C</td> </tr> <tr> <td>Size</td> <td>57.5mmX189.5mm</td> </tr> <tr> <td>Implementation standard</td> <td>GB 8898-2011</td> </tr> </table>	Model	M1	Microphone directivity	single directivity	Speaker	5W/ Φ45mm	Frequency response range	60Hz-20KHz	Bluetooth version	4.2	Connection distance	7 meters (accessibility and strong interference)	Battery	3.7V/890mAh	Charging input	DC5V/0.8A	Charging time	about 1.5 hours	Use time	about 4 hours	Interface	USB Type-C	Size	57.5mmX189.5mm	Implementation standard	GB 8898-2011	<p><b>Product And Accessories List</b></p>       <p>sponge cover (including one that has been assembled on the product) user manual (including warranty card)</p>	<p><b>Attention and FAQ</b></p> <ol style="list-style-type: none"> <li>When the microphone is placed in a small space or there is an object to block the speaker, if a howling is generated, it is a normal appearance. Please grasp the microphone correctly and place it on a flat surface when placed.</li> <li>Low battery level may affect the quality of playback, please charge in time.</li> <li>When playing music or accompaniment in Bluetooth mode, if it is intermittent or distorted, the signal distance may be too far away or the signal is interfered. Try adjusting the distance from the phone.</li> <li>If the accompaniment quality is poor or the volume is too large, it may affect the playback quality. Please change the accompaniment and try to adjust the volume appropriately.</li> </ol>	<p><b>FCC Statement</b></p> <p>This device complies with Part 15 of the FCC rules. Operation is subject to the following two conditions: 1) this device may not cause harmful interference, and 2) this device must accept any interference received, including interference that may cause undesired operation. Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: --Reorient or relocate the receiving antenna. --Increase the separation between the equipment and receiver. --Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. --Consult the dealer or an experienced radio/TV technician for help. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. <b>Radiation Exposure Statement</b> This device complies with RF radiation exposure limits set forth for an uncontrolled environment. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.</p>	<p><b>Microphone Performance Failure Table</b></p> <p>Performance failure</p> <ol style="list-style-type: none"> <li>The sound pickup has no input or too much noise</li> <li>Speakers are silent or low-volume</li> <li>Cannot make cable recording or recording quality abnormal</li> <li>Cannot play mp3 music in type-C U disk</li> <li>Unable to charge</li> <li>Can't boot up</li> <li>Cannot pair with mobile phone</li> <li>Music volume cannot be adjusted</li> </ol>	<p><b>Prompt</b></p> <ol style="list-style-type: none"> <li>Please read this manual carefully before using the product and keep it in a safe place;</li> <li>For the first time, please fully charge the product yourself;</li> <li>If the product is not used for a long time (more than 3 months), please charge it;</li> <li>Select the charger that has been certified by the national CE certification.</li> </ol>	<p><b>Warning</b></p> <ol style="list-style-type: none"> <li>Do not dismantle or repair the modified microphone for any reason, otherwise it may cause fire, electronic breakdown, or even completely damage the product;</li> <li>Do not place the product in an environment where the temperature is too low or too high (below 0 °C or above 45 °C);</li> <li>Do not place the indicator light of the device near the eyes of children or animals;</li> <li>Do not use the product during thunderstorms. Thunderstorms may cause the device to malfunction and increase the risk of electric shock.</li> <li>Do not wipe the product with oil and other volatile liquids;</li> <li>Do not let the device get wet with liquids.</li> </ol>
Start up	blue light is always on																																																
Shutdown	indicator is off																																																
Low battery	red light is flashing																																																
When the microphone is in shutdown charging	red light is always on																																																
When the microphone is in shutdown charging	red light and blue light are always on at the same time																																																
When the microphone is power off and full charged	green light is always on																																																
When the microphone is power on and full charged	green and blue lights are always on																																																
Model	M1																																																
Microphone directivity	single directivity																																																
Speaker	5W/ Φ45mm																																																
Frequency response range	60Hz-20KHz																																																
Bluetooth version	4.2																																																
Connection distance	7 meters (accessibility and strong interference)																																																
Battery	3.7V/890mAh																																																
Charging input	DC5V/0.8A																																																
Charging time	about 1.5 hours																																																
Use time	about 4 hours																																																
Interface	USB Type-C																																																
Size	57.5mmX189.5mm																																																
Implementation standard	GB 8898-2011																																																