



THANK YOU FOR CHOOSING WET SOUNDS FOR YOUR HIGH PERFORMANCE AUDIO SYSTEM!

The WW-BT-RS is an easy to operate Bluetooth Source Controller.

Designed to mount in a standard Carling style opening, the BT-RS controls all Bluetooth functions as well as the system volume!

BLUETOOTH PAIRING INSTRUCTIONS:

STEP 1: Turn on WW-BT-RS by pressing the power  switch (1), which will be backlit RED momentarily, then WHITE constantly to indicate that the WW-BT-RS is ready to use.

STEP 2: If not already paired with another learned device, the WW-BT-RS will automatically enter pairing mode, which is indicated by the backlight flashing RED.

STEP 3: From your phone's Bluetooth pairing menu find the WW-BT-RS and connect to it.

You are now paired to the WW-BT-RS and will automatically default to this device if in range whenever the WW-BT-RS is powered on.

MOUNTING INSTRUCTIONS:

The WW-BT-RS is designed to snap into a standard Carling style switch opening, which is commonly used in the dashboard of many automobiles and off-road vehicles.

WIRING INSTALLATION INSTRUCTIONS:

RED WIRE Connect to +12V for Power


BLUE WIRE Connect to Amplifier Remote Wire
To turn on amp when the BT-RS is Powered on.

BLACK WIRE Connect to -12V for Ground

MAIN OUTPUT Connect to input of an amplifier

AUX INPUT Connect to an optional auxiliary source other than Bluetooth

OPERATING INSTRUCTIONS:



1. POWER PLAY/PAUSE

Press & hold to power on.

The BT-RS defaults to BT Mode, which is indicated by the center button constantly backlit WHITE.

Press once for play/pause

2. MODE

Press & hold to switch from BT to AUX input. When in AUX mode the center button will be constantly backlit RED.

3. VOLUME INCREASE

4. VOLUME DECREASE

5. TRACK ADVANCE

6. TRACK RETREAT

LIMITED WARRANTY:

What This Warranty Covers

This is a "limited" warranty. This warranty covers any defect in materials and workmanship. This warranty only covers the original purchaser and is not transferrable. This warranty is also only valid if the original purchase was made from an authorized Wet Sounds TM dealer.

How Long Coverage Lasts

This warranty extends for 2 years from the date of purchase. It is recommended to REGISTER your warranty online within 45 days of purchase at www.wetsounds.com – click on "warranty registration".

What Is Not Covered

This warranty does not cover fading or discoloration caused by exposure to sunlight or chemicals such as ammonia, household bleach, or any cleaning material that contains abrasive substances. Wet Sounds, Inc. does not cover the expense for removal or reinstallation. Additionally, shipping TO Wet Sounds, Inc. must be paid for by the purchaser. This warranty is void and inapplicable if Wet Sounds deems that the product was abused or misused; including but not limited to damage caused by accident, mishandling, improper installation, removing the inline fuse on the power connection, negligence, normal wear and tear, excessive water or heat damage, freight/shipping damage, or products that have been disassembled by anyone other

Federal Communications Commission (FCC) Statement

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Warning: Changes or modifications made to this device not expressly approved by VERTICAL WORLDWIDE TRADING LTD. may void the FCC authorization to operate this device.

Note: The manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications to this equipment. Such modifications could void the user's authority to operate the equipment.