

FCC Disclaimer:

This device Complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- 1- This device may not cause harmful interference, and
- 2- This device must accept any interference received, including Interference that may cause undesired operation. The manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications to this equipment. Such modifications could void the user authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or on experienced radio/TV technician for help or assistance.

This device complies with Part 15 of the FCC Rules and Industry Canada license-exempt RS5 standard(s). Operation is subject to the following two conditions;

- 1- This device may not cause harmful interference, and
- 2- This device must accept any interference received, including interference that may cause undesired operation. The manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications to this equipment. Such modifications could void the user's authority to operate the equipment. Under Industry Canada regulations, this radio transmitter may only operate using an antenna of a type and maximum (or lesser) gain approved for the transmitter by Industry Canada. To reduce potential radio interference to other users, the antenna type and its gain should be so chosen that the equivalent isotropically radiated power (e.i.r.p.) is not more than that necessary for successful communication.

Karaoke




MICROPHONE SPEAKER



INFO

**IMPORTANT:
PLEASE READ BEFORE USING THIS PRODUCT**



SPECIFICATIONS

Model No: SP -013

Bluetooth Ver: 4.2

Working Distance: Approx. 33ft

Playback Time: 4 Hours

Charge Time: 1.5 Hours

Speaker Output Power: 4W

Frequency: 100 Hz - 10 KHz

Box includes:

Karaoke speaker, Micro to USB charging cable, Micro-USB to Aux cable

Bluetooth® CONNECTION

1. To power the speaker on, press and hold the power button until the indicator light begins to flash. This means that your speaker has entered pairing mode.
2. Turn on your device's Bluetooth. From the Bluetooth menu select the "iW_SP-013" speaker.
3. When paired successfully the device will make a tone to confirm the connection has been made.

CHARGING

1. To begin charging your speaker, connect the provided micro USB cable to the speaker's charging port. Then connect the other end of the micro USB cable to your power source. Indicator light will turn on (red) when it's charging.
2. The red LED indicator light will turn off once your speaker has reached a full charge.
3. Always disconnect the cable when charging is finished.

HOW TO USE YOUR SPEAKER

1. You can connect the speaker to your device through Bluetooth or by using the Micro-USB to Aux cable (included).
2. Adjust the microphone volume by sliding the volume button up or down. Turn the microphone volume to minimum when you only use the speaker to listen to music.
3. Slide the reverb button to adjust the reverberation.
4. Remember to turn the speaker off by pressing and holding the power button after each use.