


**ENGLISH**

**OWLOTECH**

# EarTwins NEXT


Indicator



Charging connector 5V

**Docking station with built-in battery**


Power, play and phone calls sensor control area



L R

**Earbud**

## Connection




- 1 Disable Bluetooth on your phone
- 2 Take the headphones out of the case, wait until they connect
- 3 Turn on Bluetooth on your phone and connect to Ear Twins NEXT

**NOTE** If the headset is not connected to the smartphone, it will automatically turn off after 3 minutes

## Play/Pause


Triple touch: previous song  
Long press: increase volume

Triple touch: Next song  
Long press: decrease volume



Touch: Play/pause  
Double touch: voice assistant

## Charging



- Case is charging
- Case is charged
- Earbuds charging
- Earbuds charged

Lightning-USB 5V


**NOTE** If headset is not used for more than three months, it must be charged, to prevent internal battery malfunction.

**ESPAÑOL**

**OWLOTECH**

# EarTwins NEXT


Indicador



Conector de carga de 5V

**Estuche de carga con batería incorporada**


Área de control del sensor de encendido, reproducción y llamadas



L R

**Auricular**

## Conexión




- 1 Active el Bluetooth en su teléfono
- 2 Saque los auriculares del estuche y espere a que se conecten
- 3 Acceda al Bluetooth en ajustes de su teléfono y conéctese a los Ear Twins NEXT

**NOTA** Si los auriculares no están conectados al smartphone, se apagarán automáticamente después de 3 minutos

## Reproducir/pausar


Triple pulsación: canción anterior  
Pulsación larga: aumentar el volumen

Triple toque: canción siguiente  
Pulsación larga: bajar el volumen



Toque: Reproducir/pausar  
Doble toque: asistente de voz

## Carga



- El estuche se está cargando
- Estuche cargado
- Carga de los auriculares
- Auriculares cargados

Tipo C - USB 5V

**NOTA** Si los auriculares no se utilizan durante más de tres meses, deben cargarse, para evitar el mal funcionamiento de la batería interna.

## **FCC STATEMENT :**

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

**Warning:** Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.

- Increase the separation between the equipment and receiver.

- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

- Consult the dealer or an experienced radio/TV technician for help.

## **RF warning statement:**

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.