

**PANTONE Cool Gray 5c**




**MPOW**

MODEL: PA115A


**QUICK START GUIDE**

1. Long press the shutter for 3 seconds and when the blue light blinks (inside the shutter), it means iSnap X is ready to pair with your device.




2. Turn on Bluetooth of your device, search "Mpow iSnap X" and connect it. Blue light stays bright, and the phone shows "Connected" in the interface.

3. Rotate the holder for 270 degree (or so) to get a good viewing angle and screw the clamp. Hold the handle and stretch out the telescopic stick.



4. Place the phone on the foldable clamp. Open up your chosen camera app and press the shutter release button to take a photo.

NOTE: MAKE SURE THE PHONE WAS HOLDEN SECURELY.



Lights status	What it means
LED1: blue light blinks	iSnap X is in pairing mode, you can connect it to your device by Bluetooth
LED1: blue light on	iSnap X is connected with your device, you can use it as remote controller to take photos or record videos.
LED2: red light on	iSnap X is in charging status.

5. When you finish using it, take out your phone, draw back the telescopic stick, and rotate the holder back in place.

**MPOW**  
 Copyright © MPOW Inc. All rights reserved.  
 Model: PA115A  
 Input: DC 5V / 55mA  
  
 FCC-ID: 2AMH2-PA115A  
 MADE IN CHINA

If you have any question, please contact us by e-mail: support@xmpow.com  
 MPPA115AB

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.