

# Spec:

#### Remote control socket

Base type: Standard E26

Working voltage: 120VAC/60Hz

Maximum load: 40W

Wireless protocol: 433.925MHz Working temperature: 0~40°C Size: Die 60MM x 62mm Model


No.: IM040303



#### Remote control switch

Power: 3V(CR2032x1 included) Wireless protocol: 433.925MHz Working temperature: 0~40 °C Max Remote Control Distance: 35 meters. (Free Area) size: 70mm 115mm\* 14mm

Model No.: IM040304



#### How to use:

- 1. Install the remote control socket to the present standard E26 socket. Install the light bulb onto the remote control socket.
- 2. Mount the remote control switch to the wall mount or stick the switch to anywhere you like.

## How to pair?

- 1. Power the socket.
- 2. Long press set button 2 seconds. The button flashes blue slowly indicates the socket entered pairing mode.
- 3. Press the switch to pair. The button flashes 3 times indicates the switch and the socket paired succeed.
- \* Socket will quit the pairing mode if no switch been paired in 30 seconds. Or you may quit pairing mode by pressing the set button.


# How to unpair?

Long press set button 10 seconds to unpair all the switch that paired to this socket. The button flashes 3 times indicates the switch and the socket unpaired succeed.

## **Pairing options**

We have 2 optional control kits available for you.

- a. Multiple switches controls one socket. ( max 10 switches )
- b. One switches controls One socket.



#### **FCC Statement**

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

**Note:** This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- —Reorient or relocate the receiving antenna.
- —Increase the separation between the equipment and receiver.
- —Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- —Consult the dealer or an experienced radio/TV technician for help.

### **ISED RSS Warning:**

This device complies with Innovation, Science and Economic Development Canada licence-exempt RSS standard(s). Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

Le présent appareil est conforme aux CNR d'ISED applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes:

- (1) l'appareil ne doit pas produire de brouillage, et
- (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.