



**Portable Bluetooth® Speaker
with Carrying Strap**
EAS-3000



Instruction Manual

Please read before operating product

Thank You

We know you have many choices when it comes to technology; thank you for choosing us here at Naxa Electronics. Established in 2001 in Los Angeles, California, we are dedicated to delivering products that entertain and delight. We trust that you will be happy with your purchase. Please read this manual carefully and save it for refer and other product material at our website. Come visit us on the web at www.emersonaudio.com and see all that we have to offer!

In The Box


Please take a moment to make sure that you have everything in the list below. Although we make every effort to ensure that each Naxa device is securely packed and sealed, we know a lot can happen in between us and you. If anything is missing, check back with your local retailer to get immediate assistance. If they can not help you, please contact our Naxa Support team at www.naxa.com/supportcenter/.

- EAS-3000
- USB charging cable

Features

- Bluetooth® functionality allows you to wirelessly stream all your favorite entertainment content from Bluetooth-enabled devices in high-quality audio
- Play media from removable storage devices, such as TF memory cards and USB flash drives thanks to the built-in TF card slot and USB port
- Modern, stylish design and included carrying strap make this Bluetooth® speaker a welcome accessory for wherever you go
- LED indicator light keeps you in the know on all status updates
- High-power speaker produces peerless soft, clear, and dynamic sound
- Set the speaker down and enjoy your favorite tunes from across the room with ease thanks to the wireless range of up to 33 feet
- Manually connect external media devices via the 3.5mm auxiliary input, boasting a seamless connection with minimal transmission loss
- Tune in on all of your favorite local radio station with the FM radio tuner
- Accessories Included: USB charge cable, carrying strap, user manual

At A Glance



1. DC 5V slot: Standard Micro USB charging cable for power charging.
2. TF slot: It can decode and play MP3 format audio when a TF card is put into the slot.
3. USB slot: It can decode and play MP3 format audio when a USB flash drive is put into the slot.
4. AUX IN slot: Use 3.5mm auxiliary cable to connect to external media devices.
5. When playing music, Briefly press for last song. Press and hold to turn down the volume.

6. When playing music, briefly press for next song. Press and hold to turn up the volume.

7. When playing music, (USB card/TF card/Wireless/AUX in), briefly press to play/pause.

8. When playing music, (TF card/AUX in/USB card/Wireless), briefly press to switch modes. Press and hold to power on. Press and hold again to power off.

Connecting Power

Works on internal rechargeable Lithium battery. Please charge your speaker fully before first use. To charge the battery :

1. Using a Micro USB cable (included), insert the jack into Charging jack located at the back of the units and then plug the USB connector into the USB port on a computer for charging.
2. A red light aside will indicate the charging situation. When battery is full, the red light will turn off automatically.

Bluetooth® Mode

1. The Blue LED light will flash rapidly indicating your speaker is powered on and in pairing mode.
2. Select the pairing name “EMERSON EAS-3000” from your device s Bluetooth® menu and connect it, then the Blue LED light will go steady after connecting successfully.

NOTE: while playing music, the Blue LED light will flash slowly.

If connection fails, restart device and do steps 1 & 2 again.

Music Playback

Once you have paired an external media device with the twin speakers via Bluetooth®, you can play all of your favorite songs over the speakers. To do so:

1. Open the music library on your connected Bluetooth® media device.
2. Choose a song and begin playback to stream music through the connected twin speakers.

USB Mode

This speaker allows you to listen to music from USB flash drives. To do so, follow these steps:

1. Turn on speaker.
2. Then, press the mode button to cycle through modes until you are in “USB Mode”.
3. Insert the USB flash drive you wish to listen to into the USB port.
4. Press play to begin media playback.

During Playback:

- Hold the Volume Up/Down button to control volume.
- Briefly press the Volume Up/Down button to go to the next/previous track.

TF Mode

This speaker allows you to listen to music from TF memory cards. To do so, follow these steps:

1. Turn on speaker.
2. Then, press the mode button to cycle through modes until you are in "TF Mode".
3. Insert the memory card you wish to listen to into the TF card slot.
4. Press play to begin media playback.

During Playback:

- Hold the Volume Up/Down button to control volume.
- Briefly press the Volume Up/Down button to go to the next/previous track.

AUX Mode

This speaker allows you to listen to music from external devices via 3.5mm auxiliary connection. To do so, follow these steps:

1. Turn on speaker.
2. Then, press the mode button to cycle through modes until you are in "AUX IN" mode.
3. Insert one end of an auxiliary cable (not included) into the 3.5mm AUX port on the speaker.
4. Insert the other end of the auxiliary cable into the external media device you wish to listen to music from.
5. Press play to begin media playback.

During Playback:

- Hold the Volume Up/Down button to control volume.
- Briefly press the Volume Up/Down button to go to the next/previous track.

FM Mode

This speaker allows you to listen to all of your favorite local radio stations. To do so, follow these steps:

1. Turn on speaker.
2. Then, press the mode button to cycle through modes until you are in “FM” mode.
3. In FM mode, Press and hold the play/pause button to search stations automatically, briefly press to stop searching.

NOTE: When using FM mode, insert the USB cable in the USB port for better station reception

During Playback:

- Hold the Volume Up/Down button to control volume.
- Briefly press the Volume Up/Down button to go to the next/previous station.

Answering Phone Calls

Once you have paired an external media device with the twin speakers via Bluetooth®, you can answer, end, or make calls via your twin speakers. To do so:

1. To answer an incoming call, press the play/pause button once.
2. To end an ongoing call, press the play/pause button once again.
3. To redial a number, press the play/pause button twice.

Specifications

- BT version: 5.0
- Output Power: 10W*2
- Play time: 3-4 hours
- Charging time: 2-3 hours
- Supports: USB / TF / AUX
- Radio Tuner: FM
- Speaker: 4Ω 10W*2
- Lithium battery: 3000mAh
- Sensitivity: $\leq 1\%$
- Frequency response: 80Hz-20KHz
- SNR: $\geq 85\text{dB}$
- DC/5V: input DC 5V/0.5A
- Operating Voltage: DC 5V

FCC Notice

This device complies with Part 15 of the FCC Rules.

Operation is subject to the following two conditions:

(1) this device may not cause harmful interference, and

(2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference, will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which

can be-terminated by turning the equipment off and on,the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

CAUTION ON MODIFICATIONS

Any changes or modifications not expressly approved by the grantee of this device may void the authority granted by the FCC to operate the equipment.

RF Exposure Statement

The device has been evaluated to meet general RF exposure requirement. This equipment should be installed and operated with minimum distance 0mm between the radiator & your body.

Support

If you have problems with your device, please consult the instructions in this manual. Please also visit us on the web at www.emersonaudio.com to get up to the minute news, alerts, and documentation for your device. For additional assistance, please contact Naxa Technical Support.

NAXA Technical Support

2320 East 49th St.

Vernon, CA 90058

http://www.naxa.com/naxa_support/

MADE IN CHINA