

Wireless Earphone User Manual

Product Specifications

Bluetooth: V4.2

Driver Size: 9mm*2

Response Frequency: 20Hz-20KHz

Transmission: 360°, 10m

Impedance: 16ohm

Play Music time: 3-4 hour

Distortion: < 0.1%

Battery: 3.7V, 80mAh

Operating Instructions:

How to Power ON Your Earphones

Press & hold the  button for 3 seconds to turn on the earphones.

How to Power OFF Your Earphones

Once the earphones are is on, press & hold the  button for 3 seconds to turn off the earphones.

Initial Pairing

To use your Bluetooth earphones, you must first pair your earphones with a mobile phone. Once your Bluetooth earphones are paired to a mobile phone, they will remain paired and automatically recognize each other whenever they are within range.

1. Turn on your phone and ensure the Bluetooth function is activated.
2. Press & hold the POWER button for 3 seconds to turn ON until the red and blue lights flash (This means the headset has entered pairing mode)
3. Search the Bluetooth devices on your phone by following the phone's instructions. Refer to your phone's user manual for more information.
4. Click and pair.
5. The blue light flashes twice every five seconds means the pairing is successful

Please Note: If required, enter the password "0000". Select OK or YES to pair your device.

Auto Re-Connect

1. Turn your device's Bluetooth ON, before turning on the headset
2. The headset will connect automatically to the last paired device

Answer/End/Reject Call

Answering Call: During an incoming call, press the  button to answer the call.

Ending Call: When on a call, click the  button to end the call.

Redial: While on standby or playing music, double-click the MFB to dial the last call in your call log.

Play / Pause Music

Press the Multi-Function Button to play music and press it again to pause music.

Vol+/ Next Track

- Press and hold the  button to turn up the volume
- Click the  button to switch to the next song.

Vol-/ Previous Track

- Press and hold the  button to turn down the volume
- Click the  button to switch to the Previous song.

Charging Your Earphones

Use the Micro USB cable provided with these earphones. Connect the Micro USB plug to the Micro USB charging port on the earphones. Connect the USB plug to a USB port on a computer or wall adapter to activate charging. When there was a low voltage power, the machine will prompt "Low battery, please charge", and then will automatically shut down, please recharge.

Please note: The indicator light turns red when charging, the light will turn off when full of charge.

Federal Communications Commission (FCC) Interference Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules.

These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generate, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

FCC Caution: Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.

RF exposure warning

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. The equipment must not be co-located or operating in conjunction with any other antenna or transmitter.