

DO NOT USE LOW RESOLUTION PDF FILE FOR PRINTING. ONLY USE THE HIGH RESOLUTION AI FILE
这是一个低分辨率的PDF文件,绝对不能用来做印刷，只能用高分辨率的AI



Merkury Innovations **CONFIDENTIAL**

FILE INFORMATION
DATE: 08/28/23
FACTORY: DongShun Tech Development Limited
MODEL NUMBER:
MI-S305B-101

PRINTER SPECIFICATIONS
FILE NAME:
MI-S305B-101_Manual_082823_OL.ai
SCALE: 100%
SIZE: TRIM: W 220mm x H 164mm
PAPER STOCK: 80g Art Paper
INKS: 1/1
Grayscale
PRESS WORK / NOTES: Trim to size, score, fold, & glue in specified areas.

Trim

Score

DO NOT print Comments or Dielines.
Physical sample according to specs must be approved by MERKURY before proceeding to production.

CONTACT
MERKURY CHINA: Perry
perry@merkuryinnovations.com.cn

COMMENTS (Internal reference only)
File created by William
- Please include this manual in all packaging for MI-S305B-101
- Grayscale
- Double sided printing

TRUBLESHOOTING

No power

Recharge your Blast Wireless Speaker using the included USB Type-C cable. Try using a different cable.

Music is not playing over Bluetooth

Check if both devices are paired and connected over Bluetooth®. Restart the speaker to reconnect your Bluetooth® device.

Bluetooth device will not reconnect with the speaker

Navigate to your Bluetooth® settings menu on your Bluetooth® device, tap “Merkury S305B” and select “Forget”. Now follow the steps to pair your device again.

TECHNICAL SUPPORT

If you are experiencing problems, do not attempt to fix the product by yourself or return it to the store you bought it from. Please refer to the user manual or just contact our helpful support team:

Merkury Innovations
45 Broadway, 3rd Floor,
New York, New York 10006
www.merkuryinnovations.com
support@merkuryinnovations.com

This device complies with Part 15 of the FCC Rules. Operation is subject to the two following conditions:
1. This device may not cause harmful interference.
2. This device must accept any interference received, including interference that may cause undesired operation.

©2023 Merkury Innovations, LLC.
To explore our full selection of products, visit us at: www.merkuryinnovations.com

Bluetooth is a registered trademark of Bluetooth SIG, Inc.
The illustrated product and specifications may differ slightly from those supplied.
All other trademarks and trade names are those of their respective owners.

Made in China

FC

CE

Recycle

RoHS

Merkury Innovations

Bluetooth®

BLAST

Portable Indoor/Outdoor Bluetooth Speaker

USER'S MANUAL:
MI-S305B

INCLUDES:
• BLAST Speaker
• USB Type-C Cable
• User Manual

IMPORTANT! PLEASE READ BEFORE USING THIS PRODUCT

OUTSIDE

CHARGE

• Plug the USB Type-C cable into the Type-C port on the side of the speaker, and connect the other end of the cable with any compatible USB charger or USB power wall adapter.

• When charging, the small LED indicator will glow red. When fully charged, the LED indicator will turn off.

• Charging time is approximately 3-4 hours.

PAIR & CONNECT

• Press and hold the power button on the speaker to turn it ON or OFF.

• Make sure the speaker is turned ON. Speaker must be ON to turn the lights on.

• On your Bluetooth® enabled device, navigate to the Bluetooth® settings menu, turn on the Bluetooth® feature, and search for new devices.

• Wait a few seconds & select “MERKURY S305B”. The speaker will emit a tone when successfully paired.

NOTE:
• If your device's Bluetooth® version is below version 2.1, you may need to enter the password “0000”.
• Speaker will switch to USB, MicroSD, or AUX mode automatically when an input is detected.

RECONNECT TO BLUETOOTH®

• You only need to pair your Bluetooth® device with the speaker once.

• With your previously paired device's Bluetooth® turned on & in range, power on the speaker.

• The speaker will automatically reconnect to the last Bluetooth® device it was connected to.

• If you have a previously paired device that does not auto-reconnect, navigate to the Bluetooth® settings menu on your device, turn on the Bluetooth® feature, and select “MERKURY S305B” from your list of paired Bluetooth® devices.

ON-BOARD CONTROLS (TOP)

VOLUME +
PRESS
NEXT TRACK

PLAY/PAUSE
CLICK TO SWITCH FUNCTIONS

MODE KEY
CLICK TO SWITCH FUNCTIONS

LIGHT SWITCH
ON/OFF

PRESS & HOLD
ON/OFF
PREVIOUS TRACK

VOLUME -
PRESS
PREVIOUS TRACK

SPEAKER INPUTS (BACK)

MicroSD Card Input

LED Charging Indicator

3.5mm AUX Input

USB Input

5V

USB Type-C Charging Input

SPECIFICATIONS

• Speaker Specifications:
Frequency Response: 80HZ~10KHZ
Speaker: 57mm 2.4Ω10W

• Power Information:
Input: DC5V
Battery Capacity: 1200mAH
Music playing time: Up to 6 Hours*

• Additional Connection Sources:
Audio: 3.5mm AUX cable
Power Source: Built-in rechargeable battery or via Type-C USB cable
Support U disk/TF card/AUX play mode

• Bluetooth® Information:
Bluetooth® Version: 5.0
Operating Distance: 5*2w.
System Requirements: Bluetooth®-capable device

*Depends on individual use and may be slightly more or less than the time specified.

INSIDE

FCC STATEMENT :
This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) This device may not cause harmful interference, and
(2) This device must accept any interference received, including interference that may cause undesired operation.
Warning: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
Reorient or relocate the receiving antenna.
Increase the separation between the equipment and receiver.
Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
Consult the dealer or an experienced radio/TV technician for help. RF warning statement:
The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.