



TWS Dual Bluetooth® Speakers

Combo

NAS-3105D



Instruction Manual

Please read before operating product

Thank You

We know you have many choices when it comes to technology; thank you for choosing us here at Naxa Electronics. Established in 2001 in Los Angeles, California, we are dedicated to delivering products that entertain and delight. We trust that you will be happy with your purchase. Please read this manual carefully and save it for refer and other product material at our website. Come visit us on the web at www.naxa.com and see all that we have to offer!

In The Box



Please take a moment to make sure that you have everything in the list below. Although we make every effort to ensure that each Naxa device is securely packed and sealed, we know a lot can happen in between us and you. If anything is missing, check back with your local retailer to get immediate assistance. If they can not help you, please contact our Naxa Support team at www.naxa.com/supportcenter/.

- NAS-3105D
- USB charging cable

Features

- Stereo speakers deliver outstanding power and sound (5W x 1)
- Play music wirelessly from your Bluetooth® enabled smartphone, tablet, or laptop
- TWS function allows you to connect speakers and seamlessly stream music from both across rooms
- Manually connect to external devices to stream music via memory card, AUX IN, or USB
- Use as a speakerphone with a connected smartphone
- Built-in rechargeable battery

At A Glance



1. Charge Indicator
(Red when Charging,
off when full)

2. Charge Port

3. AUX Port

4. USB Slot

5. TF Card Slot

6. Power Switch
off when full)

7. Volume Down

8. Pause/Play/Mode

9. Volume Up

Connecting Power

Your speakers has an integrated rechargeable battery. Upon initial use, the battery should be charged fully to ensure optimal performance and battery life. Use the included USB charging cable to connect the speakers to a USB power source to charge the battery.

- Connect the small end of the cable to the DC 5V USB charge port of the unit.
- Connect the large end of the cable to a high-power USB port of a computer. The computer should be powered on.

The Status LED will light red when the battery is charging. When charging is complete, the Status LED will turn off.

Bluetooth® Mode

This speaker allows you to listen to music wirelessly via Bluetooth® mode. To do so, follow these steps:

1. Turn on speaker (slide the button to “On”), the Speaker will sound a voice prompt “BT Mode”. Then, the blue light will begin flashing, and it’s in BT mode.
2. Turn on BT mode in Mobile/Device Bluetooth menu. Next, search the model name “NAS-3105D” click to connect. Then, after a few seconds, the speaker will sound an audio “Ding” to notify you of a successful connection.

If connection fails, restart device and do steps 1 & 2 again.

During Playback:

- Hold the Volume Up/Down button to control volume.
- Briefly press the Volume Up/Down button to go to the next/previous track.

USB Mode

This speaker allows you to listen to music from USB flash drives. To do so, follow these steps:

1. Turn on speaker (slide the button to “On”), the Speaker will sound a voice prompt “BT Mode”. Then, press the mode button to cycle through modes until you are in “USB Mode”.
2. Insert the USB flash drive you wish to listen to into the USB port.
3. Press play to begin media playback.

During Playback:

- Hold the Volume Up/Down button to control volume.
- Briefly press the Volume Up/Down button to go to the next/previous track.

TF Mode

This speaker allows you to listen to music from TF memory cards. To do so, follow these steps:

1. Turn on speaker (slide the button to “On”), the Speaker will sound a voice prompt “BT Mode”. Then, press the mode button to cycle through modes until you are in “TF Mode”.
2. Insert the memory card you wish to listen to into the TF card slot.
3. Press play to begin media playback.

During Playback:

- Hold the Volume Up/Down button to control volume.
- Briefly press the Volume Up/Down button to go to the next/previous track.

AUX Mode

This speaker allows you to listen to music from external devices via 3.5mm auxiliary connection. To do so, follow these steps:

1. Turn on speaker (slide the button to “On”), the Speaker will sound a voice prompt “BT Mode”. Then, press the mode button to cycle through modes until you are in “AUX IN” mode.
2. Insert one end of an auxiliary cable (not included) into the 3.5mm AUX port on the speaker.
3. Insert the other end of the auxiliary cable into the external media device you wish to listen to music from.
4. Press play to begin media playback.

During Playback:

- Hold the Volume Up/Down button to control volume.
- Briefly press the Volume Up/Down button to go to the next/previous track.

Specifications

- Bluetooth Version: 5.0V
- Power: 5W*1
- Speaker unit: 78mm, 4Ω 5W
- Frequency Range: 33ft / 10m
- Frequency Response: 100Hz-18KHz
- Battery: 3.7V 1200mAh
- Play Time: 3-4 hours
- Charging voltage: 5V
- Support: TF card / USB / AUX / TWS

FCC Notice

This device complies with Part 15 of the FCC Rules.

Operation is subject to the following two conditions:

(1) this device may not cause harmful interference, and

(2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference, will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which

can be-terminated by turning the equipment off and on,the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC Radiation Exposure Statement:

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.

CAUTION ON MODIFICATIONS

Any changes or modifications not expressly approved by the grantee of this device may void the authority granted by the FCC to operate the equipment.

Support

If you have problems with your device, please consult the instructions in this manual. Please also visit us on the web at www.naxa.com to get up to the minute news, alerts, and documentation for your device. For additional assistance, please contact Naxa Technical Support.

NAXA Technical Support

2320 East 49th St.

Vernon, CA 90058

http://www.naxa.com/naxa_support/

MADE IN CHINA