



True Wireless Earphones & Charging Case

NE-980



Instruction Manual

Please read before operating product

Table of Contents

Introduction.....	3
Package Contents.....	3
Safety Instructions.....	4
Product Breakdown.....	6
How to Use.....	7
LED Overview.....	12
Specifications.....	13
Support.....	15

Introduction

Congratulations, and thank you for choosing Naxa's True Wireless Bluetooth® Earphones & Charging Case. This manual will help you operate your new device, but first you should familiarize yourself with the Bluetooth functionality of your mobile phone or other external devices before using the Naxa True Wireless Bluetooth® Earphones & Charging Case.

Package Contents

- NE-980
- USB Charging Cable
- Instruction Manual

Safety Instructions


Before using the device, read the operating instructions very carefully. Keep this operation manual for later reference.

1. Do not use an appliance for any purpose other than its intended use.
2. Warning: Do not expose the appliance to extreme temperatures, to strong temperature fluctuations, direct sunlight or humidity.
3. To prevent any potential auditory damage, do not listen to music at high volumes for long periods.
4. No naked flame sources, such as lit candles, should be placed on the appliance.
5. This appliance should be used in temperate climate only.
6. Electric and electronic equipment should be disposed of separately. Do not discard used electric and electronic equipment with unsorted municipal waste but have them collected separately.
7. Attention should be drawn to the environmental aspects of battery disposal.
8. The appliance contains a battery or batteries that are non-replaceable.

9. Batteries (battery pack or batteries installed) shall not be exposed to excessive heat such as sunshine, fire or the like.
10. The battery must be removed from the appliance before it being disposed of properly.
11. Only remove the rechargeable battery when you intend to dispose of the appliance. Have the rechargeable battery removed by trained professionals.
12. **CAUTION!** Risk of explosion if battery is replaced by an incorrect type of battery.
13. Dispose of used batteries according to the instructions

Product Breakdown

1. Multi-Function Button
2. LED Indicator (Earphones)
3. Charging Case
4. LED Indicator 1 (Charging Status of Earphone)
5. LED Indicator 2 (Charging Status of Case)
6. Power Button
7. Micro USB Port



How to Use

Unpack all parts and check for damage that may have occurred during transportation. If any parts are damaged or missing, contact our after-sales service team. Clean the appliance and its components.

- Fully charge the earphones and the case before first use.
- Charge the case first, or insert the earphones into the case to charge both at the same time via the micro-USB charging cable.
- Disconnect the USB cable after charging.

WARNING: Never use detergent, solvents/abrasive products, scouring pads, abrasive cleaners, sharp objects or wire brushes to clean the product.

Storage:

- Store the earphones in the charging case.
- Recharge the case regularly when not using it for extended periods of time (e.g. more than 6 months).

Bluetooth® Operation

1. Remove the earphones from the charging case.
2. Press and hold the Multifunction button (1) on both earphones for 2 seconds until you hear the voice prompt "POWER ON" and the blue and red LEDs (2) start to blink alternately on both earphones (Pairing Mode).
3. Turn on Bluetooth on your connecting (mobile) device. Search for the earphones on your device and choose the name "NAXA NE-979" to connect.
4. After pairing is successful, the blue LEDs (2) on both earphones will blink slowly, and you will hear the voice prompt "CONNECTED".

Note: If you have paired the earphones successfully, the earphones will automatically reconnect to the paired device the next time you turn them on within range of each other and when Bluetooth is enabled on your mobile device.

Low battery may result in a poor Bluetooth connection.

If the Bluetooth connection is lost, recharge the batteries and follow the steps above to pair them again.

Playback

1. To play a song through your bluetooth earbuds from your mobile phone, press the multi-function button once.
2. To pause a song, press the multi-function button once again.

Answering Calls

1. To answer incoming calls, briefly press the multi-function button once.
2. To end a call, briefly press the multi-function button again.
3. To reject an incoming call, press and hold the multi-function button for 2 seconds.
4. To redial a number, press the multi-function button twice.

Charging Earbuds

1. Open the lid of the charging case.
2. Insert the earphones into the case.
3. Press the power button (6) on the bottom of the charging case. The earphones will start to charge.
4. The LEDs (2) will show the charging status of the earphones:
Red – charging
Off – fully charged

Note: When the earphone batteries are low, an alert tone will indicate a low battery and the blue LED indicators (2) will blink slowly.

Charging Case

When fully charged, the case provides 2.5 full charges to the earphones.

1. Insert the micro-USB connector into the micro-USB charging port (8) on the back of the case.
2. Connect the USB-A plug on the cable into your

computer or a USB power adapter plugged into a wall socket.

3. The LED (4) on the charging case will show the charging status of the earphones when they are in the case:

Blue – charging

Off – fully charged

4. The LED (5) on the charging case will show the charging status of the case:

Red and blinking – charging

Red – fully charged

5. Disconnect the USB cable when charging is complete.

Note: When the earphone batteries are low, a voice prompt will indicate a low battery and the LED indicators (2) will flash in Red.

LED Overview

Charging Case Status	LED Indicator (5)	-
Charging	links red	-
Fully charged	Red-	
Earphones Status	LED Indicator (L/R) (2)	LED Indicator (4)
Charging in charging case	RedB	blue
Fully charged	Off	Off
Power on	Blinks red & blue alternately three times	Blinks red & blue alternately three times
Pairing mode	Blinks red and blue alternately	Blinks white and red alternately
Paired	Blinks blue slowly	Blinks blue slowly

Specifications

Bluetooth® Version: 5.0

Charging Interface: Type-C

Power Input: DC/5V, 0.5A

Working Distance: Up to 33 Ft.

Earbuds Battery Capacity: 45mAh/3.7V

Support: A2DP/AVCTP/AVDTP/AVRCP/HFP Music

Time: Up to 3 Hours

Charging Time: 1-2 Hours (Case), 1-1.5 Hours (Earphones)

CAUTION ON MODIFICATIONS

Any changes or modifications not expressly approved by the grantee of this device may void the authority granted by the FCC to operate the equipment.

FCC STATEMENT :

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

This device may not cause harmful interference, and

This device must accept any interference received, including interference that may cause undesired operation.

Warning: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

Reorient or relocate the receiving antenna.

Increase the separation between the equipment and receiver.

Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

Consult the dealer or an experienced radio/TV technician for help.

RF warning statement:

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

Support

If you have problems with your device, please consult the instructions in this manual. Please also visit us on the web at www.naxa.com to get up to the minute news, alerts, and documentation for your device. For additional assistance, please contact Naxa Technical Support.

NAXA Technical Support

2320 East 49th St.
Vernon, CA 90058

http://www.naxa.com/naxa_support/
MADE IN CHINA