



WIRELESS P2 CONTROLLER

WIRELESS P2 GAME CONTROLLER

Appearance and Key List

The image below shows the location of the switches and buttons. Each function is outlined below. (The illustration is for reference only. Certain controller functions are incompatible with some games.)

1 START

Press the button to start the game and press it again to pause.



2 Directional Pad (D-Pad)
Directional Pad for game playing.

3 Power Indicator

Press any key and the indicator will light up if there is still battery power left in the controller.

4 Power

Turn the controller's power ON/OFF.



NOTE:
Button functions may vary depending on game.

HOW TO PAIR THE CONTROLLER WITH THE BLAST! HDMI DONGLE

1

Turn the controller's power off.

2

Press and hold Game key A and press Up on D-pad for 5 seconds until the power indicator starts blinking after completing Step 3.

3

Turn the controller's power on.

4

Plug the small end of the USB cable into the Micro-USB port on your HDMI dongle.

5


Plug the large end of the USB cable into a USB port or USB AC adapter (not included) to turn on the HDMI dongle.

6

When the power indicator stops blinking, you have completed pairing.

NOTE : If the controller is not working, the batteries may have run out. Please change the batteries.

HOW TO CONFIRM THE WIRELESS CONTROLLER CONNECTS TO THE BLAST! HDMI DONGLE



Insert two AAA batteries into the back of the controller.



Power on the system. Press any button on the controller and it will connect to the HDMI dongle automatically.



The Power indicator light will blink. Repeat for the second controller.

NOTE :

If a controller button has not been pressed for a while, the controller will enter standby mode.

Press any button to wake the controller from standby.

Each wireless controller requires 2 AAA batteries, not included.

Controllers from previous AtGames' consoles are not supported.

HOW TO PLAY TWO-PLAYER GAMES

1

Power on your Blast! dongle.

2

Enter any 2-player game using the P1 controller.

3

Press **START** on your P2 controller to join the game.

Find out more about Blast!™ at:
<https://blast.atgames.net>

Battery Safety

- Never try to short-circuit the battery terminals.
- Rechargeable batteries are to be removed from the device before being charged.
- Rechargeable batteries are only to be charged under adult supervision.
- Do not charge non-rechargeable batteries.
- Batteries are to be inserted with the correct polarity as indicated inside the battery compartment.
- Do not mix old and new batteries. Do not mix batteries of different types: standard (carbon-zinc), alkaline, or rechargeable (nickel-cadmium).
- Remove batteries during long period of non-use.
- Always remove dead batteries from the product.
- Dispose of batteries safely. Do not dispose this product or any batteries in a fire.

FCC Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

For remoter

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 0mm between the radiator and your body. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

ISED Statement

This device complies with Industry Canada license-exempt RSS standard(s). Operation is subject to the following two conditions: (1) This device may not cause interference, and (2) This device must accept any interference, including interference that may cause undesired operation of the device.

The digital apparatus complies with Canadian CAN ICES-3 (B)/NMB-3(B).

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes: (1) l'appareil ne doit pas produire de brouillage, et (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

L'appareil numérique du CIEM conforme canadien peut - 3 (b) / nmb - 3 (b).

For remoter

This device meets the exemption from the routine evaluation limits in section 2.5 of RSS 102 and compliance with RSS 102 RF exposure, users can obtain Canadian information on RF exposure and compliance.

Cet appareil est conforme à l'exemption des limites d'évaluation courante dans la section 2.5 du CNR - 102 et conformité avec RSS 102 de l'exposition aux RF, les utilisateurs peuvent obtenir des données canadiennes sur l'exposition aux champs RF et la conformité.

This equipment complies with Canada radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 0mm between the radiator & your body.

Cet équipement est conforme Canada limites d'exposition aux radiations dans un environnement non contrôlé. Cet équipement doit être installé et utilisé à distance minimum de 0mm entre le radiateur et votre corps.