

1

2

3

4

5

6

Remark	Description	Editor	Date

A

B

C




D


A

B


C

Quick Installation Guide

- Power MRE220 up via a USB charging port near your main Wi-Fi. Proximity to main Wi-Fi is required only during the initial setup process.
 
- Wait for the LED to flash amber and green alternatively. Then connect smartphone or PC to MRE220's Wi-Fi network.
 
- Enter www.meross.net in the address field of browser and simply follow the in-built setup wizard.
 

 P/N:610200001

LED and Button Rules



- Solid amber:** Initialization/Reset/Firmware upgrading mode
- Flashing amber and green slowly:** Configuring mode
- Flashing green rapidly:** Wi-Fi connecting mode
- Solid green:** Successfully connected, good signal
- Flashing green slowly:** Successfully connected, poor signal
- Solid red:** No internet connection
- Reset button**

Frequently Asked Questions

- How to factory reset MRE220?**
Insert a pin into the reset hole and hold (for 5 seconds) until LED is lit a solid amber to initiate factory reset process.
- What should I do when the LED is lit a solid red?**
A solid red indicates no internet connection. You can troubleshoot the following:
 - Check the main Wi-Fi's internet connection.
 - Make sure that main Wi-Fi's password hasn't been changed.
 - Make sure your MRE220 is not too far from the main Wi-Fi.
 - Factory reset MRE220 and try to add it again.
- How many clients does MRE220 support?**
MRE220 supports up to 16 clients.
- How to upgrade the firmware of MRE220?**
This function is only applicable on desktop/laptop PCs. Firstly, visit www.meross.com/support to download the latest firmware and reset MRE220. After that, connect PC to MRE220's Wi-Fi and visit www.meross.net to implement the firmware upgrade.

©2017 Meross. All rights reserved

FCC statement

This device complies with Part 15 of the FCC Rules: Operation is subject to the following two conditions:

1. This device may not cause harmful interference and
2. This device must accept any interference that is received, including any interference that may cause undesired operation.

This device is acting as slave and operating in the 2.4 GHz (2412 ~2462 MHz) band.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help

Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.