

User Manual

SK509-W-N is a wifi Wireless's socket , the hardware include one keyswitch, one wifi chip (BK7231N) ,two outputs and two blue LEDs.Its working principle is divided into:The Smart Phone control socket through the internet or 4G net. BK7231N responsible for the function keyswitch signals are transmitted to a control part.Control part based on the keyswitch information,control LED and RELAY output ON or OFF.

The shell side of the appliance has one button and two indicators. There are two types of keystrokes: tap and long.

- Tap the switch to control the socket, the light is on when on, and off when off;
- Press and hold into the EZ distribution status, the light flashes, at this time can be in accordance with the EZ configuration method for the distribution of the network;
- Press and hold again when flashing, will enter the AP distribution status, the indicator flashes slowly, at this time according to the AP configuration method for the distribution.

Register

If you don't have the account of Tuya Smart APP yet, you could register an account or sign in with cellphone number+ verification code. This page describes the Registration process.

1. Tap "Register" on the upper right
2. The system will automatically recognize your country I area. You can also select your country code by yourself. Enter the cellphone number / E-mail and tap "Next"
3. If you entered the mobile cellphone number, you gonna enter the verification code you received, and then enter the password, finally, tap "Confirm" to finish your registration.
4. If you entered the E-mail address, enter the password, then tap "Confirm" to finish your registration.

Sign in with cellphone number+ verification code

1. Tap "Sign in with SMS verification" to enter a new page.
2. The system will automatically recognize your county/ area. You can also select your country code by yourself.
3. Enter the cellphone number and tap "Get" to get a message.
4. Enter the verification code in the message and tap "Login" to login the app.

Sign in with account number+ password

- 1.The system will automatically recognize your county/area.
You can also select your country code by yourself.
- 2.Enter the registered cellphone number / E-mail and password, then tap "Login" to login the app.

Sign in with social media account

If you have installed Facebook or Twitter in your cellphone, tap the corresponding icons and then sign in the app after social network authentication.

FCC STATEMENT :

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

Warning: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.

- Increase the separation between the equipment and receiver.

- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

- Consult the dealer or an experienced radio/TV technician for help.

FCC Radiation Exposure Statement:

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.