


Lenovo SE-631 TWC

Safety, Warranty &Quick Start Guide

True Wireless Earbuds

Lenovo

What's In The Box



1. Charging Case
2. Earbuds LED Indicator
3. Touch Panel
4. Charging Case LED Indicator

5. Type-C Connector

* Before using it for the first time, please tear off the isolation film on the headset, put the earbuds into the charging box, and the red indicator light of the earbuds lights up to the charging state to indicate the activation is completed.

Pair

Bluetooth pairing (automatic pairing when taking out the headset from the charging box)

1. The earbuds switch on automatically when taken out of the charging case.

2. The earbuds enter pairing mode after 2 seconds, rapidly flashing white/red.

3. Select "Lenovo SE-631TWC" in the Bluetooth list of the mobile device, and pair with the device.

4. Once successfully paired, the white light of the indicator will flash slowly.

Choose Your Ear Tips

Ear tips x6 (Size S/M/L)

Note: The size M ear tips are attached to the ear buds in-box

Touch Function

To play/pause

Tap the touch panel of the left/right earbuds twice.

To Pick/Hang up call

Tap the touch panel of the left/right earbuds twice.

To next song/previous

Press the left earbud touch panel and hold 2s to previous song

Press the right earbud touch panel and hold 2s to next song

Activate voice assistant

Tap the touch panel of the left/right earbuds 3 times

Bluetooth disconnected into pairing mode

Tap the touch panel of the left/right earbuds 7 times

How to manually reset the earbuds.

Reset the earbuds if you can only hear music/voice on one side after pairing with your mobile device.

Charging

Ear buds Charge

Charging starts after insert the earbuds into the charging box, the red

Earbuds LED indicator will turn slowly while charging, and the red light will turn off after charging is complete.

Charge the charging case

Charging starts after insert the earbuds into the charging box, the Charging Case LED indicator is always on while the power is connected.

Note: Power less than 25%: One solid LED light

Power less than 50%: One solid, one flashing LED light

Power less than 75%: Two solid, one flashing LED light

Power less than 100%: Three solid, one flashing LED light

Charging complete: Four solid LED light

IMPORTANT

The operation of switching on your hi-fi system may cause clicks which at high volume settings may affect your hearing. Therefore, always set the volume control to minimum before switching between different sources.

Device models equipped with wireless communication comply with the radio frequency and safety standards of any country or region in which it has been approved for wireless use.

Please read the Regulatory Notice for your country or region before using the wireless devices contained in your device. To obtain a PDF version of the Regulatory Notice, go to

<https://upr.lenovo.com>

© Copyright Lenov 2020.
Reduce | Reuse | Recycle



1. Turn off the Bluetooth on your mobile device, and insert both earbuds into the charging case.

2. Remove one earbud from the charging case.

3. Tap the touch panel 7 times to enter pairing mode (Earbud light rapid flash white/red).

4. Tap the touch panel 6 times to reset pairing (Earbud light flash white 3 times then shut off), then place the earbud into the charging case.

5. Repeat steps 2-4 for the 2nd earbud.

6. Remove both earbuds from the charging case, and the earbuds will be paired automatically within 3 seconds.

7. Reconnect / re-pair with your mobile device.

Auto reconnect

After the pairing is recorded, unplug the earbuds from the charging case, and the earbuds will automatically reconnect to a recently connected mobile phone.

Note: The Bluetooth of the mobile phone needs to be turned on, and the mobile phone is within the effective Bluetooth connection range of the earbuds.

How to choose a suitable charger

It is recommended to use the power adapter that complies with applicable national/ regional regulations or one of the following standards: IEC60950-1/IEC62684 or other applicable interoperability standards of power adapters. Only use an adapter that complies with international and regional safety standards (including IEC60950/ IEC62684) for charging. Do not use an adapter rated at more than 5.2V or less than 5A as this may damage the device. Other adapters may not comply with applicable safety standards and using such adapters to charge may result in injury or death.

Bluetooth remote disconnection and reconnect

1. If the earbuds are disconnected with the mobile phone and return to the effective connection range within 10 minutes, Bluetooth will automatically reconnect.

2. If the earbuds are disconnected with the mobile phone and return to the effective range after 10 minutes, Bluetooth needs to be reconnected manually.

Note: If the earbuds cannot automatically reconnect with the phone, please manually connect on the Bluetooth interface of the phone.

Specifications

Model: Lenovo SE-631TWC

Product size: 1x1x3.3mm

Product weight: 4.1g (single ear bud), 6.2g (two earbuds and charging case)

Drive: 5.8mm bidirectional speaker

Input: 5V/1.0A

Audio decoding: SBC

Frequency response range: 20-20kHz (Bluetooth)
Sensitivity: 93dB±3dB
Connection method: USB-C to USB-A charging cable
Support modes: BT 5.0, HSP v1.2, HFP v1.7, A2DP v1.3, AVRCP v1.6
Bluetooth frequency: 2.402-2.480GHz
Bluetooth power: <8.0dBm
Bluetooth range: 10m
Battery Specifications: Rechargeable polymer lithium ion battery (ear buds: 3.7V, 43mAh charging box: 3.7V, 210 mAh)
Battery charge: 2 hours
Play time: 4 hours for earbuds, 10 hours of use for earbuds with the charging case.
Waterproof level: IPX5 for the earbuds, charging case is not waterproof.

Regulatory and important safety information

Before using and operating the device, read and follow the precautions below to ensure that the equipment performs optimally and avoids dangerous or illegal conditions

1. Do not use this device in dusty, humid, dirty environment or places near magnetic field to avoid malfunction of the internal circuit of the device.
2. Do not cover, seal or put other items on the device.
3. Keep the device away from heat sources or bare fire like electric heaters, microwave ovens, stoves, water heaters, candles or any place with high temperature conditions.
4. Do not use an external heating appliance such as a hair dryer or microwave to dry the device.
5. Avoid striking the device and its accessories to a hard object or vice versa as it may lead the battery to explode or might cause malfunction.
6. Wipe the device with a clean, dry, soft cloth. Do Not use the device before cleaning and maintenance.

7. Use and store the device and its accessories in the temperature range of 0°~45°. When the environmental temperature is too high or too low, it may cause device malfunction. The battery efficiency would be limited when the temperature is lower than 0°.
8. Keep the device and its accessories in a ventilated and cool environment without exposing it to direct sunlight.
9. This device is not a toy and children may use this device under adult supervision. This device and its accessories may contain small parts that should keep away from children. Children may inadvertently damage the device and its accessories, or swallow small parts resulting in suffocation or other hazards.
10. The device is equipped with non-removable built-in rechargeable battery. Do Not replace the battery by yourself. The battery can only be replaced by authorized service center. To avoid replacement of a battery with an incorrect type.
11. General recycling statement: Lenovo encourages owners of information technology (IT) equipment to responsibly recycle their equipment when it is no longer needed. Lenovo offers a variety of programs and services to assist equipment owners in recycling their IT products. For information on recycling Lenovo products, go to <http://www.lenovo.com/recycling>.
12. In medical and health care facilities where the use of wireless devices is prohibited, comply with the regulations of such facilities and turn off the device.
13. Radio waves generated by devices may affect the normal operation of implantable medical devices or personal medical devices, such as pacemakers, cochlear implants, hearing aids, etc. If you use any of these medical devices, consult their manufacturer about the use restrictions of the device.
14. Keep the device at least 15cm away from the implanted medical device such as pacemaker, cochlear implants etc.
15. Use of unauthorized or incompatible power supplies, chargers or batteries may cause fire, explosion or other hazards.
16. Danger: Plastic bags can be dangerous. Keep plastic bags away from babies and children to avoid danger of suffocation.

Informational Note for Customers in U.S.A. Only:

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.

- Increase the separation between the equipment and receiver.

- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

- Consult the dealer or an experienced radio/TV technician for help.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules.

Operation is subject to the following two conditions:

(1) this device may not cause harmful interference.

(2) this device must accept any interference received, including interference that may cause undesired operation.

This device complies with FCC's radiation exposure limits set forth for an uncontrolled environment.



Lenovo Products meet the requirement of Directive 2011/65/EC on the restriction of the use of the certain hazardous substances in electrical and electronic equipment ('RoHS 2'). Lenovo products sold in the European Union, from the 21st July 2019, meet the

Informational Note For Customers In EU Only:

Important battery and WEEE information

Batteries and electrical and electronic equipment marked with the symbol of a crossed-out wheeled bin may not be disposed as unsorted municipal waste. Batteries and waste of electrical and electronic equipment (WEEE) shall be treated separately using the collection framework available to customers for the return, recycling, and

treatment of batteries and WEEE. When possible, remove and

isolate batteries from WEEE prior to placing WEEE in the waste

collection stream. Batteries are to be collected separately using the

framework available for the return, recycling, and treatment of batteries and accumulators. Country-specific information is available at:

<http://www.lenovo.com/recycling>.



Compliance with the RE Directive

Lenovo PC HK Limited declares that the radio equipment type Lenovo SE-631TWC is in compliance with Directive 2014/53/EU. The full text of the EU declaration of conformity is available at the following internet address: <https://www.lenovo.com/us/en/compliance/eu-doc>.

This radio equipment operates with the following frequency bands and maximum radio-frequency power:



Battery recycling information for the United States and Canada



US & Canada Only

Battery recycling information for the European Union



EU

EU