


5000mAh Control Box With Power Bank
Instruction Manual
MSL-6022

READ ALL INSTRUCTIONS CAREFULLY BEFORE USE AND KEEP THIS MANUAL

Features



- 1.USB Output
- 2.Type-C Input
- 3.Audio Output (Left and Right)
- 4.LED Indicators
- 5.ON/OFF Button

What's included

- 1 × 5000mAh Control Box With Power Bank
- 1 × USB A to Type-C Charging cable
- 1 × Instruction Manual

Tech Specifications

- Battery: 5000mAh/3.7V 18.5Wh
- Audio Output L/R: left channel, right channel
- USB A output: 5V/2A
- Type-C input: 5V/2A

Instructions

Charge the power bank fully before usage.

Charging the Power Bank

- Using USB A to Type-C charging cable,insert the USB Charging cable into a certified USB AC adapter or USB port of a computer to begin charging.
- When charging, the LED will flash white,once fully charged LED will stop flashing.

Charging mobile phones and other electronic devices:

- Connect the charging cable to your mobile phone/device using the appropriate connector. Connect the USB A Part of the cable into the USB Output, The LED indicator will illuminate when charging.
- Remove the USB cable from your mobile phone/device when it is fully charged.

Bluetooth® Setup:

Connect the built-in audio cable from Speaker to the Left and Right output on the power bank, cable with white tip to the L port and with black tip to the R port . Turn on the power switch,Once on, Bluetooth LED indicator will flash BLUE. the speaker will enter Bluetooth pairing mode. Using a Bluetooth enabled device, search for "BOOM BAG" from the list of available options. LED will turn solid BLUE if successfully paired.

Safety Precautions

- This product is NOT a toy, keep away from children and pets.
- Only use the device according to the instructions in this manual.
- Never use the device for anything other than its intended purpose.
- Do not open this device or attempt to repair the unit yourself if it is not working properly. Doing so risks fire, shock or injury.
- When not in use, the device should be stored in a dry, cool location, away from sources of water or heat.
- Do not expose device or power cable to extreme temperatures (heat or cold), open flames, humid or wet conditions.
- Do not submerge in water. Do not use in a location where the device or power cable could fall into liquid.
- Unplug the charging cable when not in use. Do not pull the charging cable to disconnect, or use the cable as a handle.
- Do not use if device or power cable is damaged. If device or power cable is damaged, it MUST be serviced or replaced by the manufacturer or its service agent before using again.
- Low battery may cause dysfunction.

- Do not over charge battery.
- This device contains a built-in battery and should not be disposed of with regular household waste. Please consult the local authorities on the correct way to dispose of this device.

FCC Information

This device complies with Part 15 of the FCC Rules.

Caution: Any changes or modifications not expressly approved could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

