
# The Looking Glass 10000mAh Wireless Power Bank

Instruction Manual 7122-03



# Features:

- 1 LED Indicator
- 2 Powerbank ON/OFF Button
- 3. Type-C Input
- 4. USBA Output
- 5. Wireless Charging Surface

#### What's included:

- 1 x 10.000 mAh Wireless Power Bank
- 1 x USB to Type-C charging cable 1 x Instruction Manual

#### **Tech Specifications**

- 10000mAh/3.85V/38.5Wh Input power: DC 5V/2A
- USBA Output: DC 5V/2A
- Wireless Output: 5W

## I FD Indicators

 Press the Powerbank ON/OFF Button(2) once to view the remaining power capacity. Press the button twice to turn OFF

Number of LEDs | 0000 Rive | 0000 Blue | 0000 Blue | 0000 Blue Canacity Remaining obout 100% obout 75% obout 50% obout 25%

## INSTRUCTIONS:

connector

- 1. Charging the PowerBank:
- . Charge the powerbank fully before usage. . Connect the provided charging cable to a power source and to the Type-C Input port (3) on the powerbank.
- \* Once connected the LED Indicetor(1) will begin to flash when cahroing.
- Once fully charged LED will stop flashing.
- 2. Charging Electronic Devices with the Power Bank:
- · Connect the charging cable to your mobile phone/device using the appropriate
- . Connect the USB part of the cable to USB Output, the LED Indicator will illuminate when charging.
- · Remove the charging cable from your mobile device when fully charged.
- 3. Charging Electronic Devices with the
- Wireless Charging: Press Powerbank ON/OFF button(2)
- LED indicator will show Green once he powerbank is in wireless charging standby mode.
- · Place wireless charging enable device on Wireless Charging Pad(5). The device will begin to charge, LED indicator will turn RED when charging.
- \*\* Note: If the LED indicator is flashing RED an unknown object is being detected between the wireless charging pad and the phone by FOD(Foreign Object Detection). (The device will not begin to charge until object is removed.)

# SAFETY PRECAUTIONS:

- · WARNING-When using this product, basic precautions should always be followed: Read all the instructions before use.
- 2. Never store or use this product in temperatures below 32°F (0°C) or above 115°F (45°C)
- 3. Do not overcharge your phone. The unit may become hot under excessive use. Remove your phone once it is fully charged. Never charge your phone for more than 7 hours at a time
- 4. The unit will only achieve full performance after 2 or 3 completed charge and discharge cycles.
- 5. To reduce the risk of injury, close supervision is required when the product is used near children
- 6. Do not expose the device to moisture
- 7 Do not use the device in excess of its. output rating. Overload outputs above the
- rating may result in a risk of fire or injury. 8. Do not use the device if damaged or modified
- 9. Damaged or modified batteries may exhibit unpredictable behaviour resulting in fire. explosion or risk of injury.
- 10. Do not disassemble the device. For repairs, seek a qualified service professional, Incorrect reassembly may result in a risk of fire or injury.
- 11. Do not expose the device to fire or excessive temperatures. Exposure to fire or temperatures above 104°F (40°C) may result in explosion.
- 12. To ensure product safety, ensure that qualified service professionals use only identical replacement parts.
- 13. Attachments on the back of your phone can impede the effectiveness of the wireless charger, and lead to overheating

# Please remove attachments from the phone before charging on this device.

### This device complies with part 15 of the FCC Rules. Operation is subject to the

following two conditions: (1) This device may not cause harmful interference, and (2) this desire must accept any interference received, including interference that may cause undesired operation

Any Changes or modifications not expressly approved by the party responsible for compliance could you d the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and if not installed and used in accordance with the instructions, may raise harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television recention, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: -Reprient or relocate the receiving antenna

-Increase the separation between the equipment and receiver

Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. -Consult the dealer or an experienced radio/TV technician for help.

This equipment complies with FCC radiation emogure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.



20 mm **FSC** 3 Paper from responsible sources FSC® C161647

**FSC** 

2

က

2021.02.01